

[Manuals.plus](#) /

> [Jectse](#) /

> Jectse Slider 2G GSM Mobile Phone User Manual - Model Jectseh01frq3yoa-11

Jectse Jectseh01frq3yoa-11

Jectse Slider 2G GSM Mobile Phone User Manual

Model: Jectseh01frq3yoa-11

INTRODUCTION

Thank you for choosing the Jectse Slider 2G GSM Mobile Phone. This manual provides essential information for setting up, operating, and maintaining your device. Please read it carefully to ensure proper use and to maximize your phone's capabilities.

Important Note: This phone supports **2G GSM networks only**. Applicable frequency bands are GSM: 850/900/1800/1900 MHz. Please contact your local SIM card provider to confirm 2G network support in your area before use.

PACKAGE CONTENTS

Ensure all items are present in the package:

- 1 x Jectse Mobile Phone
- 1 x Charging Cable (Type-C)
- 1 x Lanyard
- 1 x User Manual

SETUP

1. SIM Card and Memory Card Installation

The phone features three card slots: one for a standard SIM card, one for a Nano-SIM card, and one for a memory card (up to 16GB, not included).

1. Carefully slide open the phone's back cover.
2. Locate the SIM card and memory card slots.
3. Insert your SIM card(s) and memory card into the respective slots, ensuring correct orientation.
4. Close the back cover securely.

2. Battery Installation and Charging

The phone comes with a 1000mAh lithium-ion battery.

1. If the battery is not pre-installed, insert it into the battery compartment, matching the contacts.
2. Connect the provided Type-C charging cable to the phone's charging port and plug the other end into a compatible USB power adapter (not included).
3. Allow the phone to charge fully before first use. The battery indicator on the screen will show charging status.

3. Powering On/Off

- **To Power On:** Press and hold the Power button until the screen lights up.
- **To Power Off:** Press and hold the Power button, then select 'Power Off' from the options on the screen.

4. Language Settings

The phone's default language is English. You can change the language in the settings menu. Supported languages include English, French, Spanish, Portuguese, Russian, Arabic, and Persian.

OPERATING INSTRUCTIONS

1. Slider Mechanism

The phone features a convenient slider design. Slide the top part of the phone upwards to reveal the keypad and unlock the device. Slide it down to cover the keypad and lock the device.



Image: The Jectse slider phone with its keypad revealed, demonstrating the open position.

2. Basic Phone Functions

- **Making Calls:** Enter the phone number using the keypad and press the Call button.
- **Answering Calls:** Press the Call button when the phone rings.
- **Sending/Receiving Text Messages:** Navigate to the 'Messages' menu to compose, send, and read text messages.
- **Speed Dial:** You can set up to 9 family numbers for quick dialing. Refer to the phone's menu for 'Speed Dial' settings.

3. Display and Audio

- **2.0-inch HD Display:** The phone features a 2.0-inch high-definition screen, providing clear and easy-to-read text.

- **High Volume Speaker:** The built-in high-volume speaker delivers clear audio for calls and multimedia.
- **3.5mm Headphone Jack:** Connect standard 3.5mm headphones for private listening.

2.0 inch high definition screen

The text is clear and easy to read.



Image: Multiple views of the Jectse phone, highlighting its 2.0-inch high-definition screen for clear text readability.

4. Multimedia and Additional Features

This phone includes various functionalities:

- **Camera:** The phone is equipped with a camera (approximately 300,000 pixels) for capturing photos.
- **MP3/MP4 Player:** Play your favorite audio and video files.
- **FM Radio:** Listen to FM radio broadcasts.
- **Bluetooth (BT) 4.0:** Connect to compatible Bluetooth devices.
- **Tools:** Alarm, Calendar, Flashlight, Calculator.
- **Games:** Enjoy pre-installed games.
- **Internet Access/Browser:** Basic internet browsing capabilities are supported.
- **Voice Changer:** A function allowing for voice modulation (male, female, child voices).

Supports making and receiving phone calls, sending and receiving text messages, camera, MP3 MP4, FM, alarm clock, calendar, flashlight, calculator, and games. Access the Internet/browser. Voice changing function.



Image: The Jectse phone displaying its screen, with an overlay listing its various features including calls, texts, camera, MP3/MP4, FM radio, BT, alarm, calendar, flashlight, calculator, games, internet access, and voice changing function.

MAINTENANCE

To ensure the longevity and optimal performance of your Jectse mobile phone, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the phone's screen and body. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the phone in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Exposure:** This phone is not waterproof. Avoid exposure to water or high humidity.
- **Battery Care:** Do not expose the battery to extreme heat or puncture it. Use only the provided charging cable.

TROUBLESHOOTING

If you encounter issues with your phone, refer to the following common solutions:

- **Phone does not power on:** Ensure the battery is charged. Connect the charger and try again.
- **No network signal:** Verify that your SIM card is correctly inserted. Confirm with your local provider that a 2G GSM network is available and supported in your area (GSM: 850/900/1800/1900 MHz).
- **Cannot make/receive calls or texts:** Check network signal strength. Ensure your SIM card is active and has sufficient credit/plan.
- **Screen is unresponsive:** Try restarting the phone. If the issue persists, ensure the screen is clean and free from damage.
- **Sound issues:** Check volume settings. Ensure the speaker is not obstructed. If using headphones, ensure they are properly connected.

SPECIFICATIONS

Feature	Detail
Model Number	Jectseh01frq3yoa-11
Screen Size	2.0 inches
Network Type	2G GSM
Frequency Bands	GSM: 850/900/1800/1900 MHz
SIM Card Slots	1 x Standard SIM, 1 x Nano-SIM
Memory Card Support	Up to 16GB (not included)
Battery Capacity	1000mAh Lithium-ion
Charging Port	Type-C
Headphone Jack	3.5mm
Bluetooth Version	4.0
Camera Pixels	Approx. 300,000
Supported Languages	English (default), French, Spanish, Portuguese, Russian, Arabic, Persian
Manufacturer	Jectse
Item Dimensions	10 x 10 x 6 cm (Package)
Item Weight	182 g (Package)

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the retailer. Keep your proof of purchase for any warranty claims.

You can also visit the official Jectse store for more information:[Jectse Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0G64N2JH1>

More documents and user manuals: <https://manuals.plus/>