VELECO SHARPY PRO

VELECO SHARPY PRO Mobility Scooter User Manual

Model: SHARPY PRO | Brand: VELECO

1. Important Safety Information

Before operating the VELECO SHARPY PRO mobility scooter, please read and understand all safety instructions. Failure to follow these instructions may result in injury or damage to the scooter.

- **Keep away from fire or direct heat sources.**
- Always wear appropriate safety gear, including a helmet, if required by local regulations.
- Ensure the battery is fully charged before each use to avoid unexpected power loss.
- Do not operate the scooter under the influence of alcohol or medication that may impair your judgment.
- Always check the scooter for any damage or loose parts before operation.
- Adhere to all local traffic laws and regulations when operating the scooter in public areas.

2. Setup and Assembly

The VELECO SHARPY PRO mobility scooter requires minimal assembly. Follow these steps to prepare your scooter for first use:

1. **Unboxing:** Carefully remove all components from the packaging. Retain packaging for future transport or storage.
2. **Seat Installation:** Place the captain-style seat onto the seat post and ensure it locks securely into position. Adjust the seat height and swivel as needed for comfort.
3. **Steering Column Adjustment:** Adjust the angle and height of the steering column to a comfortable operating position. Tighten all adjustment knobs firmly.
4. **Battery Charging:** Connect the charger to the scooter's charging port and then to a standard electrical outlet. Allow the battery to charge completely before initial use. Refer to the 'Battery Charging' section for detailed instructions.
5. **Tire Pressure Check:** Verify that all four tires are inflated to the recommended pressure as indicated on the tire sidewall.



Image: Angled front view of the VELECO SHARPY PRO mobility scooter, showing the seat, steering column, and front wheels.

3. Operating Instructions

The VELECO SHARPY PRO is designed for intuitive operation. Familiarize yourself with the controls before driving.

3.1 Starting the Scooter

- **Keyless NFC Start:** Tap your NFC key card to the designated area on the dashboard to power on the scooter.
- The digital display will illuminate, showing battery level, speed, and other operational information. You can select from three display designs.

3.2 Driving Controls

- **Forward/Reverse Levers:** Use the levers on the handlebars to control forward and reverse motion. Gently press to

accelerate.

- **Steering:** Turn the handlebars to steer the scooter. The four-wheel structure and full suspension provide stable handling.
- **Automatic Speed Reduction:** The scooter features an intelligent system that automatically reduces speed when turning, enhancing safety and control.
- **Speed Control:** Use the speed regulator to set your desired maximum speed.
- **Braking:** Release the forward/reverse levers to engage the automatic electromagnetic brake. For emergency braking, use the manual brake lever if equipped.

3.3 Integrated Features

- **Bluetooth Speaker:** Connect your mobile device via Bluetooth to play audio.
- **USB Port:** Use the USB port to charge your mobile devices.
- **Card Slot:** Insert a memory card for additional media playback.
- **Mobile Phone Holder:** Securely place your phone in the integrated holder.
- **Mirrors and Horn:** Utilize the mirrors for rear visibility and the horn to alert others.



Image: Angled rear view of the VELECO SHARPY PRO mobility scooter, highlighting the comfortable seat and rear wheel design.

4. Maintenance

Regular maintenance ensures the longevity and optimal performance of your VELECO SHARPY PRO scooter.

- **Battery Care:** Charge the battery regularly, even if the scooter is not in use for extended periods, to maintain battery health. Avoid fully discharging the battery.
- **Tire Maintenance:** Check tire pressure weekly and inflate to the recommended PSI. Inspect tires for wear and tear.
- **Cleaning:** Clean the scooter regularly with a damp cloth. Avoid using harsh chemicals or high-pressure water jets, which can damage electrical components.
- **Inspections:** Periodically check all nuts, bolts, and fasteners for tightness. Ensure all lights and indicators are functioning correctly.
- **Professional Service:** For any complex repairs or issues, contact an authorized service technician.



Image: Detailed view of the front wheel and suspension system, emphasizing the robust design.

5. Troubleshooting

This section addresses common issues you might encounter with your VELECO SHARPY PRO scooter.

Problem	Possible Cause	Solution
Scooter does not power on	Battery discharged; NFC key not detected; Power switch off	Charge battery; Ensure NFC key is correctly tapped; Check main power switch
Motor not engaging	Brake engaged; Loose connection; Faulty motor	Release brake; Check connections; Contact service center

Problem	Possible Cause	Solution
Reduced range/power	Battery degradation; Under-inflated tires; Overload	Replace battery if old; Inflate tires to correct pressure; Reduce load
Unusual noises	Loose components; Worn bearings; Obstruction	Inspect scooter for loose parts; Contact service for inspection

If you experience issues not listed here or if solutions do not resolve the problem, please contact VELECO customer support.

6. Specifications

Key technical specifications for the VELECO SHARPY PRO mobility scooter:

Feature	Detail
Model Reference	SHA-PRO
Dimensions (L x W x H)	204 x 75 x 149 cm
Weight	190 kg
Motor	High-performance motor
Suspension	Full advanced suspension
Wheels	Four large wheels
Start System	Keyless NFC
Safety Features	Automatic speed reduction in curves
Connectivity	Bluetooth speaker, USB port, card slot
Manufacturer	Veleco
Country of Origin	Poland



Image: Side profile of the VELECO SHARPY PRO, illustrating its overall dimensions and design.

7. Warranty and Support

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. VELECO offers customer support for technical assistance, parts, and service inquiries.

Please visit the official VELECO website or contact your authorized dealer for the most up-to-date support information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question