

taopodo S7

taopodo S7 Portable Bluetooth Speaker User Manual

Model: S7

[Introduction](#)

[Setup](#)

[Operating Instructions](#)

[Maintenance
Support](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty &](#)

1. INTRODUCTION

Thank you for choosing the taopodo S7 Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. Please read this manual thoroughly before use.



Image 1.1: taopodo S7 Portable Bluetooth Speaker, front view.

2. SETUP

2.1 Charging the Speaker

Before first use, fully charge the speaker using the provided USB-C charging cable. Connect the USB-C end to the speaker's charging port and the USB-A end to a compatible power adapter (not included) or a computer's USB port. The charging indicator light will show the charging status.



Image 2.1: Speaker showing USB-C charging port and TF card slot.

2.2 Bluetooth Pairing

1. **Power On:** Press and hold the power button (circle icon) on the top of the speaker until you hear an audible prompt and the LED lights illuminate.
2. **Activate Bluetooth:** On your mobile device, navigate to the Bluetooth settings and ensure Bluetooth is enabled.
3. **Select Speaker:** Look for "S7" in the list of available devices and select it to pair. You will hear a confirmation sound once connected.

Wide Compatibility

Suitable for laptops, tablets, phones



USB Port



TF Card



Image 2.2: Speaker displaying Bluetooth connection with a smartphone.

2.3 True Wireless Stereo (TWS) Pairing (Optional)

To achieve a stereo sound experience, you can pair two taopodo S7 speakers together:

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On both speakers, press and hold the 'M' (Mode) button simultaneously.
3. The speakers will enter TWS pairing mode and connect to each other. A confirmation sound will indicate successful pairing.
4. Once paired, connect your mobile device to one of the speakers via Bluetooth as described in Section 2.2. Both speakers will now play audio in stereo.

Your browser does not support the video tag.
Video 2.3: Demonstration of TWS pairing for two taopodo S7 speakers.



Image 2.4: Visual representation of two taopodo S7 speakers connected in TWS mode.

3. OPERATING INSTRUCTIONS

3.1 Basic Controls

The speaker features intuitive controls located on the top panel:

- **Power Button (Circle):** Press and hold to power on/off.

- **Volume Up (+):** Press to increase volume.
- **Volume Down (-):** Press to decrease volume.
- **Play/Pause Button (Triangle):** Press to play or pause audio.
- **Mode Button (M):** Press to cycle through input modes (Bluetooth, TF Card, USB). Long press for TWS pairing.
- **Light Mode Button (Sun/Star icon):** Press to change the RGB lighting effects.

Your browser does not support the video tag.

Video 3.1: Demonstration of power, volume, and light controls on the taopodo S7 speaker.

3.2 RGB Lighting

The speaker features multiple RGB lighting modes. Press the Light Mode button (Sun/Star icon) to cycle through different colors and rhythm changes. This allows for customization of the visual experience.

Colorful RGB Light

20 colors * 10 rhythm changes



Image 3.2: taopodo S7 speaker showcasing various colorful RGB light modes.

3.3 Call Handling

When connected via Bluetooth, the speaker's built-in microphone allows for hands-free calling. Incoming calls can be answered or ended directly from the speaker (specific button functionality may vary, refer to general play/pause button for call control).



Image 3.3: Speaker highlighting its HD Call and Built-in Microphone capabilities.

3.4 Alternative Playback Options

In addition to Bluetooth, the speaker supports audio playback from a TF (Micro SD) card (up to 128GB) and a USB drive. Insert the media into the respective port, and the speaker will automatically switch to the corresponding mode or can be selected using the 'M' (Mode) button.

4. MAINTENANCE

The taopodo S7 speaker is designed for durability and features an IPX7 waterproof rating, making it suitable for outdoor use and resistant to submersion in water up to 1 meter for 30 minutes. To maintain its condition:

- Ensure the charging port cover is securely closed when near water.
- Clean the speaker with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- Store the speaker in a cool, dry place when not in use.
- Avoid exposing the speaker to extreme temperatures or direct sunlight for extended periods.



Image 4.1: Speaker demonstrating its IPX7 waterproof capability.

5. TROUBLESHOOTING

If you encounter issues with your taopodo S7 speaker, refer to the following common solutions:

- **Speaker does not power on:** Ensure the battery is charged. Connect the speaker to a power source using the USB-C cable.
- **Cannot pair via Bluetooth:**
 - Ensure the speaker is in pairing mode (LED indicator blinking).
 - Turn off Bluetooth on your device and turn it back on.

- Forget "S7" from your device's Bluetooth list and attempt to pair again.
- Ensure the speaker is not already connected to another device.

- **No sound or low volume:**

- Check the volume levels on both the speaker and your connected device.
- Ensure the speaker is properly paired.
- If using TWS, ensure both speakers are correctly paired to each other and then to your device.

- **TWS pairing fails:**

- Ensure both speakers are powered on and not connected to any other Bluetooth device.
- Try repeating the TWS pairing steps (long press 'M' on both speakers).

6. SPECIFICATIONS

Feature	Detail
Product Dimensions	4 x 7 x 4 inches
Item Weight	2.18 pounds
Item Model Number	S7
Brand	taopodo
Mounting Type	Tabletop Mount
Color	Black
Connectivity	Bluetooth 5.4, USB, TF Card
Power Output	30W
Waterproof Rating	IPX7
Battery Life	Up to 30 hours (with lights off and 20% volume)



Image 6.1: Visual representation of the speaker's 30-hour battery life.



ENHANCE BASS 3.0

20Hz ultra-low diving, with a 150% increase in bass and heavy bass even at low volumes.




Image 6.2: Diagram illustrating the 66MM high-fidelity speaker driver.

7. WARRANTY & SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or contact taopodo customer service directly through their official website or the retailer where the product was purchased. Specific warranty terms and conditions may vary.