

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [SGIN](#) /

› [SGIN-Y101 15.6 Inch Laptop User Manual](#)

SGIN SGIN-Y101

SGIN-Y101 15.6 Inch Laptop User Manual

Model: SGIN-Y101

Brand: SGIN

1. SETUP

This section guides you through the initial setup of your SGIN-Y101 laptop.

1.1 Unboxing and Initial Inspection

Carefully remove all components from the packaging. Ensure the following items are present:

- SGIN-Y101 Laptop
- Power Adapter/Charger
- User Manual (this document)

Inspect the laptop for any physical damage. If you find any damage or missing components, contact customer support immediately.

Multiple Interfaces are More Convenient to Use



Image: SGIN-Y101 laptop connected to its power adapter.

1.2 Charging the Battery

Before first use, it is recommended to fully charge the laptop battery. Connect the power adapter to the laptop's charging port and then plug it into a power outlet. The charging indicator light will typically illuminate to show that the device is charging.

1.3 First Boot and Windows 11 Setup

Press the power button to turn on your laptop. The system will guide you through the initial Windows 11 setup process. Follow the on-screen instructions to:

1. Select your region and keyboard layout.
2. Connect to a Wi-Fi network.
3. Accept the license terms.
4. Create or sign in with a Microsoft account.
5. Set up a PIN for quick login.
6. Adjust privacy settings.

Once the setup is complete, your laptop will be ready for use.

2. OPERATING YOUR LAPTOP

This section covers the basic operation of your SGIN-Y101 laptop.

2.1 Power On/Off and Sleep Mode

- **Power On:** Press the power button located on the keyboard.
- **Power Off:** Click the Windows Start button, then select Power > Shut down.
- **Sleep Mode:** Close the laptop lid or click the Windows Start button, then select Power > Sleep.

Powerful and Fast CPU

Newly upgraded CPU i3 is smoother and faster

- 2 Cores
- 4 Threads
- 3.9Ghz Turbo Boost
- 5w Power Consumption
- 6MB Cache

CORE i3 10th Gen

CPU Performance Comparison

Processor	Performance Level
i3 CPU	High (Longest bar)
N5095	Medium (Shorter bar)
N4020	Low (Shortest bar)

Image: The SGIN-Y101 laptop with its screen displaying the Windows desktop and the keyboard visible.

2.2 Keyboard and Touchpad

Your laptop features a full-size keyboard with a numeric keypad and a precision touchpad.

- **Backlit Keyboard:** To turn the keyboard backlight on or off, press the **FN + F5** keys simultaneously.

- **Touchpad:** Supports multi-touch gestures for navigation. Refer to Windows settings for customization.

Backlit Keyboard and Full Numeric Keyboard



Backlit Keyboard



Full Numeric Keypad




Image: A close-up view of the SGIN-Y101 laptop's keyboard with the backlight illuminated.

2.3 Display Features

The SGIN-Y101 laptop is equipped with a 15.6-inch Full HD (1920x1080) IPS display, offering wide viewing angles and vibrant colors. The 180° hinge design allows for flexible screen positioning, facilitating collaboration and content sharing.

1920x1080

15.6" FHD Visual Experience

The narrow frame design allows you to enjoy the maximum 1920*1080 viewing experience

1080P FULL HD **IPS** **2K** 

Full HD 1920*1080 IPS Color Screen Brilliant Vision Display Eye Protection

Image: The SGIN-Y101 laptop screen showcasing a high-resolution image, highlighting its visual clarity.

2.4 Connectivity

Your laptop provides various ports and wireless connectivity options:

- **USB 3.0 Ports:** For connecting peripherals like external drives, mice, and keyboards.
- **HDMI Port:** To connect to external monitors or projectors.
- **Micro SD Slot:** For expanding storage with a TF card up to 1TB.
- **Type-C Port:** A versatile port for data transfer and potentially charging (check specifications for charging capability).
- **3.5mm Headphone Jack:** For audio output.
- **Wi-Fi 6:** For high-speed wireless internet connection.

Endless Power, Unleash Your Ideas




Image: A detailed view of the side of the SGIN-Y101 laptop, highlighting its various connectivity ports including USB, HDMI, and Type-C.

3. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your laptop.

3.1 Cleaning

- **Screen:** Use a soft, lint-free cloth slightly dampened with water or a screen cleaner. Avoid harsh chemicals.
- **Keyboard and Chassis:** Use a soft cloth to wipe surfaces. Compressed air can be used to remove dust from between keys.
- **Ports:** Keep ports free of dust and debris to ensure proper connections.

3.2 Battery Care

- Avoid extreme temperatures.
- Do not fully discharge the battery frequently.

- If storing the laptop for an extended period, ensure the battery is charged to about 50-70%.

3.3 Software Updates

Regularly update your Windows 11 operating system and drivers to ensure security, stability, and optimal performance. You can check for updates via Windows Settings > Windows Update.

3.4 Storage Management

Your laptop comes with a 1024GB SSD. To maintain performance:

- Regularly delete unnecessary files.
- Uninstall unused applications.
- Utilize cloud storage for large files.
- Consider using a TF card for additional storage if needed.

4. TROUBLESHOOTING

This section addresses common issues you might encounter with your SGIN-Y101 laptop.

4.1 Power Issues

- **Laptop not turning on:** Ensure the power adapter is securely connected and the battery has sufficient charge. Try holding the power button for 10-15 seconds to perform a hard reset.
- **Battery not charging:** Check the power adapter and cable for damage. Try a different power outlet.

4.2 Display Problems

- **Blank screen:** Connect an external monitor to check if the display output works. If it does, the laptop screen might be faulty. If not, there could be a system issue.
- **Flickering screen:** Update your graphics drivers. Adjust display refresh rate in Windows settings.

4.3 Keyboard and Touchpad Issues

- **Keys not responding:** Ensure no debris is under the keys. Restart the laptop. If specific function keys (like volume or brightness) are not working, ensure you are pressing the **FN** key in combination with the desired function key, or check if a driver update is needed.
- **Touchpad not working:** Ensure the touchpad is not disabled (check function keys, usually **FN + F10** or similar icon). Update touchpad drivers.

4.4 Connectivity Problems

- **Wi-Fi not connecting:** Ensure Wi-Fi is enabled in Windows settings. Restart your router and laptop. Update Wi-Fi drivers.
- **USB devices not recognized:** Try a different USB port. Update USB drivers.

If these steps do not resolve your issue, please contact SGIN customer support for further assistance.

5. SPECIFICATIONS

Detailed technical specifications for the SGIN-Y101 15.6 Inch Laptop.

Feature	Specification
---------	---------------

Feature	Specification
Brand	SGIN
Model Name	SGIN-Y101
Operating System	Windows 11
Screen Size	15.6 Inches
Display Resolution	1920 x 1080 (Full HD IPS)
Processor	Intel Core i3-10100 (2-core, 4-thread, up to 3.9GHz)
RAM	16 GB DDR3
Storage	1024 GB SSD (Expandable with TF card up to 1TB)
Graphics Card	Integrated
Battery	7000mAh / 53.2Wh (Up to 8 hours battery life)
Wireless Connectivity	WiFi 6
Ports	2x USB 3.0, HDMI, Micro SD slot, Kensington lock, 3.5mm Headphone Jack, Type-C
Special Features	Backlit Keyboard, 180° Viewing Angle
Item Weight	4.99 pounds
Product Dimensions	14.56 x 9.4 x 0.86 inches

6. WARRANTY AND SUPPORT

Your SGIN-Y101 laptop comes with a 1-year protection plan. SGIN also offers 24/7 customer instant help for any issues or questions you may have.

6.1 Warranty Information

Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects under normal use conditions. It does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

6.2 Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact SGIN customer support through the official channels provided at the time of purchase or on the SGIN official website.