Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lenz Heat Socks 5.1 Toe Cap Regular Fit

Lenz Heat Socks 5.1 Toe Cap Regular Fit Instruction Manual

1. Introduction

This manual provides essential information for the proper use, setup, operation, and maintenance of your Lenz Heat Socks 5.1 Toe Cap Regular Fit. Please read these instructions carefully before using the product to ensure optimal performance and longevity.

2. Product Overview

The Lenz Heat Socks 5.1 Toe Cap Regular Fit are designed to provide warmth to your feet, particularly in the toe cap area. They feature a regular fit and are constructed from a blend of durable and comfortable materials.
Key Features:

- Integrated heating elements in the toe cap area.
- Regular fit design for comfort.
- Fabric blend for warmth and durability.



Image: Lenz Heat Socks 5.1 Toe Cap Regular Fit, showing the overall design.



Image: A close-up view of the toe cap area of the Lenz Heat Socks 5.1, highlighting the integrated heating elements and stitching.



Image: A detailed view of the ribbed texture on the leg portion of the Lenz Heat Socks 5.1, indicating a supportive or ergonomic design.



Image: Another close-up showing the varied knit patterns on the Lenz Heat Socks 5.1, suggesting different compression or cushioning zones.



Image: A close-up of the fabric weave of the Lenz Heat Socks 5.1, demonstrating the quality and composition of the material.



Image: A close-up of the heel or arch area of the Lenz Heat Socks 5.1, showing a subtle logo or size marking.

3. Setup

The Lenz Heat Socks 5.1 require a compatible Lenz battery pack for operation. Please note that**battery packs are sold separately** and are not included with the socks. Ensure you have purchased the correct battery pack for your socks.

3.1 Initial Battery Charging

1. Connect your Lenz battery pack to the provided charger.

2. Plug the charger into a standard wall outlet.
3. Allow the battery pack to charge fully before first use. Refer to your battery pack's specific instructions for charging indicators and times.

3.2 Connecting Socks to Battery Packs

1. Locate the connection cable inside the cuff of each sock.
2. Carefully connect the cable from the sock to the corresponding port on the fully charged Lenz battery pack.
3. Secure the battery pack in the designated pocket on the sock cuff or using a compatible attachment system. Ensure the connection is firm to prevent accidental disconnection during use.

4. Operating Instructions

Once the battery packs are connected, you can begin operating your heated socks.

4.1 Powering On/Off

- To power on, press and hold the power button on the battery pack for approximately 2-3 seconds until an indicator light appears.
- To power off, press and hold the power button again for 2-3 seconds until the indicator light turns off.

4.2 Adjusting Heat Settings

The Lenz Heat Socks 5.1 typically offer multiple heat settings, often up to 9 levels, allowing you to customize the warmth. The heating element is primarily located in the front top part and the toes of the socks.

- **Using Battery Pack Buttons:** Briefly press the power button on the battery pack to cycle through the available heat levels. Each press will typically increase or decrease the heat, indicated by a change in the LED lights on the battery pack.
- **Using the Lenz Heat App:** For more precise control, download the official Lenz Heat App on your smartphone. Pair your battery packs with the app via Bluetooth. The app allows you to adjust heat levels, monitor battery status, and customize settings. Note that the app may require registration and might reset to default settings upon reopening.

4.3 Battery Life

Battery life varies significantly depending on the chosen heat setting and battery pack capacity. On the highest setting (e.g., level 9), a large capacity battery pack (e.g., 1800 mAh) may last approximately 5 hours. Lower heat settings will extend battery life.

5. Maintenance

Proper care and maintenance will extend the life of your Lenz Heat Socks 5.1.

5.1 Washing Instructions

The socks are machine washable. Always disconnect and remove the battery packs before washing.

- Machine wash cold on a gentle cycle.
- Do not bleach.
- Do not iron.

- Do not dry clean.
- Air dry only. Do not tumble dry, as high heat can damage the heating elements.

5.2 Battery Care

- Store battery packs in a cool, dry place when not in use.
- Avoid fully discharging the batteries for extended periods. Recharge them periodically, even during storage, to maintain battery health.
- Do not expose battery packs to extreme temperatures or moisture.

6. Troubleshooting

If you encounter issues with your Lenz Heat Socks 5.1, refer to the following common troubleshooting steps:

- **Socks not heating:**
  - Ensure battery packs are fully charged.
  - Verify that the battery packs are securely connected to the socks.
  - Check if the battery packs are powered on.
- **Uneven heating or cold areas:**
  - The heating elements are concentrated in the toe cap area. Other parts of the foot may not receive direct heat.
  - Ensure socks are worn correctly and not bunched up, which could affect heat distribution.
- **App connectivity issues:**
  - Ensure Bluetooth is enabled on your smartphone.
  - Make sure the battery packs are powered on and within range of your device.
  - Try restarting the app or your smartphone.
  - If the app consistently shows default settings, manually adjust via battery buttons or re-pair the devices.
- **Short battery life:**
  - Higher heat settings consume battery power more quickly. Reduce the heat level for longer duration.
  - Ensure battery packs are fully charged before each use.
  - Consider purchasing higher capacity battery packs if extended warmth is required.

If these steps do not resolve the issue, please contact Lenz customer support for further assistance.

7. Specifications

Feature	Detail
Model	Heat Socks 5.1 Toe Cap Regular Fit
Fabric Type	30% polyester, 25% merino wool, 20% nylon
Care Instructions	Machine Wash

Origin	Made in the USA or Imported
Item Weight	0.2 Kilograms
Unit Count	1.0 Count (Socks Only)

8. Warranty and Support

The Lenz Heat Socks 5.1 Toe Cap Regular Fit come with a**Limited Warranty**. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty documentation included with your product or visit the official Lenz website.
For technical support, warranty claims, or any other inquiries, please contact Lenz customer service through their official website or the contact information provided with your purchase.

© 2024 Lenz. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G6G5HG1W

More documents and user manuals: **https://manuals.plus/**