

[Manuals.plus](#) /

› [Globlazer](#) /

› Globlazer Large Cat Tree Tower F76C User Manual

Globlazer F76C

Globlazer Large Cat Tree Tower User Manual

Model: F76C

PRODUCT OVERVIEW

The Globlazer Large Cat Tree Tower, model F76C, is a multi-level cat furniture designed to provide a comprehensive activity center for adult cats. It features various elements for climbing, scratching, lounging, and playing, promoting physical activity and mental stimulation.



Image: The Globlazer Large Cat Tree Tower, showcasing its multi-level design and various features.

SAFETY INSTRUCTIONS

- Ensure all components are securely fastened during assembly to prevent instability.
- Place the cat tree on a flat, stable surface to minimize wobbling.
- Regularly inspect the cat tree for loose parts, wear, or damage. Tighten screws and replace worn components as necessary.
- Keep children away from the cat tree during assembly and supervise them when cats are actively using it.
- This product is intended for indoor use only.

ASSEMBLY INSTRUCTIONS

The Globlazer Large Cat Tree Tower is designed for straightforward assembly. Follow the detailed step-by-step instructions provided in the included assembly guide. A visual guide is typically included to assist with the process.

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list in your assembly guide.
2. **Identify Base:** Begin by assembling the base structure, ensuring it is stable and level.
3. **Attach Posts and Platforms:** Connect the scratching posts and platforms according to the numerical sequence or diagram in your guide. Ensure all screws are tightened firmly.
4. **Install Condos and Accessories:** Attach the cat condos, hanging basket, and other accessories as indicated.
5. **Final Check:** Once assembled, gently shake the entire structure to confirm stability. Retighten any loose connections.



Image: An illustrative diagram of the cat tree's structure, indicating various components and their positions.

OPERATING INSTRUCTIONS

This cat tree provides multiple areas for your cats to engage in natural behaviors.

- **Climbing and Exploring:** The multi-level design encourages cats to climb and explore different heights.

- **Scratching:** Utilize the natural sisal scratching posts to satisfy your cat's urge to scratch, helping to maintain nail health and protect your furniture.
- **Lounging and Resting:** The cozy condos, extra-large platforms, and hanging basket offer comfortable spots for napping and relaxation.
- **Playing:** Integrated toys (if applicable) and varied surfaces provide opportunities for play and exercise.



Image: An extra-large platform providing a comfortable lounging area for cats.



Image: Two spacious cat condos offering private resting and hiding spots.

JUST FOR FUN! Expanded Play Area

Providing cats with varied paths
and spaces for play



Image: Cats utilizing the expanded play areas, including scratching posts and a hanging basket.

MAINTENANCE

Regular maintenance ensures the longevity and safety of your Globlazer Cat Tree Tower.

- **Cleaning Plush Surfaces:** Use a vacuum cleaner with a brush attachment to remove loose fur and dust from the plush covering. For spot cleaning, use a damp cloth with mild soap and water, then air dry thoroughly. Avoid harsh chemicals.
- **Sisal Scratching Posts:** Periodically check the sisal ropes for wear and tear. While durable, heavily used areas may fray over time.
- **Structural Integrity:** Every few months, check all screws and connections to ensure they remain tight. Retighten as needed to maintain stability.
- **Odor Control:** If odors develop, sprinkle baking soda on plush surfaces, let it sit for 15-30 minutes, then vacuum thoroughly.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Cat tree is wobbly	Loose connections; uneven surface	Ensure all screws are tightened. Place on a flat, stable floor.
Cats not using scratching posts	Preference for other surfaces; unfamiliarity	Encourage use with catnip spray or by gently guiding paws. Place near preferred scratching areas.
Plush covering appears dirty	Accumulation of fur and dust	Vacuum regularly. Spot clean with a damp cloth and mild soap.

SPECIFICATIONS

Brand: Globlazer

Model: F76C

ASIN: B0G6JMW34T

Overall Height: Approximately 76 inches

Color: Beige

Main Material: Premium particle board, skin-friendly plush covering, natural sisal rope

Large Cat Condo Dimensions: 19.69" (L) x 12.6" (W) x 11.81" (H)

Unit Count: 1

WARRANTY AND SUPPORT

For specific warranty information regarding your Globlazer Cat Tree Tower, please refer to the documentation included with your purchase or contact the retailer where the product was acquired. Globlazer provides customer support for product inquiries and assistance.

You can visit the official Globlazer store for more information and support:[Globlazer Amazon Store](#)

© 2025 Globlazer. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question