

COZPAW WJG-2406

COZPAW 3-Tier Toy Storage Organizer with Movable Bins User Manual

Model: WJG-2406 | Brand: COZPAW

INTRODUCTION

Thank you for choosing the COZPAW 3-Tier Toy Storage Organizer with Movable Bins. This manual provides essential information for the safe assembly, operation, and maintenance of your new storage unit. Please read these instructions carefully before use and retain them for future reference.

SAFETY INFORMATION

Important Safety Instructions:

- Always assemble the product according to the instructions provided.
- Do not overload the shelves to prevent tipping.
- Keep the area around the shelf clear to avoid tripping hazards.
- Ensure the anti-tip device is properly installed to enhance stability and safety, especially in households with children.
- This product is designed for indoor use only.
- Regularly check all fasteners and connections to ensure they remain tight.



Figure 1: Anti-Tip Device Installation. The anti-tip device secures the organizer to the wall, preventing accidental tipping and ensuring safety.



Figure 2: Rounded Corner Design. Thoughtfully designed rounded corners help protect children from injuries due to collisions.

SPECIFICATIONS

Feature	Description
---------	-------------

SETUP AND ASSEMBLY

Assembly of the COZPAW Toy Storage Organizer is required. All necessary hardware is included. Please follow the detailed assembly instructions provided in the packaging. Ensure all components are present and undamaged before beginning assembly.

1. Unpack all components and verify against the parts list in your separate assembly guide.
2. Assemble the main frame of the organizer, ensuring all screws are tightened securely.
3. Install the shelves into their designated slots.
4. Attach the wheels to the movable bins.
5. Insert the assembled bins into the bottom tier of the organizer.
6. Install the anti-tip device to a wall stud using appropriate hardware to prevent accidental tipping.



Figure 4: Baffle Protection. The baffle protection on each shelf helps prevent items from falling off.

OPERATING INSTRUCTIONS

The COZPAW Toy Storage Organizer is designed for easy access and organization of children's items.

- **Shelves:** Utilize the three open shelves for displaying books, larger toys, or decorative items. The design allows for easy visibility and access.
- **Movable Bins:** The two bottom bins are equipped with smooth-rolling wheels, allowing children to easily pull them out for play and push them back for cleanup. This feature promotes independence and organization.



Figure 5: Rolling Drawers. The bins can be easily rolled out for access to toys and rolled back for storage.

Large Capacity Kids Toy Organizer

Tabletop for Ornaments

Spacious Shelf for Books

Large Shelf for Stuffed Animals

Movable Drawers for Small Items

Figure 6: Spacious Storage. The organizer offers ample space for various items, promoting a tidy play area.

MAINTENANCE

To maintain the quality and appearance of your COZPAW Toy Storage Organizer:

- **Cleaning:** Wipe with a dry cloth. Avoid using harsh chemicals or abrasive cleaners, which may damage the finish.
- **Inspection:** Periodically check all screws and connections to ensure they are tight. Re-tighten if necessary.
- **Placement:** Avoid prolonged exposure to direct sunlight or extreme humidity to prevent material degradation.

TROUBLESHOOTING

If you encounter any issues with your COZPAW Toy Storage Organizer, please refer to the following common solutions:

- **Instability:** Ensure all screws are fully tightened. Verify that the anti-tip device is correctly installed and secured to a wall stud. Place the organizer on a flat, level surface.

- **Drawers not rolling smoothly:** Check for any obstructions under the wheels or in the drawer tracks. Clean the wheels and tracks if necessary. Ensure the wheels are securely attached.
- **Missing parts:** If any parts are missing upon unboxing, please contact customer support immediately for assistance.

WARRANTY AND SUPPORT

COZPAW stands behind the quality of its products. For warranty information, product support, or to report any issues, please contact COZPAW customer service through the retailer's platform or the official COZPAW website. Please have your model number (WJG-2406) and purchase date available when contacting support.

© 2026 COZPAW. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question