

DAMCROP XG04YM

DAMCROP Fluted Shoe Cabinet with 2 Flip Drawers Instruction Manual

Model: XG04YM

1. PRODUCT OVERVIEW

This manual provides essential information for the assembly, operation, and maintenance of your DAMCROP Fluted Shoe Cabinet. Designed with a slim profile and vertical flip drawers, this cabinet offers efficient shoe storage while complementing your home decor.

Key Features:

- Slim, space-saving design with a curved profile.
- Two vertical flip drawers for hidden shoe storage.
- Removable double-layer panels for customizable shoe compartment sizes.
- Guardrail top surface for secure placement of decorative items.
- Constructed with solid wood legs and durable hardware for stability.



Image 1.1: The DAMCROP Fluted Shoe Cabinet in a typical entryway setting.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Anti-Tipping Device:** It is mandatory to install the included anti-tipping device to prevent the cabinet from falling, especially in households with children or pets. Securely attach the cabinet to the wall using the provided hardware.
- **Weight Capacity:** Do not overload the cabinet or place excessively heavy items on the top surface or inside the drawers.
- **Stability:** Ensure the cabinet is placed on a flat, stable surface. Adjust the feet if necessary to prevent wobbling.
- **Children Safety:** Do not allow children to climb on or play with the cabinet. Keep small parts away from children during assembly.
- **Assembly:** Assemble the unit according to the instructions. Do not use power tools for tightening screws unless specifically instructed, as this may strip the threads or damage the material.



Image 2.1: Illustration of the anti-tipping device securely attaching the cabinet to the wall.

3. SETUP AND ASSEMBLY

Assembly of the DAMCROP Fluted Shoe Cabinet is required. Please follow the detailed instructions provided in the separate assembly guide included with your product. Ensure all parts are present before beginning assembly.

Recommended Tools:

- Phillips head screwdriver
- Hammer (for dowels)
- Measuring tape (for placement)

General Assembly Steps:

1. Unpack all components and verify against the parts list.
2. Assemble the main frame of the cabinet.
3. Install the flip drawer mechanisms and panels.
4. Attach the solid wood legs.
5. Install the anti-tipping device to a wall stud or appropriate anchor point.

Product Dimensions




Image 3.1: Detailed product dimensions for planning placement.

4. OPERATING INSTRUCTIONS

The DAMCROP Fluted Shoe Cabinet is designed for convenient and organized shoe storage.

Using the Flip Drawers:

- Gently pull the handle on each drawer to open the flip mechanism. The drawer will tilt forward, revealing two tiers for shoe placement.
- To close, push the drawer back until it clicks securely into place.

Customizing Storage:

Each flip drawer features removable double-layer panels. These panels allow you to adjust the internal space to accommodate various shoe types, from flats and sandals to sneakers and short boots.

- To remove a panel: Carefully lift and slide the panel out of its slots.
- To re-insert a panel: Align the panel with the desired slots and slide it into place until secure.



Image 4.1: Demonstrates how to remove panels to accommodate taller shoes.

2-Tier Storage with Metal Adjustable Slots



High Heels



Slippers



sneaker



Leather Shoes



Sports Shoes

Image 4.2: Visual guide for storing various shoe types within the 2-tier system.

Top Surface Usage:

The guardrail top surface is designed to securely hold decorative items such as plants, picture frames, keys, or small bags, preventing them from falling off.

Anti-Drop Shield Countertop

Place decorations or objects such as potted plants keys and bags



Image 4.3: The anti-drop shield countertop in use with various items.

5. MAINTENANCE

Proper maintenance will ensure the longevity and appearance of your shoe cabinet.

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, which can damage the finish.
- **Dust Protection:** The enclosed design of the flip drawers helps keep shoes away from dust and water stains. Regularly wipe down the exterior to maintain cleanliness.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they are tight. Re-tighten if necessary to maintain structural integrity.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood finish.

keep your shoes away from dust and water stains



Image 5.1: The cabinet's design helps protect shoes from dust and water.

6. TROUBLESHOOTING

If you encounter any issues with your shoe cabinet, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cabinet wobbles	Uneven floor surface; loose assembly screws	Ensure cabinet is on a flat surface. Adjust leveling feet if present. Check and tighten all assembly screws.
Flip drawers do not open/close smoothly	Obstruction; misaligned mechanism; loose hardware	Check for any items obstructing the drawer's movement. Verify that the drawer mechanism is correctly installed and all screws are tight.
Anti-tipping device feels insecure	Improper installation; wall material issue	Ensure the device is anchored into a wall stud or using appropriate wall anchors for your wall type. Re-read installation instructions carefully.

7. SPECIFICATIONS

Detailed specifications for the DAMCROP Fluted Shoe Cabinet (Model: XG04YM).

- **Brand:** DAMCROP
- **Model Name:** Shoe Storage Cabinet Oak
- **Item Model Number:** XG04YM
- **Color:** Natural Oak
- **Product Dimensions:** 9.44"D x 32"W x 40"H
- **Item Weight:** 58 Pounds
- **Material:** Engineered Wood (Frame, Back Material), Wood (Top Material)
- **Handle Material:** Metal
- **Number of Compartments:** 2 (flip drawers)
- **Special Feature:** 2 Flip Drawer Storage
- **Mounting Type:** Floor Mount
- **Installation Type:** Freestanding
- **Assembly Required:** Yes

8. WARRANTY AND SUPPORT

Warranty Information:

For specific warranty details, please refer to the warranty card included with your purchase or contact the retailer where the product was purchased. Warranty terms typically cover manufacturing defects and material flaws under normal use.

Customer Support:

If you have any questions, require assistance with assembly, or need to report a missing/damaged part, please contact DAMCROP customer service. Have your model number (XG04YM) and purchase information ready for faster service.

You can typically find contact information on the product packaging, the retailer's website, or the DAMCROP brand store on Amazon: [DAMCROP Store](#)