

COZPAW WJG-2406

COZPAW Toy Storage Organizer Instruction Manual

Model: WJG-2406 | Brand: COZPAW

INTRODUCTION

Thank you for choosing the COZPAW 2-Tier Montessori Shelf with Movable Bins. This organizer is designed to provide a functional and accessible storage solution for children's toys and books, promoting independence and organization. Please read this manual carefully before assembly and use to ensure proper installation and safe operation.

SAFETY INFORMATION

- **Anti-Tip Device:** Always install the included anti-tip device to secure the organizer to a wall. This prevents accidental tipping and ensures stability, especially in households with young children.
- **Stable Design:** The trapezoid design enhances stability. Ensure the unit is placed on a flat, level surface.
- **Rounded Corners:** This product features rounded corners to minimize the risk of injury from collisions.
- **Non-Toxic Materials:** The organizer is constructed from durable, non-toxic, and odorless MDF board, safe for children's environments.
- **Weight Capacity:** Do not exceed the recommended weight capacity for each shelf (approximately 40 lbs per shelf). Overloading can compromise stability and safety.
- **Adult Supervision:** While designed for child independence, adult supervision is recommended during initial use and play.

PACKAGE CONTENTS

Before beginning assembly, verify that all parts are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Wooden Panels (Side panels, back panels, shelves)
- Movable Bins (2 units)
- Caster Wheels (for movable bins)
- Hardware (Screws, dowels, anti-tip kit, etc.)
- Assembly Tools (Hex key, screwdriver - may not be included, prepare your own)

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is required for this product. It is recommended to assemble the unit on a soft, clean surface to prevent scratches. Two people may be required for easier assembly.

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out. Refer to the included hardware list to ensure all pieces are present.
2. **Assemble the Main Frame:** Attach the side panels to the main shelves using the provided screws and dowels. Ensure all connections are secure.
3. **Install Back Panels:** Secure the back panels to the main frame. This adds rigidity and stability to the unit.
4. **Assemble Movable Bins:** Construct the two movable bins. Attach the caster wheels to the bottom of each bin. Ensure wheels are securely fastened and can roll smoothly.
5. **Insert Bins:** Place the assembled movable bins into their designated slots at the bottom of the organizer.
6. **Attach Anti-Tip Device:** Locate a suitable wall stud and securely attach the anti-tip device to the back of the organizer and to the wall. This is a critical safety step.





Figure 1: Fully assembled COZPAW Toy Storage Organizer. This image shows the complete unit with two shelves and two movable bins.



Tips: Measure your space and double-check the item size before purchase.

Figure 2: The organizer filled with various children's books and toys, demonstrating its storage capacity.

OPERATING INSTRUCTIONS

The COZPAW Toy Storage Organizer is designed for easy access and organization, aligning with Montessori principles to encourage child independence.

- **Upper Shelf:** Use the upper shelf for displaying books with their covers facing forward, making them easily visible and accessible for children. It can also hold smaller toys or decorative items.
- **Movable Bins:** The two bottom bins are equipped with smooth-rolling caster wheels, allowing children to easily pull them out, access toys, and push them back in for cleanup. This feature promotes responsibility and makes tidying up an engaging activity.
- **Organization:** Encourage children to sort and organize their belongings into the different sections, fostering early organizational skills.



Figure 3: A child reaching for items on the lower shelf, demonstrating the accessible design.

MAINTENANCE

To ensure the longevity and appearance of your COZPAW Toy Storage Organizer, follow these simple maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the wood finish.
- **Spills:** Clean up spills immediately to prevent staining or warping of the wood.
- **Hardware Check:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Caster Wheels:** Keep the caster wheels free of debris to ensure smooth movement of the bins.

TROUBLESHOOTING

Issue: Difficulty during assembly (e.g., holes not aligning).

Solution: Double-check that you are using the correct panels and hardware for each step as indicated in the assembly instructions. Sometimes, loosening all screws slightly before tightening them fully can help align parts. If issues persist, contact customer support.

Issue: Movable bins do not roll smoothly.

Solution: Inspect the caster wheels for any trapped debris (e.g., hair, lint). Clean the wheels if necessary. Ensure the wheels are securely attached to the bins.

Issue: Unit feels unstable or wobbly.

Solution: Ensure the organizer is placed on a completely flat and level surface. Verify that all assembly screws are tightened. Confirm the anti-tip device is properly installed and secured to both the unit and the wall.

SPECIFICATIONS

Feature	Detail
Brand	COZPAW
Model Name	WJG-2406
Model Number	WJG-2406-2T02
Material	Wood (MDF Board)
Color	Wood
Overall Dimensions (D x W x H)	11.8" x 40.2" x 23.6" (30 cm x 102 cm x 60 cm)
Number of Shelves	2
Special Features	Adjustable, Durable, Movable Drawers, Space Saving, Stable, Rounded Corners, Anti-Tip Device
Mounting Type	Floor Mount (with wall anchor)
Assembly Required	Yes



Figure 4: Detailed dimensions of the COZPAW Toy Storage Organizer and its movable bins.

WARRANTY AND SUPPORT

For warranty information or technical support, please contact COZPAW customer service through the retailer where the product was purchased. Please have your model number (WJG-2406) and purchase date available when contacting support.

We are committed to providing high-quality products and support. Your satisfaction is important to us.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question