UNINELL HOME UV2

UNINELL HOME UV2 Cordless Vacuum Cleaner User Manual

Model: UV2

1. Introduction

Thank you for choosing the UNINELL HOME UV2 Cordless Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new vacuum cleaner. Please read it thoroughly before first use and keep it for future reference.

2. Important Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using an electrical appliance. These include:

- Read all instructions before using the appliance.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be

present.

- Do not pick up toxic material (chlorine bleach, ammonia, drain cleaner, etc.).
- Do not use without dust cup and/or filters in place.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.
- Do not use to pick up hard or sharp objects such as glass, nails, screws, coins, etc.

3. Package Contents

The UNINELL HOME UV2 Cordless Vacuum Cleaner package includes the following items:

- UV2 Cordless Vacuum Cleaner Main Unit (1)
- Telescopic Pole (1)
- Floor Brush Assembly (with Roller Brush) (1)
- Removable Rechargeable Battery (1)
- 1.6L Dust Cup (with Filter Assembly) (1)
- 2-in-1 Brush (1)
- Long Crevice Nozzle (1)
- Charging Wall Mount Plate (with screws) (1)
- Adaptor (1)
- Cleaning Brush (1)
- Washable HEPA Filters (2)
- User Manual (1)
- Quick Guide (1)



Figure 1: All included components of the UNINELL HOME UV2 Cordless Vacuum Cleaner.

This image displays all the components included in the UNINELL HOME UV2 Cordless Vacuum Cleaner package, including the main unit, various attachments, and charging accessories.

4. Assembly

Follow these steps to assemble your UNINELL HOME UV2 Cordless Vacuum Cleaner:

1. **Attach the Telescopic Pole:** Insert the telescopic pole into the main unit until it clicks securely into place.
2. **Attach the Floor Brush:** Connect the floor brush assembly to the other end of the telescopic pole, ensuring it locks firmly.
3. **Install the Battery:** Slide the removable rechargeable battery into the designated slot on the main unit until it clicks.
4. **Attach Accessories:** Depending on your cleaning needs, attach the 2-in-1 brush or long crevice nozzle directly to the main unit or the telescopic pole.

Your browser does not support the video tag.

Video 1: This video demonstrates the unboxing and assembly process of the UNINELL HOME UV2 Cordless Vacuum Cleaner, showing how to connect the main components and attach accessories.

5. Operating Instructions

The UNINELL HOME UV2 is designed for versatile cleaning with intuitive controls.

5.1 Power On/Off and Suction Modes

The vacuum features an intuitive LED screen and thumb-control design for easy operation.

- **Power On/Off:** Press the power button to turn the vacuum on or off.
- **Switch Modes:** Use the mode switch button to cycle through the three suction modes:
  - **Barefloor Mode:** Up to 65 minutes runtime, ideal for hard floors.
  - **Carpet Mode:** Up to 40 minutes runtime, suitable for carpets.
  - **Turbo Mode:** Up to 20 minutes runtime, for maximum suction on stubborn dirt.
- **LED Display:** The LED screen clearly shows the battery level and provides immediate malfunction alerts for brushroll blockages and airduct clogs.



Figure 2: The LED display provides real-time information on battery level and selected suction mode.

This image illustrates the smart LED display, highlighting the battery status, and the three available suction modes: Barefloor, Carpet, and Turbo.

5.2 Green Searchlight and Maneuverability

- **Green Searchlight:** A built-in green searchlight on the brush head illuminates hidden dust and pet hair under furniture, ensuring thorough cleaning.
- **Flexible Brush Head:** The brush head lies flat at 180° and swivels 270°, allowing it to glide deep under beds and sofas and navigate effortlessly around furniture.
- **Self-Standing Design:** The vacuum features a self-standing design, simplifying storage and allowing you to pause cleaning instantly without leaning it against surfaces.



Figure 3: The green searchlight on the brush head reveals dust and debris on the floor, making it easier to clean.

This image shows the green LED lights on the vacuum's brush head, effectively highlighting dust and debris on a hard floor surface for improved visibility during cleaning.



Figure 4: The vacuum cleaner stands upright independently, showcasing its self-standing design for convenient storage and temporary pauses during cleaning.

This image demonstrates the self-standing capability of the UNINELL HOME UV2 Cordless Vacuum Cleaner, allowing it to remain upright without support, which is convenient for storage and breaks during cleaning.

Your browser does not support the video tag.

Video 2: This video highlights the lightweight design and versatile cleaning capabilities of the UNINELL HOME UV2, demonstrating its use in various scenarios and its ability to reach difficult areas.

6. Charging

The UV2 cordless vacuum offers three versatile charging methods:

- **Removable Battery Charging:** The battery can be removed from the main unit and charged independently using the provided adaptor.
- **Wall-Mounted Dock Charging:** Use the 2-in-1 wall-mounted dock for both storage and charging of the entire unit.

- **Direct Unit Charging:** The entire vacuum unit can be charged directly by plugging the adaptor into the main unit.

A full charge takes approximately 4-5 hours and provides up to 65 minutes of continuous runtime in barefloor mode.



Figure 5: The vacuum cleaner is shown charging while mounted on its wall dock, which also provides convenient storage.

This image displays the UNINELL HOME UV2 Cordless Vacuum Cleaner being charged via its wall-mounted dock, illustrating one of the convenient charging and storage options.



Figure 6: The removable battery is shown detached from the main unit, highlighting its portability and independent charging capability.

This image shows the removable battery of the UNINELL HOME UV2 Cordless Vacuum Cleaner, emphasizing its design for flexible charging options.

7. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

7.1 Emptying the Dust Cup

The oversized 1.6L dust cup features a hassle-free, one-touch dust ejection system for hygienic emptying directly into your trash bin.




Figure 7: A hand demonstrates the one-touch dust ejection mechanism of the vacuum cleaner's dust cup.

This image illustrates the simple, one-touch method for emptying the dust cup, ensuring a hands-free and hygienic disposal of collected debris.

7.2 Cleaning Filters and Cyclone Core

The dust cup and cyclone core are fully washable. The HEPA filtration system captures 99.9% of fine dust and allergens. Ensure all washable components are completely dry before reassembling.



Figure 8: A detailed diagram showing the 6-stage cyclone filtration system, including the HEPA filter, for effective air purification.

This image provides a visual breakdown of the vacuum's 6-stage filtration system, highlighting how it captures fine dust and allergens to release purified air.

7.3 Tangle-Resistant Roller Brush

The innovative V-shaped tangle-resistant roller brush actively prevents pet hair from clinging. If hair or debris does accumulate, use the provided cleaning brush with a small blade to easily remove tangled hair from the roller.

Your browser does not support the video tag.

Video 3: This video demonstrates the maintenance procedures, including how to clean the dustbin, filters, and the brush roll to ensure optimal performance.

8. Troubleshooting

If you encounter issues with your UNINELL HOME UV2, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Vacuum not turning on	Battery is depleted or not properly installed.	Charge the battery fully. Ensure the battery is securely clicked into place.
Low suction power	Dust cup is full, filters are clogged, or brush roll is tangled.	Empty the dust cup. Clean or wash the filters and ensure they are dry. Remove any tangled hair or debris from the brush roll. Check LED display for airduct clog alerts.
Brush roll not spinning	Brush roll is jammed or tangled.	Turn off the vacuum and remove any obstructions from the brush roll. Use the provided cleaning tool to remove tangled hair. Check LED display for brushroll blockage alerts.
Short runtime	Battery not fully charged or battery degradation.	Ensure the battery is fully charged (4-5 hours). If runtime remains significantly short, contact customer support.

9. Specifications

Feature	Detail
Brand	UNINELL HOME
Model Name	UV2
Suction Power	48,000Pa (Turbo mode)
Motor	550W Brushless Motor
Runtime	Up to 65 minutes (Barefloor mode)
Battery	6x 2200mAh Removable Lithium-ion
Charging Time	4-5 Hours
Dust Cup Capacity	1.6 Liters
Filtration System	6-stage Cyclone with HEPA Filter
Noise Level	45 Decibels
Weight	2.1 lbs (main unit) / 3 pounds (item weight)
Product Dimensions	9.05"L x 8.58"W x 41.73"H
Special Features	Green Searchlight, V-shaped Tangle-Resistant Roller Brush, Self-Standing Design, LED Display, 3-Way Charging
Recommended Uses	Hardwood Floor, Low-Mid-Pile Carpet, Tile Floor, Marble Floor, Bed, Sofa, Stair, Car

10. Warranty and Support

UNINELL HOME cordless vacuum cleaners come with a 2-year warranty and lifetime technical support. For any inquiries or assistance, please contact our 24/7 customer support team.
For more information or to register your product, please visit the official UNINELL HOME Store:UNINELL HOME Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I know when I should replace the HEPA filter instead of cleaning it for the UNINELL HOME UV2? How do I remove the HEPA filter to install a new one? How do I clean the HEPA filter? Is the dust bin the only part that is washable? The instructions mentioned a core part so where is that?

For the UNINELL HOME UV2 Cordless Vacuum Cleaner, the manual provides the following information regarding filter maintenance:When to replace the HEPA filter: The manual does not specify a replacement schedule for the HEPA filter....

Read full answer

How can I order replacement HEPA filters for my Uninell UV2 Cordless Vacuum Cleaner?

To order replacement HEPA filters for your UNINELL HOME UV2, you should contact the manufacturer's customer support or visit their official storefront. While the manual does not list a specific part number for the...

Read full answer