

[Manuals.plus](#) /

› [Jocoevol](#) /

› Jocoevol Natural Rattan 5-Drawer Dresser Instruction Manual

Jocoevol Natural Rattan Dresser

Jocoevol Natural Rattan 5-Drawer Dresser Instruction Manual

Model: Natural Rattan Dresser (B0G723B92X)

1. PRODUCT OVERVIEW

The Jocoevol Natural Rattan 5-Drawer Dresser is designed to provide versatile storage with a bohemian aesthetic. It features handwoven natural rattan drawer fronts and a sturdy wood construction, suitable for various rooms in your home.

- **Natural Rattan Design:** Handwoven rattan fronts offer a unique boho style and natural texture.
- **Spacious Storage:** Five large drawers provide ample space for clothing, linens, or other essentials.
- **Versatile Placement:** Can be used as a dresser, console table, entryway organizer, or accent cabinet in bedrooms, living rooms, closets, or hallways.
- **Durable Construction:** Crafted from waterproof-coated MDF with a scratch-resistant finish, designed for long-lasting use.
- **Safety Features:** Includes anti-tip hardware for secure wall-mounting and full-extension metal glides for smooth drawer operation.



Image: The Jocoevol Natural Rattan 5-Drawer Dresser, showcasing its design and size in a bedroom environment.

2. SAFETY INFORMATION

Please read and adhere to all safety warnings to prevent injury or damage to the product.

- **Weight Limits:** Do not exceed 30 lbs per drawer. The top surface has a maximum weight limit of 100 lbs.
- **No Climbing or Sitting:** Children and pets are prohibited from climbing on or sitting in the unit or drawers.
- **Heat Sources:** Maintain a minimum of 12 inches clearance from heaters or other heat sources.
- **Rattan Care:** Avoid using sharp objects near the rattan weave to prevent damage.
- **Drawer Safety:** Always close drawers when not in use to prevent accidental tipping.
- **Placement:** Ensure the dresser is placed on a level floor surface. Avoid direct sunlight exposure to preserve the wood and rattan.
- **Anti-Tip Hardware:** Always install the provided anti-tip hardware to securely wall-mount the dresser, especially in households with children or pets.



Image: Illustration of the dual anti-tip kit, essential for securing the dresser to a wall.

3. ASSEMBLY INSTRUCTIONS

This dresser requires assembly. All necessary parts, tools, and illustrated instructions are included. Assembly typically takes approximately 40 minutes with two people. For a visual guide, please refer to the assembly video below.

Your browser does not support the video tag.

Video: Detailed assembly guide for the Jocoevol Natural Rattan 5-Drawer Dresser. This video provides step-by-step visual instructions for putting together your new dresser.

General Assembly Steps:

1. **Unpack and Identify Parts:** Carefully unpack all components and hardware. Refer to the included parts list to ensure all items are present.
2. **Assemble the Base:** Attach the side support beams to the bottom panel using the provided fasteners.
3. **Construct the Frame:** Connect the side panels and back panel to the base and top panel, ensuring all connections are secure.
4. **Install Drawer Glides:** Secure the drawer glides to the interior side panels of the dresser frame.
5. **Assemble Drawers:** Each of the five drawers will be assembled individually. This involves attaching the front, back, and side panels, then inserting the bottom panel.
6. **Attach Drawer Fronts:** Secure the rattan drawer fronts to the assembled drawer boxes.
7. **Install Drawer Knobs:** Fasten the gold metal knobs to each drawer front.
8. **Insert Drawers:** Carefully slide the assembled drawers onto the installed glides within the dresser frame.
9. **Install Anti-Tip Kit:** Securely attach the anti-tip hardware to the top rear of the dresser and to a wall stud, following the detailed instructions provided.

Note: For specific part numbers and detailed diagrams, please consult the printed instruction manual included in your package.



Image: Diagram illustrating the overall product dimensions and individual drawer capacities.

4. USAGE

The Jocoevol Natural Rattan 5-Drawer Dresser is designed for versatile use and efficient storage.

- **Drawer Functionality:** Utilize the five large drawers for organizing clothes, accessories, linens, or other personal items. The full-extension metal glides ensure smooth and quiet operation.
- **Top Surface:** The extra-wide wooden top can serve as a display area for decorative items, plants, lamps, or a mirror. Ensure the weight limit of 100 lbs is not exceeded.
- **Side Hooks:** The integrated side hooks are convenient for hanging umbrellas, bags, or other frequently used items, keeping them easily accessible.
- **Room Placement:** Its adaptable design allows it to seamlessly integrate into various rooms, including bedrooms, living rooms, entryways, or closets, maximizing storage in smaller spaces.



Image: The dresser with drawers partially open, demonstrating its ample storage capacity for various items.

5. MAINTENANCE

Proper care will ensure the longevity and appearance of your Jocoevol dresser.

- **General Cleaning:** Effortlessly clean the surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Stain Removal:** Blot spills immediately with a clean, dry cloth. For stubborn stains, dip a cotton swab in a mild soap solution, dab gently on the stain, then wipe with a dry cloth.
- **Rattan Care:** Periodically dust the rattan with a soft brush or cloth. Avoid excessive moisture on the rattan.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary to maintain stability.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or damage to the wood and rattan. Position the dresser away from direct sunlight or use window coverings.

6. SPECIFICATIONS

Feature	Detail
Brand	Jocoevol
Model Name	Natural Rattan Dresser
ASIN	B0G723B92X
Material	Engineered Wood
Finish Type	Polished
Product Dimensions (D x W x H)	15.7"D x 31.5"W x 40.6"H
Number of Drawers	5
Item Weight	82.3 Pounds
Color	Natural Oak
Style Name	Bohemian
Required Assembly	Yes
Included Components	Dresser, Installation tools, User Manual

7. TROUBLESHOOTING

If you encounter any issues with your Jocoevol Natural Rattan 5-Drawer Dresser, please refer to the following common solutions:

- **Wobbly or Unstable:** Ensure all fasteners are securely tightened. Verify the dresser is placed on a level surface. If necessary, adjust furniture levelers (if included) or use shims.
- **Drawers Not Sliding Smoothly:** Check that the drawer glides are correctly installed and aligned. Ensure no objects are obstructing the glides. Lubricate glides with a silicone-based lubricant if needed.
- **Missing Parts:** If any parts are missing upon unboxing, please contact customer support immediately with your product model and a list of missing components.
- **Damaged Parts:** If any parts are damaged during shipping or assembly, do not proceed with assembly. Contact customer support for replacement parts.

For further assistance, please contact Jocoevol customer support.

8. WARRANTY AND SUPPORT

The Jocoevol Natural Rattan 5-Drawer Dresser comes with a **1-year manufacturer's warranty**. For warranty claims, technical support, or any other inquiries, please refer to the contact information provided in your product packaging or visit the official Jocoevol website. We are committed to providing high-quality products and excellent customer service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question