

HOOBRO BK19MB01

HOOBRO BK19MB01 2-Tier Corner Bamboo Bread Box

Instruction Manual

- Introduction
- Safety
- Contents
- Setup
- Operation
- Maintenance
- Troubleshooting
- Specifications
- Warranty

1. INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your HOOBRO BK19MB01 2-Tier Corner Bamboo Bread Box. This product is designed to offer a practical and stylish storage solution for your kitchen countertop, helping to keep baked goods fresh and your space organized.

The bread box is constructed from natural bamboo, ensuring durability and a refined aesthetic. Its corner-adaptable design maximizes space efficiency, fitting snugly into kitchen corners. It features a two-tier storage capacity and a flat top surface with raised edges to prevent items from slipping.



Image 1.1: The HOOBRO 2-Tier Corner Bamboo Bread Box in a kitchen corner, showcasing its design and storage capacity.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembling and using this product. Retain this manual for future reference.

- Ensure all components are securely fastened during assembly to prevent instability.
- Do not overload the bread box. Adhere to the specified capacity to maintain structural integrity.
- Keep the product away from open flames, excessive heat, and direct sunlight to prevent damage to the bamboo material.
- Avoid using abrasive cleaners or harsh chemicals, as these can damage the bamboo finish.
- This product is intended for indoor use only.

3. PACKAGE CONTENTS

Verify that all parts are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Top Panel
- Bottom Panel
- Side Panels (x2)
- Back Panels (x2)
- Middle Shelf
- Front Doors (x2)
- Door Handles (x2)
- Hinges and Screws
- Assembly Hardware (dowels, cam locks, etc.)
- Instruction Manual

4. SETUP AND ASSEMBLY

The HOOBRO BK19MB01 bread box requires assembly. Detailed instructions and necessary tools are included in the package. Please follow the step-by-step guide provided with your product for proper assembly.

4.1. Before You Begin

- Clear a spacious, clean, and flat work area.
- Unpack all components and verify against the package contents list.
- Gather any additional tools that may be required (e.g., screwdriver, hammer).

4.2. Assembly Steps (General Guide)

1. Attach the side panels to the bottom panel using the provided hardware.
2. Insert the middle shelf into the designated slots or attach with hardware.
3. Secure the back panels to the frame.
4. Attach the top panel to complete the main structure.
5. Install the hinges onto the front doors and then attach the doors to the main frame.
6. Affix the door handles.
7. Ensure all connections are tight and the structure is stable.



Image 4.1: Dimensional diagram of the bread box, useful for planning placement and assembly.

Right-Angle Design

Fits snugly to corners, maximizing small spaces.



Image 4.2: Detail of the right-angle design, illustrating how it fits snugly into corners.

5. OPERATING INSTRUCTIONS

The HOOBRO BK19MB01 bread box is designed for convenient storage of various food items.

5.1. Storing Items

- Open the desired tier's front door by gently pulling the handle.
- Place bread, pastries, snacks, or other dry food items inside. The two-tier design allows for organized storage.
- Close the door securely to maintain freshness and protect contents.
- The transparent doors allow for easy visibility of stored items without needing to open the box.

5.2. Utilizing the Top Surface

The flat top surface with raised edges provides additional stable space for placing kitchen items such as spice jars,

cups, or small decorative elements, preventing them from slipping off.



Image 5.1: The bread box on a dining table, demonstrating its use for storing various baked goods.



Image 5.2: Two bread boxes in a kitchen, highlighting their ability to fit into different kitchen layouts.

Your browser does not support the video tag.

Video 5.3: An official HOOBRO video demonstrating the features and usage of the BK19MB01 bread box, including its two-tier design and corner placement.

6. MAINTENANCE AND CARE

Proper care will ensure the longevity and appearance of your HOOBRO bread box.

6.1. Cleaning

- **Hand Wash Only:** Clean the bread box by hand. Do not place it in a dishwasher.
- Wipe surfaces with a soft, damp cloth. For stubborn stains, use a mild soap solution.
- Dry thoroughly immediately after cleaning to prevent moisture damage to the bamboo.
- Avoid using abrasive sponges, scouring pads, or harsh chemical cleaners.

6.2. General Care

- Periodically check all screws and connections to ensure they remain tight.
- Keep the bread box in a dry environment to prevent warping or mold growth on the bamboo.
- The bamboo material is naturally resistant to water and oil, making it easy to clean and maintain.



Image 6.1: Visual representation of key features including natural bamboo material, ease of cleaning, water and oil resistance, and simple assembly.

7. TROUBLESHOOTING

If you encounter any issues with your bread box, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Doors do not close smoothly or are misaligned.	Hinges are loose or incorrectly installed.	Check hinge alignment and tighten screws. Ensure the bread box is on a level surface.
Bread box feels wobbly or unstable.	Loose assembly hardware or uneven surface.	Verify all assembly screws are tightened. Place the bread box on a flat, stable surface.
Scratches or marks on the bamboo surface.	Contact with sharp objects or abrasive cleaning.	Use a soft cloth for cleaning. Minor scratches may be buffed out with fine-grit sandpaper and a suitable wood oil, if desired.

8. SPECIFICATIONS

Feature	Detail
Brand	HOOBRO
Model	BK19MB01
Material	Bamboo
Color	Black
Dimensions (L x W x H)	15.6"L x 15.6"W x 17.3"H (32cm x 32cm x 44cm)
Item Weight	3.6 kg
Capacity	5 kg
Container Shape	Corner
Closure Type	Snap (doors)
Product Care Instructions	Hand Wash Only

9. WARRANTY AND SUPPORT

HOOBRO products are manufactured with quality and customer satisfaction in mind. For specific warranty details, please refer to the documentation included with your purchase or visit the official HOOBRO website.

If you have any questions, require assistance with assembly, or need to report a missing/damaged part, please contact HOOBRO customer support. Have your model number (BK19MB01) and purchase information ready when contacting support.

HOOBRO US Customer Service: [Visit the HOOBRO Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question