

Apetexo TC-021 B002

Apetexo Nose and Ear Trimmer User Manual

Model: TC-021 B002 | Brand: Apetexo

INTRODUCTION

Thank you for choosing the Apetexo Nose and Ear Trimmer. This professional USB-C rechargeable grooming tool is designed for simple, portable, and comfortable use, providing a painless trimming experience. Equipped with double-edged stainless steel blades and an 8500 RPM motor, it ensures a clean and precise cut without pulling. Its IPX7 waterproof design allows for easy cleaning, and the USB-C fast charging provides up to 150 minutes of cordless operation. This versatile device is suitable for nose, ear, eyebrow, and sideburn hair, helping you maintain a neat appearance anytime, anywhere.

SAFETY INFORMATION

- **Electrical Hazard:** Avoid immersing the trimmer in water to prevent electrical hazards. While the head is waterproof for rinsing, the main body should not be submerged.
- **Children:** Keep the device out of reach of children.
- **Damage:** Do not use the trimmer if it is damaged or malfunctioning.
- **Cleaning:** Ensure the device is turned off before cleaning.
- **Charging:** Use only the provided USB-C cable for charging. Do not attempt to charge with a damaged cable or in wet conditions.
- **Internal Components:** Do not attempt to disassemble or repair the trimmer yourself. Contact customer support if service is required.

PACKAGE CONTENTS

Please check the package for the following items:

- Apetexo Nose and Ear Trimmer Unit
- USB-C Charging Cable
- Cleaning Brush
- User Manual



The Apetexo nose hair trimmer and its packaging, showing the product and its features on the box.

PRODUCT OVERVIEW

The Apetexo Nose and Ear Trimmer is engineered for efficient and comfortable grooming. Key features include:

- **High-Speed Motor:** 8500 RPM for precise, painless trimming.
- **Double-Edged Blades:** Stainless steel blades for clean cuts without pulling.
- **USB-C Fast Charging:** Fully charges in 2 hours for up to 150 minutes of cordless use.
- **IPX7 Waterproof:** Allows for safe use in the shower and easy rinsing of the blade head.
- **Ultra-Quiet Operation:** Operates at less than 60dB for discreet use.
- **Multi-Purpose:** Suitable for nose, ear, eyebrow, and sideburn hair.

- **Compact & Portable:** Lightweight design ideal for travel and on-the-go grooming.

Powerful Motor



**Double-edged
stainless steel
blade**



**360° rotating
metal drive shaft**

8500 RPM

A detailed cutaway illustration of the trimmer's internal motor and blade. The motor is shown with glowing orange and yellow internal components, indicating high speed. The blade is a double-edged stainless steel blade, and the drive shaft is a 360° rotating metal drive shaft. The background is a light gray with a subtle circular pattern.

Illustration of the Apetexo trimmer's internal motor and double-edged stainless steel blade, highlighting its 8500 RPM speed.



<60dB

Ultra-Quiet



The Apetexo trimmer operates quietly, making it suitable for discreet use.



Compact and Portable

Can be carried and used for travel, business trips and parties

The compact design allows for easy portability in a travel pouch.

SETUP

1. Charging the Trimmer

1. Locate the USB-C charging port at the bottom of the trimmer.
2. Connect the provided USB-C cable to the trimmer and the other end to a compatible USB power source (e.g., computer, wall adapter).
3. The display will indicate charging status. A full charge takes approximately 2 hours.
4. Once fully charged, the trimmer provides up to 150 minutes of cordless operation.



The trimmer features USB-C fast charging for convenience.

2. Initial Use

- Before first use, ensure the trimmer is fully charged.
- Press the power button to turn the trimmer ON. Press again to turn OFF.

OPERATING INSTRUCTIONS

For optimal results and to prevent discomfort, follow these guidelines:

General Trimming Tips:

- Ensure your skin is clean and dry before trimming.

- Hold the trimmer firmly and gently guide it over the desired area.
- Avoid pressing the trimmer too hard against your skin.
- Trim against the direction of hair growth for a closer cut.

Specific Applications:

1. **Nose Hair:** Gently insert the trimmer tip into your nostril, no more than 5mm. Move the trimmer in a circular motion to trim visible hairs. Breathe normally.
2. **Ear Hair:** Carefully guide the trimmer around the outer ear and into the ear canal opening to remove visible hairs. Do not insert too deeply.
3. **Eyebrows:** Use the trimmer to carefully shape and trim stray eyebrow hairs. For precision, you may use your free hand to hold the skin taut.
4. **Sideburns:** Hold the trimmer flat against your skin and move it downwards to neaten sideburns.

One Machine for Multiple Uses

Three interchangeable heads for easy
facial hair trimming



The Apetexo trimmer is versatile for nose, ear, eyebrow, and sideburn grooming.

MAINTENANCE

Cleaning the Trimmer:

1. Turn off the trimmer before cleaning.
2. Twist the trimmer head counter-clockwise to detach it from the main body.
3. Rinse the detached trimmer head under running water to remove hair clippings. You can use the provided cleaning brush for stubborn hairs.
4. Shake off excess water and allow the head to air dry completely before reattaching.
5. Wipe the main body of the trimmer with a clean, dry cloth. Do not rinse the main body under water.

6. Align the trimmer head with the main body and twist clockwise to secure it back in place.



The trimmer head is detachable and washable for easy cleaning.

Storage:

- Store the trimmer in a cool, dry place away from direct sunlight and moisture.
- Ensure the trimmer is clean and dry before storing.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Trimmer does not turn on.	Battery is depleted.	Charge the trimmer using the provided USB-C cable.
Trimmer pulls hair or is ineffective.	Blades are clogged with hair. Battery is low.	Clean the trimmer head thoroughly. Fully charge the trimmer.
Trimmer makes unusual noise.	Hair caught in the mechanism. Head not properly attached.	Clean the trimmer head. Reattach the trimmer head securely.

SPECIFICATIONS

Feature	Detail
Model Number	TC-021 B002
Brand	Apetexo
Power Source	Battery Powered (USB-C Rechargeable)
Motor Speed	8500 RPM
Charging Time	Approx. 2 hours
Operating Time	Up to 150 minutes (cordless)
Waterproof Rating	IPX7 (Trimmer head washable)
Blade Material	Stainless Steel
Noise Level	< 60 dB
Color	Matte Black
Product Dimensions	16.4 x 9 x 3.9 cm (approx. from package dimensions)
Product Weight	160 grams (approx. from package dimensions)

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact the retailer/manufacturer directly. Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question