Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GAOMON PTG_338K

GAOMON 24V 2-Seater Ride-On Truck Instruction Manual

Model: PTG_338K | Brand: GAOMON

Introduction

Thank you for purchasing the GAOMON 24V 2-Seater Ride-On Truck. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new electric vehicle. Please read all instructions carefully before assembly and use. Keep this manual for future reference.

Important Safety Information:

- Adult assembly required.
- Always supervise children during operation.
- Ensure all connections are secure before use.
- Do not operate near stairs, hills, roads, or swimming pools.
- Wear appropriate safety gear, including a helmet.

Setup and Assembly

Follow these steps to assemble your GAOMON 24V 2-Seater Ride-On Truck. A detailed video guide is provided below for visual assistance.

Your browser does not support the video tag.

Official installation video for the 24V Kids Ride-On Car (BBH-032), demonstrating the assembly process from unboxing to final setup.

Step-by-Step Assembly Guide:

1. **Unboxing and Initial Inspection:** Carefully open the packaging. Remove all components and protective materials. Verify all parts are present according to the packing list.
2. **Prepare the Vehicle Body:** Remove the main vehicle body from the box. Place it upside down on a soft, clean surface to prevent scratches. Carefully remove any plastic wrapping and zip ties securing internal components.

3. **Assemble Front Bumper:** Attach the U-shaped bar to the main front bumper piece using the provided screws. Then, attach the upper bar to complete the front bumper assembly. Ensure all screws are tightened securely.



Image: Components of the front bumper assembly being secured.

4. **Attach Front Bumper to Vehicle:** Align the assembled front bumper with the front of the vehicle body. Secure it in place using the designated screws.
5. **Assemble Rear Bumper:** Similar to the front, assemble the rear bumper components and attach it to the rear of the vehicle body using the provided screws.
6. **Install Rear Axle and Motors:** Insert the rear axle into its designated slots. Attach the motor housings to the vehicle body, ensuring they are correctly aligned with the axle. Connect the motor wires to the corresponding terminals.
7. **Attach Wheels:** For each wheel, slide it onto the axle, followed by a washer and then secure it with a nut. Use the provided tool to tighten the nuts. Finally, snap on the wheel caps.



Image: A wheel being attached to the vehicle's axle, showing the washer and nut.

8. **Connect Battery:** Locate the battery compartment, typically under the seat or hood. Connect the main battery terminals (red to red, black to black) ensuring a secure connection.
9. **Install Steering Wheel:** Connect the steering wheel's electrical connector to the corresponding port on the dashboard. Slide the steering wheel onto the steering column until it clicks into place.
10. **Attach Side Mirrors:** Securely attach the side mirrors to the designated slots on the vehicle's body.
11. **Install Rear Storage/Tailgate:** Place the rear storage compartment or tailgate into position and secure it with screws.
12. **Install Seats:** Place the seats into the vehicle's interior. Secure them with the provided screws.
13. **Assemble and Attach Overhead Light Bar:** Install batteries into the light bar (if required, typically 2x AAA). Assemble the light bar components and attach it to the roll bar or designated mounting points on the vehicle.
14. **Remote Control Setup:** Open the remote control battery compartment and insert 2x AAA batteries. Close the compartment. To pair the remote, turn on the vehicle, then press and hold the pairing button on the remote until the indicator light stops flashing.

Operating Instructions

Starting the Vehicle:

- Ensure the battery is fully charged and connected.
- Press the power button on the dashboard.

- The vehicle features 3 speeds, selectable via a switch on the dashboard or remote control.

Driving the Vehicle:

- **Manual Mode:** The child can operate the vehicle using the foot pedal for acceleration and the steering wheel for direction.
- **Remote Control Mode:** An adult can override manual controls using the 2.4G parent remote control. This is recommended for younger children or for safety intervention.
- Use the forward/reverse switch to select direction.
- The vehicle is equipped with LED lights and Bluetooth connectivity for entertainment.

Charging the Battery:

- Locate the charging port on the dashboard.
- Plug the charger into the charging port, then into a standard wall outlet.
- Charge for 8-12 hours before first use, and 8-12 hours for subsequent charges. Do not overcharge.
- Disconnect the charger once charging is complete.

Maintenance

Regular maintenance ensures the longevity and safe operation of your ride-on truck.

- **Cleaning:** Wipe the vehicle with a soft, damp cloth. Do not use abrasive cleaners or solvents. Avoid spraying water directly onto electrical components.
- **Battery Care:** Store the battery in a cool, dry place. Recharge the battery at least once a month during periods of non-use to prolong its lifespan.
- **Tire Inspection:** Regularly check tires for wear and tear. Ensure they are free from debris that could affect performance.
- **Electrical Connections:** Periodically check all electrical connections to ensure they are secure and free from corrosion.
- **Storage:** When not in use, store the vehicle indoors in a dry area. Protect it from direct sunlight and extreme temperatures.

Troubleshooting

If you encounter issues with your ride-on truck, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vehicle does not move	Battery not charged/connected; loose wiring; blown fuse.	Charge battery; check battery connections; inspect all wiring; replace fuse if necessary.
Vehicle runs slowly	Low battery; overloaded vehicle; operating on rough terrain.	Recharge battery; reduce load; operate on smooth surfaces.
Remote control not working	Remote batteries dead; remote not paired.	Replace remote batteries; re-pair remote control (refer to Operating Instructions).
Lights/Sound not working	Loose wiring; specific component issue.	Check wiring connections to lights/speakers.

Specifications

- **Product Dimensions:** 49.21 x 31.1 x 29.92 inches
- **Item Weight:** 67.2 pounds
- **Manufacturer Recommended Age:** 3 years and up
- **Batteries:** 2 x 12V batteries (included)
- **Manufacturer:** GAOMON

Warranty and Support

For support and warranty information, please refer to the documentation included with your product or contact the seller directly. The manufacturer is GAOMON. This product typically includes a 30-day easy return policy and customer support from the seller, Gaomon Direct.
For further assistance, you may contact the seller, WozhiWo, or refer to the support information provided by Garvee, as indicated on the product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G7K4XNC8

More documents and user manuals: **https://manuals.plus/**