

## SUNLY B0G83WDX7K

# SUNLY Touchless Automatic Soap Dispenser User Manual

Model: B0G83WDX7K

## INTRODUCTION

---

Thank you for choosing the SUNLY Touchless Automatic Soap Dispenser. This manual provides essential information for the safe and efficient operation of your new device. Designed for convenience and hygiene, this dispenser features an upgraded gear pump for clog-free dispensing, a fast infrared sensor, USB-C recharging, and a smudge-resistant stainless steel finish. It is suitable for various liquid soaps and sanitizers in both kitchen and bathroom environments.



The SUNLY Touchless Automatic Soap Dispenser in white stainless steel, shown dispensing soap into a hand, highlighting its touchless operation.

## SETUP

---

1. **Charge the Device:** Before first use, fully charge the dispenser using the provided USB-C cable. The charging port is sealed for waterproofing.
2. **Open the Lid:** Gently press the top lid to open the soap reservoir.
3. **Fill with Soap:** Pour your preferred liquid soap or sanitizer into the reservoir. Avoid foaming soaps unless diluted properly.
4. **Close the Lid:** Securely close the top lid.
5. **Power On:** Press and hold the power button for 3 seconds to turn on the dispenser.

## Easy Setup



Press the lid to open.



Fill in cleaning solution.



Hold the power button for 3 seconds to start.

Visual guide for the easy setup process: opening the lid, filling with soap, and powering on the device.

## OPERATING

### Dispensing Soap

Place your hand under the nozzle. The fast infrared sensor will detect your hand and dispense soap automatically within 0.2 seconds. The dispenser features a patented duckbill nozzle designed to prevent drips and clogs.

### 0.2 second rapid response

Infrared precise detection, zero contact to eliminate bacteria, more reassuring.




A hand positioned under the dispenser, demonstrating the rapid 0.2-second touchless dispensing action.


### Adjusting Dispensing Modes

The dispenser offers three adjustable dispensing modes to suit your needs. Tap the power button once to cycle through the modes:

- **Soft Mode (0.2ml):** Ideal for children or gentle skincare routines. (Blue light flashes once)
- **Daily Mode (0.4ml):** Suitable for regular hand washing throughout the day. (Blue light flashes twice)
- **Max Mode (0.7ml):** Best for scrubbing greasy dishes or stubborn kitchen messes. (Blue light flashes three times)




## 3 Modes. One Easy Touch.




**Soft Mode** 💧 0.2s

01 Ideal for young kids or gentle skincare routines.  
Blue light flashes once when selected.



**Daily Mode** 💧 0.4s

02 Great for regular hand washing throughout the day.  
Blue light flashes twice when selected.



**Max Mode** 💧 0.7s

03 Best for greasy dishes or stubborn kitchen messes.  
Blue light flashes three times when selected.

An illustration detailing the three dispensing modes and their recommended applications.


## MAINTENANCE


### Refilling Soap

The dispenser holds 9.1oz (270ml) of liquid soap, typically lasting 3 to 6 weeks. To refill, simply press the pop-up lid to open and pour in your soap. No tools or disassembly are required.

### Easy Pop-Up Refill Lid

Top lid pops open for fast refills.  
Fits most gel soaps and sanitizers.





The dispenser's pop-up lid is shown open, illustrating the simple and quick refilling process.

### Self-Cleaning Mode

To prevent clogs and maintain hygiene, double-tap the power button to activate the auto-clean mode. This is especially useful after long breaks or when changing soap formulas. The dispenser will automatically switch back to standby after 20 seconds.

## Auto-Clean Activated

Double-tap Power to refresh your device. We'll switch back to Standby in 20s, no action needed.

\*Clog or new formula: add warm water, run clean cycle.



A visual representation of the internal self-cleaning process, ensuring the dispenser remains clog-free.

## Waterproof Design & Cleaning

The dispenser is IPX5-rated, making it resistant to splashes and safe for use near sinks, baths, and in kitchens. The sealed silicone charging port further protects it from water. The 304 stainless steel finish is smudge- and scratch-resistant, keeping it sleek and rust-free. For cleaning, simply wipe the exterior with a damp cloth.

## IPX5 Waterproof Build

Rinse freely-rubber-sealed charging port keeps water out.



The dispenser being rinsed under water, demonstrating its IPX5 waterproof rating and sealed charging port.

## TROUBLESHOOTING

- **What kind of soap does this dispenser support?** It works best with standard gel hand soap, dish soap, or liquid sanitizers. Foaming soap is not recommended unless diluted properly.
- **What if the dispenser stops working?** Charge it. If the soap is thick, thin it. Wipe the sensor. Add warm water and double-press the button to self-clean.
- **How often do I need to refill the soap?** The dispenser holds 9.1 fl oz (270ml) of liquid soap, which typically lasts 3 to 6 weeks in an average household, depending on usage mode and frequency.
- **What if it stops working after a few months?** Your dispenser is backed by a 2-year warranty. If you experience any issues, our support team is available for quick replacements or troubleshooting.

## SPECIFICATIONS

Brand	SUNLY
-------	-------

<b>Model Number</b>	B0G83WDX7K
<b>Color</b>	White
<b>Material</b>	Stainless Steel
<b>Product Dimensions (L x W x H)</b>	3.5"L x 3.5"W x 8.5"H
<b>Material Type Free</b>	BPA Free, Lead Free
<b>Liquid Volume Capacity</b>	270ml (9.1 fl oz)
<b>Battery</b>	1500mAh Rechargeable (USB-C)
<b>Waterproof Rating</b>	IPX5

## WARRANTY & SUPPORT

---

The SUNLY Touchless Automatic Soap Dispenser comes with a **2-year warranty**. For any product inquiries, technical assistance, or warranty claims, please contact SUNLY customer support. Our dedicated team is ready to provide quick replacements or troubleshooting guidance to ensure your satisfaction.