

[Manuals.plus](#) /

› [Nimble](#) /

› Nimble Podium 2-in-1 Wireless Charging Station User Manual

Nimble B0G853T54N

Nimble Podium 2-in-1 Wireless Charging Station User Manual

Model: B0G853T54N

INTRODUCTION

Thank you for choosing the Nimble Podium 2-in-1 Wireless Charging Station. This device is designed to provide efficient and convenient wireless charging for your compatible iPhone and AirPods. Featuring Qi2 certification and MagSafe compatibility, it ensures optimal alignment and fast charging speeds. Please read this manual carefully to ensure proper setup and operation.



Image: The Nimble Podium 2-in-1 Wireless Charging Station, showcasing an iPhone magnetically attached to the upright stand and AirPods charging on the base. This image illustrates the product's primary function of charging two devices simultaneously.

WHAT'S INCLUDED

The Nimble Podium 2-in-1 Wireless Charging Station package contains the following items:

- 1x Nimble Podium 2-in-1 Wireless Charging Stand
- 1x 45W USB-C Power Adapter
- 1x 1.5M USB-C to USB-C Cable
- 1x Quick Start Guide (this manual)

KEEP YOUR DESK ORGANIZED



Image: A visual representation of the package contents, including the charging stand, 45W USB-C power adapter, USB-C cable, and quick start guide.

SETUP INSTRUCTIONS

1. **Connect the Power Adapter:** Insert one end of the provided USB-C cable into the USB-C port on the back of the Nimble Podium charging station.
2. **Plug into Power:** Connect the other end of the USB-C cable to the 45W USB-C Power Adapter. Plug the power adapter into a wall outlet.
3. **Position the Stand:** The charging stand features an adjustable magnetic phone charger. Gently pull the magnetic disc upwards to raise the stand to your desired viewing angle. It can be used upright or folded flat.



Image: A step-by-step visual guide for effortless charging: 1. Place device on the base. 2. Instant contact charging begins. 3. Lift upward to remove.

OPERATING INSTRUCTIONS

Charging Your iPhone

1. **Magnetic Attachment:** Place your MagSafe-compatible iPhone (iPhone 12 series or newer) onto the upright magnetic charging pad. The magnets will automatically align your device for optimal charging.
2. **Charging Confirmation:** Your iPhone screen will display a charging animation to confirm that charging has begun.
3. **Adjustable Viewing:** The magnetic stand allows for 360° rotation, enabling you to use your iPhone in portrait mode for video calls or landscape mode for streaming content while it charges.

2 IN 1 CHARGING STATION

3 Flexible Viewing Modes





Image: The charging station demonstrating three flexible viewing modes: portrait for video calls, landscape for movies, and laying flat for a clean setup.

Charging Your AirPods

1. **Placement:** Place your AirPods (with a wireless charging case) onto the flat charging pad located on the base of the station.
2. **Charging Confirmation:** The indicator light on your AirPods case will illuminate to confirm that charging has begun.

Simultaneous Charging

You can charge both your iPhone and AirPods simultaneously. The Nimble Podium is designed to deliver up to 25W fast charging for your iPhone and efficient charging for your AirPods.



WALL STREET
JOURNAL.

SLATE

BUSINESS
INSIDER

Forbes

Image: The charging station with an iPhone on the magnetic stand and AirPods on the flat charging pad, illustrating simultaneous charging of multiple devices.

Nightstand Mode

When your iPhone is placed in landscape orientation on the magnetic stand, it can activate Nightstand Mode (if supported by your iPhone model and iOS version), turning your phone into a bedside clock and smart display.

Your browser does not support the video tag.

Video: An official product video demonstrating the Nimble Podium 2-in-1 Wireless Charging Station in use, highlighting its adjustable stand, MagSafe compatibility, fast charging, and ability to charge two devices simultaneously, including Nightstand Mode functionality.

COMPATIBILITY

The Nimble Podium 2-in-1 Wireless Charging Station is compatible with:

- **iPhones:** iPhone 17, 17 Air, 17 Pro, 17 Max, 16, 16 Plus, 16 Pro, 16 Pro Max, 16e, 15, 15 Plus, 15 Pro, 15 Pro Max, 14, 14 Plus, 14 Pro, 14 Pro Max, 13, 13 mini, 13 Pro, 13 Pro Max, 12, 12 mini, 12 Pro, 12 Pro Max. (Requires MagSafe compatibility for magnetic attachment and optimal charging.)
- **AirPods:** AirPods Pro, AirPods 4, AirPods 3, AirPods 2 (requires a wireless charging case).

For optimal magnetic hold and charging efficiency, ensure your iPhone is either used without a case or with a MagSafe-compatible case.

WIRELESS CHARGER COMPATIBLE WITH YOUR APPLE DEVICES



iPhone 17/16 series
(except 16e)

iPhone
15/14/13/12 series



AirPods / AirPods Pro
with wireless charging



MagSafe
Magnetic case



Non-magnetic case
(remove for optimal hold)

Image: A visual guide detailing compatible iPhone models (17/16 series, 15/14/13/12 series) and AirPods with wireless charging cases. It also illustrates the necessity of a MagSafe magnetic case for proper function.

SAFETY FEATURES

The Nimble Podium is equipped with multiple safety protections to ensure safe and reliable charging:

- **Adaptive Charging:** Adjusts power delivery for optimal charging.
- **Overheat Protection:** Prevents the device from reaching excessive temperatures.
- **Overcharge Protection:** Protects your devices from being overcharged.
- **Object Detection:** Detects foreign objects on the charging surface to prevent hazards.
- **Short Circuit Protection:** Guards against electrical short circuits.



Image: A graphic illustrating the 5-in-1 safety protection features of the charging station, including adaptive charging, overheat protection, overcharge protection, object detection, and short circuit protection.

SPECIFICATIONS

Brand	Nimble
Model	Podium 2-in-1 Wireless Charging Station
Connectivity Technology	Wireless
Connector Type	USB Type C
Wattage	25 Watts (Max)
Input Voltage	24.49 Volts
Color	Black
Special Feature	Qi2 Certified, MagSafe Compatible, Foldable Design, 360° Viewing Angle
Dimensions (Folded)	Approximately 6.29 in (Length) x 3.36 in (Width) x 0.85 in (Height)

ULTRA SLIM DESIGN



Easy
to Carry



Strong
Durability



Lightweight



Image: The Nimble Podium in its compact, folded state, highlighting its ultra-slim design, portability, durability, and lightweight construction, along with its approximate dimensions.

CARE AND MAINTENANCE

- **Cleaning:** Disconnect the charging station from power before cleaning. Use a soft, dry, lint-free cloth to wipe the surface. Avoid using abrasive cleaners, solvents, or aerosol sprays.
- **Storage:** When not in use, store the charging station in a cool, dry place. Its foldable design makes it convenient for compact storage or travel.
- **Environmental Considerations:** Nimble products are designed with sustainability in mind, utilizing recycled materials. For information on recycling old electronics, please refer to local guidelines or Nimble's recycling program.



SUSTAINABLE BY DESIGN

We'll Recycle Your Old Tech for Free



Certified



Corporation



Image: The Nimble Podium alongside graphics indicating its "Sustainable by Design" philosophy, including certifications like B Corporation, Ecovadis Gold, and The Climate Label, emphasizing its eco-friendly manufacturing.

TROUBLESHOOTING

Problem	Possible Cause / Solution
---------	---------------------------

Problem	Possible Cause / Solution
Device not charging.	◦ Ensure the charging station is properly connected to the 45W power adapter and a live wall outlet. ◦ Verify your device is correctly aligned on the charging pad (for iPhone, ensure MagSafe alignment). ◦ Remove any non-MagSafe compatible cases from your iPhone. ◦ Ensure your AirPods case supports wireless charging. ◦ Check for foreign objects between the device and the charging pad.
Slow charging.	◦ Confirm you are using the provided 45W USB-C Power Adapter and cable. ◦ Ensure proper alignment of your device on the charging pad. ◦ Avoid using thick or non-MagSafe cases that can impede charging efficiency. ◦ Close unnecessary background apps on your device.
Magnetic stand is stiff or difficult to adjust.	◦ The stand is designed to be firm for stability. Apply gentle, consistent pressure to adjust. ◦ Ensure no debris is obstructing the hinge mechanism.
Device or charger feels warm during charging.	◦ It is normal for wireless chargers and devices to become slightly warm during operation. ◦ If it becomes excessively hot, disconnect the charger and device immediately. Ensure proper ventilation and check for foreign objects. ◦ The charger has built-in overheat protection.

WARRANTY AND SUPPORT

The Nimble Podium 2-in-1 Wireless Charging Station comes with a **2-year warranty**. For warranty claims, technical support, or further assistance, please contact Nimble customer service through their official website or the retailer where the product was purchased.

For more information, visit the [Nimble Store on Amazon](#).

© 2026 Nimble. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0G853T54N>

More documents and user manuals: **<https://manuals.plus/>**