

- Manuals.plus /
- › RALGEND /
- › RALGEND 52-inch L-Shaped Gaming Desk with Shelves and Power Outlet - Instruction Manual

RALGEND 5001DNUDBB

RALGEND 52-inch L-Shaped Gaming Desk Instruction Manual

Model: 5001DNUDBB

INTRODUCTION

Thank you for choosing the RALGEND 52-inch L-Shaped Gaming Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image: The RALGEND L-Shaped Gaming Desk fully assembled, showcasing its design with monitors, LED lighting, and integrated storage shelves.

SAFETY INFORMATION

To ensure safe use and prevent damage, observe the following guidelines:

- Assemble the desk strictly according to the provided instructions.
- Keep the computer desk away from water, fire, and high-temperature environments.
- Use the included anti-tip strap to enhance overall stability and prevent accidental tipping.
- Do not climb on the computer desk.
- Ensure all connections for the power outlet and LED lights are secure before use.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly. Refer to the parts list included in your packaging for specific item identification. All necessary assembly tools are included.

- Desk panels (engineered wood)
- Metal frame components
- 5-tier shelving unit components
- Monitor stand

- Built-in power strip (3 AC outlets, 2 USB ports)
- LED light strip
- Assembly hardware (screws, bolts, etc.)
- Anti-tip kit
- Assembly tools

ASSEMBLY INSTRUCTIONS

Follow the step-by-step instructions provided in the separate assembly manual included with your product. Ensure all parts are correctly oriented and tightened securely. The desk can be assembled with the shelving unit on either the left or right side.




Image: A detailed diagram illustrating the dimensions of the L-shaped desk and its reversible configuration option for the shelving unit.

Key Assembly Points:

- **Reversible Design:** The L-shaped configuration allows the 5-tier shelving unit to be installed on either the left or right side of the main desk. Decide your preferred orientation before starting.
- **Secure Connections:** Ensure all screws and bolts are fully tightened to provide maximum stability. Do not overtighten.
- **Anti-Tip Kit:** Install the anti-tip kit as directed in the assembly manual to prevent the desk from tipping, especially if heavy items are placed on the shelves.

OPERATING INSTRUCTIONS

Power Outlet Usage:


The desk includes a built-in power strip with 3 AC outlets (120V 12A) and 2 USB ports (5V 2A). Connect the desk's power cord (4.9-foot) to a standard wall outlet. You can then plug in your electronic devices directly into the desk's integrated power hub.



Image: A close-up view of the integrated power strip, showing three AC outlets and two USB ports, with devices charging.

LED Light Operation:

The integrated LED light strip can be controlled via an app. Refer to the separate LED light instruction manual for detailed pairing and operation instructions. The lights offer various color options, music sync, a built-in microphone for sound reactivity, and a timing function.



SET YOUR VIBE

Adjustable lighting for a personalized atmosphere



Over 6000 Colors



Music Sync



Built-in Mic



Timing Function

Image: The L-shaped desk with its LED lights illuminated in blue, highlighting the customizable lighting features controlled via a mobile application.

MAINTENANCE

Regular maintenance will help prolong the life and appearance of your desk:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Tighten Fasteners:** Periodically check and retighten all screws and bolts to ensure the desk remains stable.
- **Cable Management:** Organize cables to prevent tangles and reduce strain on the power strip.

TROUBLESHOOTING

If you encounter issues with your RALGEND L-Shaped Gaming Desk, consider the following:

- **Desk Wobbles:** Ensure all assembly screws are tightened. Check that the desk is on a level surface. Adjust any leveling feet if present.
- **Power Outlet Not Working:** Verify the desk's main power cord is securely plugged into a functional wall outlet. Check for tripped circuit breakers.
- **LED Lights Not Functioning:** Ensure the LED light strip is properly connected to its power source. Refer to the LED light manual for app pairing and troubleshooting steps.

SPECIFICATIONS

Feature	Detail
Brand	RALGEND
Model Number	5001DNUDBB
Shape	L-Shaped (Reversible)
Product Dimensions (D x W x H)	18.9" x 52.2" x 43.3"
Color	Black
Material	Engineered Wood, Metal
Item Weight	39.7 Pounds
Number of Shelves	5 (Open)
Maximum Weight Recommendation	200 Pounds
Power Outlet	3 AC Outlets (120V 12A), 2 USB Ports (5V 2A)
LED Lights	App-controlled, various colors, music sync, built-in mic, timing function
Included Components	Power Strip, LED Light Strip, Monitor Stand, Anti-tip Kit
Assembly Required	Yes (Instructions and tools included)



MONITOR STAND

Elevates screen height for less neck strain

😊 After



😞 Before



Image: A visual comparison demonstrating the ergonomic advantage of the elevated monitor stand, promoting better posture.

PRODUCT OVERVIEW VIDEO

Your browser does not support the video tag.

Video: An official RALGEND video showcasing the L-Shaped Gaming Desk, highlighting its 5-tier storage shelves and LED lighting features.

WARRANTY AND SUPPORT

This RALGEND product comes with a limited warranty. For specific warranty details, claims, or technical support, please refer to the warranty card included in your package or contact RALGEND customer service through the retailer where the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0G8H4C5RG>

More documents and user manuals: <https://manuals.plus/>