

[Manuals.plus](#) /

› [Otolonpe](#) /

› Otolonpe S-F16B Personal Portable Desk Fan User Manual

Otolonpe S-F16B

Otolonpe S-F16B Personal Portable Desk Fan User Manual

Model: S-F16B / S-F16A

1. INTRODUCTION

Thank you for choosing the Otolonpe S-F16B Personal Portable Desk Fan. This compact and versatile fan is designed to provide efficient cooling wherever you need it, featuring a powerful 4000mAh rechargeable battery, four adjustable speed settings, and an emergency power bank function. Please read this manual thoroughly before use to ensure proper operation and maintenance.

2. SAFETY INFORMATION

- Do not insert fingers or any objects into the fan grille when the fan is operating.
- Keep the fan away from water and other liquids to prevent electric shock.
- Do not disassemble or modify the fan. Repairs should only be performed by qualified personnel.
- Ensure the power source voltage is compatible with the fan's requirements (5V/2A).
- Keep out of reach of children.
- Avoid prolonged exposure to direct sunlight or high temperatures.
- When cleaning, ensure the fan is turned off and unplugged.

3. PACKAGE CONTENTS

- Otolonpe S-F16B Personal Portable Desk Fan
- USB-C Charging Cable
- User Manual

4. PRODUCT OVERVIEW

The Otolonpe S-F16B fan features a compact design with a front grille, control button, and a foldable stand for versatile positioning. It is equipped with a 4000mAh battery for cordless operation and a USB-C port for charging and power bank functionality.



This image shows the Otlonpe Personal Portable Desk Fan from the front, highlighting its compact design and fan grille.

5. SETUP

1. **Unpack:** Carefully remove the fan and all accessories from the packaging.
2. **Initial Charge:** Before first use, fully charge the fan. Connect the provided USB-C cable to the fan's charging port and the other end to a 5V/2A USB power adapter (not included) or a computer USB port. The charging indicator lights will show the charging status.
3. **Positioning:** Place the fan on a stable, flat surface. Adjust the foldable stand to achieve the desired angle for airflow. The fan head can be adjusted 180 degrees.

6. OPERATING INSTRUCTIONS

The fan features a single control button for power and speed adjustment.

- **Power On/Speed 1:** Press the power button once to turn on the fan at speed 1 (gentle breeze).
- **Speed 2:** Press the power button a second time for speed 2 (moderate breeze).

- **Speed 3:** Press the power button a third time for speed 3 (strong breeze).
- **Speed 4:** Press the power button a fourth time for speed 4 (powerful gust).
- **Power Off:** Press the power button a fifth time to turn off the fan.

7. CHARGING THE FAN

The fan is equipped with a 4000mAh rechargeable battery, providing 5-23 hours of cordless operation depending on the speed setting. It takes approximately 4 hours to fully charge the fan using a 5V/2A input.



This image illustrates the fan's long battery life and quick charging capabilities. It shows the fan in a cold environment, emphasizing its 'All-Day Cooling, Cord-Free' feature, powered by a 4000mAh battery for up to 23 hours of use. It also notes that it charges fully in 4 hours (5V/2A input) and can be used while charging.

- Connect the USB-C charging cable to the fan's charging port.
- Connect the other end of the cable to a compatible USB power source (e.g., wall adapter, power bank, computer USB port).
- The indicator lights will illuminate to show the charging progress. Once fully charged, the lights will indicate a full battery.

- The fan can be used while it is charging.

8. EMERGENCY POWER BANK FUNCTION

The Otlonpe S-F16B fan can also function as an emergency power bank to charge your mobile devices.

- Ensure the fan has sufficient battery charge.
- Connect your device's charging cable to the fan's USB-C port.
- The fan will begin to charge your device. Note that this function is intended for emergency use and may not provide a full charge to all devices.

9. MAINTENANCE AND CLEANING

Regular cleaning helps maintain optimal performance and extends the lifespan of your fan.

1. **Power Off:** Always ensure the fan is turned off and unplugged before cleaning.
2. **Front Grille Removal:** The front grille is detachable for easy cleaning. Gently snap off the front grille.
3. **Cleaning Blades and Grille:** Use a soft, dry cloth or a brush to remove dust from the fan blades and the grilles. For stubborn dirt, a slightly damp cloth can be used, but ensure no water enters the motor area.
4. **Reassembly:** Once clean and dry, carefully snap the front grille back into place.
5. **Exterior Cleaning:** Wipe the exterior of the fan with a soft, dry cloth. Do not use abrasive cleaners or solvents.

10. TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on.	Battery is depleted.	Charge the fan using the provided USB-C cable.
Fan runs slowly or weakly.	Low battery.	Recharge the fan.
Fan makes unusual noise.	Obstruction in blades or grille.	Turn off and unplug the fan. Carefully check for and remove any obstructions. Clean the blades.
Cannot charge external device.	Fan battery is too low; incorrect cable.	Ensure the fan is sufficiently charged. Use a compatible charging cable for your device.

11. SPECIFICATIONS

Feature	Detail
Model Name	S-F16B
Model Number	S-F16A
Brand	Otлонpe
Power Source	Battery Powered (4000mAh) / USB Powered
Number of Speeds	4
Noise Level	30 dB

Feature	Detail
Wattage	7.5 watt-hours
Voltage	5 volts DC
Dimensions (D x W x H)	3.8D x 14.4W x 16.8H centimetres
Item Weight	260 g
Material	Acrylonitrile Butadiene Styrene, Plastic
Special Features	Adjustable Tilt, Foldable, Portable, Quiet Operation, Safety Certified
Certifications	CE, FCC, RoHS, UL

12. WARRANTY AND SUPPORT

The Otolnpe S-F16B Personal Portable Desk Fan comes with a **180-Day Manufacturer's Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. For warranty claims, technical support, or any questions regarding your product, please contact Otolnpe customer service through the retailer where the product was purchased or refer to the contact information provided on the product packaging. Please retain your proof of purchase for warranty validation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0G8J6GJDK>

More documents and user manuals: <https://manuals.plus/>