

[Manuals.plus](#) /

› [Pagani Design](#) /

› Pagani Design PD1820 Automatic Men's Watch Instruction Manual

Pagani Design PD1820

Pagani Design PD1820 Automatic Men's Watch Instruction Manual

Model: PD1820

INTRODUCTION

Thank you for choosing the Pagani Design PD1820 Automatic Men's Watch. This timepiece combines advanced style with precise Japanese automatic movement and robust construction. This manual provides detailed instructions to help you understand and properly care for your watch, ensuring its optimal performance and longevity.

Your watch features a 43mm stainless steel case, a synthetic sapphire dial window, and is available with either a leather or stainless steel strap. It is powered by a Japanese 8220A automatic movement and boasts 100 meters of water resistance.



Image: The Pagani Design PD1820 watch with a green leather strap, worn on a person's wrist, showcasing its design.

SETUP

Initial Winding

As an automatic watch, the PD1820 is powered by the motion of your wrist. However, for the first use or after a period of inactivity, manual winding is recommended to ensure sufficient power reserve.

1. Unscrew the crown (if it's a screw-down crown) by turning it counter-clockwise.
2. Gently pull the crown out to position 1 (for winding).
3. Rotate the crown clockwise 20-30 times. This will build up the initial power reserve.
4. Push the crown back in and screw it down clockwise to ensure water resistance.

Setting Time and Date

1. Unscrew the crown (if applicable) and pull it out to position 2 (for date setting).
2. Turn the crown clockwise or counter-clockwise to set the date. Avoid setting the date between 9 PM and 3 AM, as this can damage the movement.
3. Pull the crown out to position 3 (for time setting). The second hand will stop.
4. Turn the crown to set the hour and minute hands. To ensure accurate AM/PM setting, advance the hands past 12 o'clock; if the date changes, you are in the AM hours.
5. Once the time is set, push the crown back to position 0 and screw it down tightly to maintain water resistance.



Image: A close-up view of the Pagani Design PD1820 watch dial and its crown, illustrating the setting mechanism.

Adjusting the Strap

The watch is available with either a leather strap or a stainless steel bracelet. For leather straps, adjust the buckle to fit your wrist comfortably. For stainless steel bracelets, a strap adjustment tool (included with the watch) may be used to remove or add links for a proper fit. If you are unsure, consult a professional watchmaker.

OPERATING YOUR WATCH

Automatic Movement

Your Pagani Design PD1820 watch is equipped with a Japanese 8220A automatic movement. This movement is self-winding, meaning it gains power from the natural motion of your arm. When worn daily, the watch will maintain its power reserve. If the watch is not worn for an extended period (approximately 40 hours of power reserve), it may stop and require manual winding as described in the 'Initial Winding' section.

Unidirectional Rotating Bezel

The watch features a unidirectional rotating bezel, which turns only counter-clockwise. This feature is useful for timing events, such as dives or elapsed time. To use it, align the bezel's zero marker with the minute hand at the start of an event. The minute hand's position on the bezel will then indicate the elapsed time.

Luminescence

The hour markers and hands of your watch are treated with a luminous material, allowing for clear time reading in low-light conditions. Exposure to light will charge the luminous elements.



Image: A detailed close-up of the Pagani Design PD1820 watch dial, highlighting the luminous hour markers and hands.

MAINTENANCE

Cleaning

Regular cleaning helps maintain the appearance and hygiene of your watch. Use a soft, dry cloth to wipe the case and crystal. For leather straps, wipe with a soft, damp cloth and allow to air dry. For stainless steel bracelets, a soft brush with mild soap and water can be used, ensuring to rinse thoroughly and dry completely.

Water Resistance

Your Pagani Design PD1820 watch is water-resistant up to 100 meters (10 ATM). This means it is suitable for everyday use, including hand washing, face washing, and swimming. However, it is crucial to observe the following precautions:

- **Do not press any buttons or operate the crown while the watch is submerged in water.**
- Always ensure the crown is fully screwed down (if applicable) before exposing the watch to water.
- Avoid exposing the watch to extreme temperature changes, such as hot showers, saunas, or hot springs, as this can compromise the water resistance seals.
- Do not wear the watch during diving activities beyond its rated depth.

Storage

When not wearing your watch, store it in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields. The original watch box is ideal for storage.

TROUBLESHOOTING

Watch Not Running or Stopping Frequently

- **Insufficient Power Reserve:** As an automatic watch, it requires motion to operate. If the watch has been inactive, manually wind it 20-30 times as described in the 'Initial Winding' section.
- **Lack of Wear:** If you do not wear the watch daily, consider using a watch winder to keep it powered.
- **Impact:** A severe impact could affect the movement. If the issue persists after winding, professional inspection may be required.

Condensation Under the Crystal

- Small amounts of condensation that disappear quickly are usually normal due to temperature changes.
- If heavy condensation persists or water droplets are visible, the water resistance may be compromised. Immediately take the watch to a qualified watch repair center to prevent further damage.

SPECIFICATIONS

Feature	Detail
Model Number	PD1820
Movement Type	Japanese Automatic (8220A)
Case Material	Stainless Steel
Case Diameter	43 mm
Case Thickness	13.3 mm

Feature	Detail
Dial Window Material	Synthetic Sapphire
Strap Material	Stainless Steel / Leather
Strap Width	24 mm
Strap Length	230 mm
Water Resistance	100 Meters (10 ATM)
Clasp Type	Safety Folding Buckle / Pin Buckle
Special Features	Unidirectional Rotating Bezel, Luminous Hands and Markers, Automatic Winding

WARRANTY AND SUPPORT

Warranty Information

Your Pagani Design PD1820 watch comes with a limited warranty. For specific details regarding the warranty period and coverage, please refer to the warranty card included in your product packaging. This warranty typically covers manufacturing defects under normal use.

Please note that Amazon.it offers a 30-day return policy for many products. For exceptions and conditions, please consult the Amazon.it return policy.

Customer Support

Should you have any questions or require assistance with your Pagani Design watch, please refer to the contact information provided in your product packaging or reach out to the seller, Tyberley Watch Store, through the Amazon platform. Providing your model number (PD1820) and purchase details will help expedite support.



Image: The Pagani Design PD1820 watch presented in its original box, ready for gifting or storage.

© 2023 Pagani Design. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0G8JRQDV1>

More documents and user manuals: <https://manuals.plus/>