

## GOEBLESON B04CF4205

# GOEBLESON 42-inch Ceiling Fan with Lights and Remote

Model: B04CF4205

User Manual

## 1. IMPORTANT SAFETY INFORMATION

---

Please read all instructions carefully before beginning installation. Failure to follow these instructions could result in electric shock, fire, or personal injury.

- Ensure the power is turned off at the circuit breaker before installation or maintenance.
- All wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- The fan must be mounted to a structurally sound ceiling joist or outlet box capable of supporting the fan's weight.
- Do not bend blade holders during installation or cleaning.
- This fan is ETL certified.

## 2. INCLUDED COMPONENTS

---

Verify that all parts are present before beginning assembly.

- Ceiling Fan Motor Assembly
- 5 Dual-Tone ABS Blades (Rustic Brown wood grain / Black)
- Light Kit with Cage-Style Housing
- Remote Control with Wall-Mountable Base
- Downrods (6-inch and 10-inch options)
- Mounting Bracket and Hardware
- User Manual

**Note:** 2 x E26 light bulbs are not included and must be purchased separately.



Image: Overview of the GOEBLESON 42-inch Ceiling Fan's main components, including the fan blades, downrods, and remote control unit.

### 3. SETUP AND INSTALLATION

---

Installation hardware and detailed instructions are included for straightforward setup. Clear instructions are provided to make installation quick and easy.

1. **Prepare for Installation:** Turn off power at the circuit breaker. Ensure the mounting location can support the fan's weight.
2. **Mounting Bracket:** Secure the mounting bracket to a ceiling joist or a UL-listed outlet box. For sloped ceilings, this fan supports a sloped ceiling as long as the pitch is not too steep. A well-mounted metal electrical box is recommended; a stud brace may be needed for secure mounting.
3. **Downrod Selection:** Choose between the 6-inch or 10-inch downrod to adjust the ceiling fan height according to your room's requirements.
4. **Wiring:** Connect the fan's wiring to your household electrical system. Ensure all connections are secure and follow local electrical codes. The remote control wiring is designed for ample room during installation.
5. **Attach Fan Assembly:** Carefully lift the fan motor assembly and attach it to the mounting bracket.

6. **Install Blades:** Attach the five dual-tone ABS blades to the motor housing.
7. **Install Light Kit:** Connect the light kit to the fan assembly. Insert 2 x E26 bulbs (not included) into the light sockets.
8. **Final Checks:** Ensure all connections are tight and the fan is securely mounted. Restore power at the circuit breaker.



Image: Illustrates the dimensions of the 42-inch ceiling fan and the adjustable height options using 6-inch and 10-inch downrods.

## TURN ON/OFF THE FAN OR LIGHT INDEPENDENTLY





Image: Details on how to turn the fan and light on/off independently, the E26 light bulb base, and the included wall-mountable base for the remote control.

## 4. OPERATING INSTRUCTIONS

The GOEBLESON ceiling fan is operated using the included remote control, which offers various functions for comfort and convenience.

### 4.1 Remote Control Functions

- **Power On/Off:** Separate buttons for fan and light control.
- **Fan Speed:** 6-speed adjustment settings.
- **Timer:** Set the fan to turn off automatically after 1H, 2H, 3H, 4H, 5H, or 8H.
- **Fan Reversal:** One-button control to change the fan's rotation direction.
- **Wall-Mountable Base:** The remote includes a wall-mountable base for convenient storage.

### 4.2 Reversible DC Motor

The fan features a reversible DC motor for all-season comfort. DC motors are energy-efficient, powerful, and quieter

than traditional AC motors.

- **Forward Mode (Summer):** Downward airflow creates a cooling effect.
- **Reverse Mode (Winter):** Upward airflow circulates warm air, helping to balance indoor temperature differences.

### 4.3 Quiet Operation

The fan operates at noise levels below 30dB, ensuring a peaceful environment for bedrooms, living rooms, and home offices.



Image: Features of the GOEBLESON 42-inch Ceiling Fan, including remote control functions, quiet operation, and adjustable speeds.

# Reversible DC Motor



## Forward Mode

Powerful airflow for quick cooling



## Reverse Mode

Balances indoor temperature differences for a warmer winter



Image: Explanation of the reversible DC motor, illustrating forward mode for cooling and reverse mode for circulating warm air.

## High-Quality Reversible DC Motor

Noise level below **30dB** for a peaceful night sleep time



Image: Visual representation of the fan's low noise level (below 30dB), ideal for quiet environments like bedrooms.

## 5. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Periodically wipe the fan blades and motor housing with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Tighten Screws:** Check all screws and connections annually to ensure they are secure.
- **Bulb Replacement:** Ensure power is off before replacing light bulbs. Use E26 base bulbs.

## 6. TROUBLESHOOTING

If you encounter issues with your GOEBLESON ceiling fan, refer to the following common solutions:

- **Fan Does Not Operate:**
  - Check if the power is on at the circuit breaker.

- Ensure all wiring connections are secure.
- Verify remote control batteries are installed correctly and are not depleted.

- **Light Does Not Work:**

- Check if the light switch on the remote is activated.
- Ensure light bulbs are correctly installed and not burnt out.
- Verify wiring connections to the light kit.

- **Fan Wobbles:**

- Ensure all blade screws are tightened.
- Check that the mounting bracket is securely fastened to the ceiling.
- Verify the downrod is properly seated and secured.

- **Remote Control Issues:**

- If the remote seems unresponsive, replace the AAA batteries.
- Note that some users have reported the light on/off icons on the remote appearing reversed. This is a known characteristic and not a malfunction.

- **Fan Speed Too Fast on Lowest Setting:**

- The lowest speed setting (1) is designed to provide effective air circulation. If it feels too fast for your preference, this is generally within the fan's operating parameters.

## 7. SPECIFICATIONS

---

|                                |                                       |
|--------------------------------|---------------------------------------|
| Brand                          | GOEBLESON                             |
| Model                          | B04CF4205                             |
| Fan Size                       | 42 inches                             |
| Color                          | Rustic Brown and Black                |
| Style                          | Industrial / Farmhouse                |
| Power Source                   | DC Motor                              |
| Product Dimensions (D x W x H) | 106.7D x 106.7W x 37.6H centimetres   |
| Number of Blades               | 5                                     |
| Number of Speeds               | 6                                     |
| Noise Level                    | Below 30 dB                           |
| Air Flow Capacity              | Max 6700 CFM (Cubic Feet Per Minute)  |
| Max Speed                      | 160 RPM                               |
| Downrod Lengths Included       | 6 inches, 10 inches                   |
| Light Kit                      | Requires 2 x E26 bulbs (not included) |

|                      |                               |
|----------------------|-------------------------------|
| Control Method       | Remote Control                |
| Indoor/Outdoor Usage | Indoor, Covered Outdoor Areas |
| Certifications       | ETL Certified, FCC            |



Robust Metal Cage  
& Frame



Sturdy and Stable Lamp  
Connection



Black: Industrial Style  
Rustic Brown: Farmhouse Style



Sturdy Light Holder

Image: Close-up views of the fan's robust metal cage, sturdy lamp connection, and the dual-color options for the blades (black and rustic brown).

## 8. WARRANTY AND SUPPORT

For warranty information or any questions regarding setup, operation, or troubleshooting, please contact GOEBLESON customer support. 24/7 customer support is available to ensure hassle-free setup and use.

Please refer to your purchase documentation or the GOEBLESON official website for specific warranty terms and contact details.

## ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question