Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VASAGLE UZH2507008

VASAGLE UZH2507008 Dining Table Set Instruction Manual

Model: UZH2507008

INTRODUCTION

Thank you for choosing the VASAGLE UZH2507008 Dining Table Set. This manual provides essential information for the safe assembly, operation, and maintenance of your new dining table and chairs. Please read these instructions carefully before assembly and retain them for future reference.



Image: The VASAGLE UZH2507008 Dining Table Set, featuring a round snow white table and two cream white upholstered chairs.

Safety Information

To ensure safe use of this product, please adhere to the following guidelines:

- Do not load more than **220 lb (100 kg)** on the dining table.
- Do not load more than **265 lb (120 kg)** per dining chair.
- Always ensure all screws and fasteners are securely tightened before use.
- Keep small parts away from children during assembly to prevent choking hazards.
- Assemble the product on a soft, clean surface to avoid scratches.
- Periodically check and re-tighten all connections to maintain stability.




Image: A diagram illustrating the maximum static load capacities: 220 lb (100 kg) for the dining table and 265 lb (120 kg) for each dining chair, along with key dimensions.

Package Contents

Please verify that all components are present before beginning assembly:

Dining Table Package:

- 1 x Dining Table
- 1 x Accessory Kit (screws, tools, etc.)
- 1 x Instructions (this manual)

Dining Chairs Package:

- 2 x Dining Chairs
- 1 x Instructions (this manual)

SPECIFICATIONS

Component	Specification
Dining Table Color	Snow White
Dining Table Material	Particleboard, Steel
Dining Table Size	31.5" Dia. x 29.4" H (80 x 74.8 cm)
Dining Table Max. Load Capacity	220 lb (100 kg)
Dining Chair Color	Cream White
Dining Chair Material	Foam, Teddy Fleece, Plywood, Steel
Dining Chair Size (per chair)	23.2" D x 19" W x 32.4" H (59 x 48.5 x 82.5 cm)
Dining Chair Max. Load Capacity (per chair)	265 lb (120 kg)
Overall Product Weight	Approximately 24.68 kg (Table: 14.5 kg, Chairs: 10.2 kg)



Image: A close-up view of the dining table's 1-inch (2.5 cm) thick particleboard tabletop, highlighting its durable construction and heat resistance.



Image: A diagram illustrating the dining chair's extra-wide 19-inch (48.5 cm) seat and 3.9-inch (10 cm) thick plush cushion, emphasizing comfort.



Image: A close-up of the premium teddy fleece fabric used on the dining chairs, highlighting its soft texture.



Image: A diagram detailing the sturdy and adaptable features of the dining chair, including quality steel construction, an X-shaped base for stability, flared legs, and adjustable feet for uneven floors.

Assembly Instructions

Follow these steps carefully for proper assembly. It is recommended to assemble the product on a soft, clean surface to prevent damage.

1. Dining Table Assembly

1. Unpack all components and lay them out. Identify the tabletop and the table base components.
2. Attach the central support column to the tabletop using the provided screws. Ensure the arrows on the column align with the pre-drilled holes on the tabletop.
3. Attach the four leg supports to the central column, forming an 'X' shape at the base. Secure them with the designated screws.
4. Tighten all screws firmly. Do not overtighten.
5. Carefully flip the table upright.



Image: A simplified diagram illustrating the assembly process for the dining table, showing the attachment of the base to the tabletop with a few screws, indicating a quick 15-minute setup.

2. Dining Chair Assembly

1. Unpack all chair components: seat, backrest, and leg frames.
2. Attach the backrest to the seat cushion using the provided screws.
3. Connect the two leg frames to the underside of the seat cushion. Ensure the flared legs are positioned correctly for stability.

4. Insert the adjustable feet into the bottom of each leg.
5. Tighten all screws firmly. Do not overtighten.
6. Repeat for the second chair.



Image: A step-by-step diagram illustrating the assembly of a dining chair in 4 steps, indicating a quick 10-minute setup by attaching the backrest, then the two leg frames to the seat.

Operating and Usage

Your VASAGLE dining set is designed for comfortable and functional use in various settings.

- The round tabletop provides ample space for 2-4 people, making it suitable for small family meals or gatherings.
- The upholstered chairs with thick padded seats and wide backrests offer comfortable support for extended periods.
- Adjust the feet on the chairs to ensure stability on uneven floor surfaces.



Image: The dining table set in use, showing a person seated comfortably at the round table, demonstrating its capacity to seat 2-4 people.

Maintenance

Proper care will extend the life and appearance of your dining set:

- **Cleaning the Tabletop:** Wipe with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners. Dry immediately to prevent water marks.
- **Cleaning the Chairs:** For the teddy fleece upholstery, gently spot clean with a mild fabric cleaner and a soft cloth. Blot dry. Do not saturate the fabric. For the steel frame, wipe with a damp cloth.
- **General Care:** Avoid placing hot items directly on the tabletop; use coasters or placemats. Keep the furniture away from direct sunlight and heat sources to prevent material degradation.
- **Periodic Checks:** Regularly inspect all screws and connections to ensure they remain tight. Re-tighten as necessary.

Troubleshooting

If you encounter any issues with your dining set, consider the following:

- **Wobbling Table/Chairs:** Check that all screws are securely tightened. For chairs, adjust the leveling feet on the bottom of the legs to compensate for uneven floors.
- **Difficulty Assembling:** Ensure you are using the correct hardware for each step as indicated in the instructions. Do not force components together. If a part seems ill-fitting, double-check the orientation.
- **Scratches/Damage:** If minor scratches occur during assembly, touch-up pens or furniture markers can be used for particleboard surfaces. For upholstery, consult a professional if damage is significant.

Warranty and Support

For information regarding warranty coverage, replacement parts, or further assistance, please refer to the purchase documentation or contact VASAGLE customer support through the retailer where the product was purchased. Please have your model number (UZH2507008) and purchase date available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G8ZZ643B

More documents and user manuals: **https://manuals.plus/**