

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [FUNYET](#) /

> [FUNYET NY-14 Laptop User Manual - 15.6 Inch, 4425Y Processor, 8GB RAM, 256GB SSD](#)

FUNYET NY-14

FUNYET NY-14 Laptop User Manual

Model: NY-14 | Brand: FUNYET

1. INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your FUNYET NY-14 laptop. Please read this guide thoroughly to ensure proper use and to maximize the performance and longevity of your device. The FUNYET NY-14 is a 15.6-inch laptop designed for everyday tasks, study, and office work, featuring a 4425Y processor, 8GB RAM, and a 256GB SSD.

2. WHAT'S IN THE BOX

Verify that all items are present in the package:

- 1 × FUNYET 4425Y Laptop
- 1 × DC 12V2A Adapter
- 1 × Instruction Manual (This Document)
- 1 × Warranty Card

3. PRODUCT OVERVIEW


The FUNYET NY-14 laptop is equipped with features designed for efficiency and user convenience.



A sleek laptop with its screen displaying dynamic visuals, highlighting the model name and processor.

Processor and Performance

The laptop features a 4425Y processor with a base frequency of 1.7 GHz, 2 cores, and 4 threads, providing balanced performance for daily computing tasks.




An illustration detailing the 4425Y processor's specifications, including 1.7GHz max frequency, 2 cores/4 threads, 6W power, and 2MB lithography.

Memory and Storage

Equipped with 8GB of DDR3 RAM for efficient multitasking and a 256GB SSD for fast boot times and application loading. The device also supports TF card expansion up to 1TB for additional storage.

5000mAh for Extended Battery Life

NY-14 laptop features a high-capacity 5000mAh/38.5Wh battery, freeing you from battery life anxiety.



A laptop screen showing various applications running simultaneously, illustrating its multitasking capabilities with 8GB RAM and 256GB SSD.

Display and Graphics

The 15.6-inch Full HD (1920x1080) IPS display offers clear and vibrant visuals. The screen features a 180° hinge for flexible viewing angles and integrated UHD Graphics 615.



The laptop screen displaying a vibrant image, emphasizing the 1920x1080 Full HD IPS display for clear visuals.

Connectivity

Features Wi-Fi 5 (802.11ac) for stable internet and Bluetooth 4.2 for wireless peripheral connections. Physical ports include 2x USB 3.0, 1x Mini HDMI, 1x 3.5mm Headphone Jack, 1x TF Card slot, and 1x DC Power port.

2026 Gold 4425Y CPU

1.7GHz

Max Frequency

2/4

2Cores /4 Threads

6W

Power

2 MB

Lithography



Gold 4425Y

Gold 4415Y

M3-8100Y

Close-up view of the laptop's side ports, including TF Card slot, Headphone Jack, USB 3.0, Mini HDMI, and 12V/2A DC Port, illustrating its comprehensive connectivity options.

Battery

A 5000mAh high-capacity battery provides extended usage time, ideal for users on the go.

Diverse Ports for Interaction



An internal view highlighting the laptop's 5000mAh battery, emphasizing its extended battery life for prolonged use.

Design and Additional Features

The laptop features a lightweight design, weighing 1.6kg and measuring 20mm thick. It includes a comfortable keyboard with a numeric keypad and a built-in webcam with a microphone for video calls.


Lightweight Design

NY-14 notebook weighs just 1.6kg and is only 20mm thick, making it easy to carry and use anywhere.



A person carrying the slim and lightweight NY-14 laptop, highlighting its portability with a weight of 1.6kg and 20mm thickness.

Comfort Keyboard



An image showcasing the laptop's comfortable keyboard with an enlarged touchpad area and a separate numeric keypad for enhanced productivity.

4. SETUP

4.1 Unpacking and Initial Inspection

Carefully remove all components from the packaging. Inspect the laptop and accessories for any signs of damage. If any damage is found, contact customer support immediately.

4.2 Charging the Battery

Before first use, connect the DC 12V2A adapter to the laptop's DC power port and plug it into a power outlet. Allow the battery to charge fully. The charging indicator light will typically change color or turn off when charging is complete.

4.3 First Power On and Windows Setup

Press the power button to turn on the laptop. Follow the on-screen instructions to complete the Windows 11 Pro setup process. This includes selecting your language, region, connecting to a Wi-Fi network, and creating a user account.

4.4 Connecting Peripherals

You can connect external devices such as a mouse, keyboard, or external hard drive using the USB 3.0 ports. For external displays, use the Mini HDMI port.

5. OPERATING INSTRUCTIONS

5.1 Using the Keyboard and Touchpad

The laptop features a QWERTY layout keyboard with a numeric keypad. The touchpad supports multi-touch gestures for navigation. Refer to Windows 11 settings for customizing touchpad gestures.

5.2 Connecting to Wi-Fi

To connect to a Wi-Fi network, click the Wi-Fi icon in the taskbar, select your desired network, enter the password if required, and click Connect.

5.3 Connecting Bluetooth Devices

To pair a Bluetooth device, go to Windows Settings > Bluetooth & devices, turn on Bluetooth, and select 'Add device'. Follow the on-screen prompts to complete pairing.

5.4 Using External Displays (Mini HDMI)

Connect an external monitor or TV using a Mini HDMI cable. Press **Windows key + P** to select display modes (Duplicate, Extend, Second screen only).

5.5 Using the TF Card Slot

Insert a TF (MicroSD) card into the designated slot to expand storage or transfer files. Ensure the card is inserted correctly to avoid damage.

5.6 Webcam and Microphone

The integrated webcam and microphone are suitable for video conferencing and online communication. Ensure privacy settings are configured in Windows for camera and microphone access.

6. BATTERY MANAGEMENT

The laptop is equipped with a 5000mAh Lithium-Ion battery. To optimize battery life:

- Fully charge the battery before first use.
- Avoid completely discharging the battery frequently.
- Adjust screen brightness to a comfortable, lower level.
- Close unnecessary applications running in the background.

- Enable Windows Battery Saver mode when battery is low.
- Store the laptop in a cool, dry place when not in use for extended periods.

7. MAINTENANCE

7.1 Cleaning

Use a soft, lint-free cloth slightly dampened with water or a screen cleaner to clean the display. For the chassis and keyboard, use a soft, dry cloth. Avoid harsh chemicals or abrasive materials.

7.2 Software Updates

Regularly check for and install Windows updates to ensure system stability, security, and performance. Go to Windows Settings > Windows Update.

7.3 Storage Management

Periodically clean up unnecessary files and applications to maintain optimal performance. Consider backing up important data to an external drive or cloud storage.

8. TROUBLESHOOTING

8.1 No Power / Does Not Turn On

- Ensure the power adapter is securely connected to both the laptop and a working power outlet.
- Verify the power outlet is functional by plugging in another device.
- Allow the battery to charge for at least 30 minutes before attempting to power on again.

8.2 Display Issues

- If the screen is blank, try pressing **Fn + F7** (or the key with a display icon) to toggle display output.
- Ensure brightness is not set to minimum.
- If using an external monitor, check the cable connection and display settings (Windows key + P).

8.3 Wi-Fi Connectivity Problems

- Check if Wi-Fi is enabled in Windows Settings.
- Restart your router and modem.
- Forget the network and reconnect.
- Ensure you are within range of the Wi-Fi signal.

8.4 Slow Performance

- Close unnecessary applications and browser tabs.
- Check for and install any pending Windows updates.
- Run a disk cleanup and defragmentation (for SSDs, this is not typically needed but can be done via Windows tools).
- Scan for malware or viruses.

For issues not resolved by these steps, please contact FUNYET customer support.

9. SPECIFICATIONS

Feature	Specification
Brand	FUNYET

Feature	Specification
Model Name	NY-14
Screen Size	15.6 Inches
Display Resolution	1920 x 1080 (Full HD)
Display Technology	IPS LCD
Processor Model	Pentium 4425Y
Processor Speed	1.7 GHz
RAM Size	8 GB DDR3
Storage Type	256 GB SSD
Operating System	Windows 11 Pro
Graphics Description	Integrated (Intel UHD Graphics 615)
Wireless Connectivity	Wi-Fi 5 (802.11ac), Bluetooth 4.2
USB Ports	2 x USB 3.0
Video Output	1 x Mini HDMI
Audio Output	3.5mm Headphone Jack, Stereo Speakers
Battery Capacity	5000 mAh
Webcam	Yes (Front)
Special Features	HD Audio, Lightweight, Memory Card Slot, Numeric Keypad
Thickness	20 mm
Weight	1.6 kg

10. WARRANTY AND SUPPORT

10.1 Warranty Information

The FUNYET NY-14 laptop comes with a limited warranty, typically covering manufacturing defects for a period of 2 years. Please refer to the included Warranty Card for specific terms and conditions. A 6-month free exchange/return policy may also apply.

10.2 Customer Support

For technical assistance, troubleshooting, or warranty claims, please contact FUNYET customer support:

- **Email:** funyestore@outlook.com
- **Phone:** +49 800-000-7147 (Available 1:00 PM - 6:00 AM, per business day)
- **Online Support:** Log in to your Amazon account, navigate to 'Your Orders', and select 'Ask Product Question' for the FUNYET NY-14 laptop.

24/7- online instant response



2-year warranty



6-month free exchange/return



per business day phone support
(1:00 PM-6:00 AM)



TEL:

+49 800-000-7147



Email:

funyetstore@outlook.com

Details for customer support, including a 2-year warranty, 6-month free exchange/return, phone support, and email address.



Image of customer service representatives wearing headsets, indicating 24/7 online support availability.