

KRUPS SA402AE0

Krups Coffee Crush Extra Automatic Coffee Machine SA402AE0 User Manual

Model: SA402AE0

1. INTRODUCTION

Thank you for choosing the Krups Coffee Crush Extra automatic coffee machine. This compact and versatile appliance is designed to deliver freshly ground coffee with 15 bars of pressure, allowing you to enjoy a variety of coffee beverages, from espresso to Americano. This manual provides essential information for safe operation, setup, use, and maintenance of your new coffee machine.

2. SAFETY INSTRUCTIONS

- Read all instructions carefully before using the appliance.
- Do not immerse the appliance, power cord, or plug in water or any other liquid.
- Keep the appliance out of reach of children.
- Always unplug the appliance from the power outlet before cleaning or when not in use.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only cold, fresh water in the water tank.
- Never open the brewing unit during operation.
- Avoid contact with hot surfaces.

3. PRODUCT OVERVIEW

The Krups Coffee Crush Extra features a compact design, measuring 29.5P x 15I x 36H cm, making it suitable for various kitchen spaces. It includes an integrated grinder with adjustable settings and an intuitive control panel.



Figure 3.1: Overall view of the Krups Coffee Crush Extra automatic coffee machine.

50% PIÙ COMPATTA

di una macchina da caffè classica

Contentitore del caffè da 150 gr



Figure 3.2: The compact design of the Krups Coffee Crush Extra, shown next to a small dog for scale.

3 VARIETÀ DI CAFFÈ

Espresso, Caffè lungo, Caffè americano



Figure 3.3: Close-up of the intuitive control panel for selecting coffee types and adjusting settings.

4. INITIAL SETUP

1. **Unpacking:** Carefully remove the coffee machine and all accessories from the packaging. Retain packaging for future transport or storage.
2. **Rinsing Components:** Wash the water tank, drip tray, and coffee grounds container with warm soapy water, then rinse thoroughly.
3. **Filling the Water Tank:** Fill the 2-liter water tank with fresh, cold water up to the MAX level. Ensure the tank is properly seated.
4. **Filling the Bean Hopper:** Open the lid of the bean hopper and pour fresh coffee beans into it. The hopper has a capacity of 150g. Close the lid securely.
5. **Initial Rinse Cycle:** Place a container under the coffee spout. Plug in the machine and turn it on. The machine will perform an automatic rinse cycle. Discard the water. Your machine is now ready for use.

5. OPERATION

5.1. Adjusting Grinding Level

The machine features 3 adjustable grinding levels. To change the grinding fineness, rotate the dial located inside the bean hopper. A finer grind (level 1) produces a stronger coffee, while a coarser grind (level 3) results in a milder taste. **Important:** Adjust the grinding level only when the grinder is operating to prevent damage.



Figure 5.1: Filling the bean hopper and the grind adjustment dial.

5.2. Brewing Coffee

The Krups Coffee Crush Extra allows you to prepare Espresso, Lungo, and Americano coffee. Follow these steps:

1. Place a cup under the coffee spout.
2. Select your desired coffee type (Espresso, Lungo, or Filter Coffee/Americano) on the control panel.
3. Adjust the intensity (coffee bean icon), length (cup icon), and temperature (thermometer icon) to your preference. The machine will remember your last settings for each coffee type.

4. Press the 'Start/Stop' button to begin brewing. You can press 'Start/Stop' again to stop brewing at any time.

5.3. Using Pre-Ground Coffee

This machine is also equipped to use pre-ground coffee, ideal for decaffeinated options or different blends. To use pre-ground coffee:

1. Open the dedicated compartment for pre-ground coffee (usually located near the brewing unit).
2. Add one level scoop of pre-ground coffee. Do not overfill.
3. Close the compartment.
4. Select the pre-ground coffee option on the control panel (often indicated by a coffee grounds icon).
5. Press 'Start/Stop' to brew.



Figure 5.4: Adding pre-ground coffee to the machine.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your coffee machine.

- **Daily Cleaning:** After each use, empty and rinse the drip tray and the coffee grounds container. The rapid disposal system for coffee grounds makes this process easy.
- **Water Tank:** Clean the water tank regularly with warm soapy water and rinse thoroughly.
- **Exterior:** Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners.
- **Descaling:** The machine will indicate when descaling is required. Follow the instructions in the full manual (available online) for the descaling procedure using a suitable descaling solution. Regular descaling prevents mineral buildup and maintains coffee quality.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No coffee is dispensed.	Water tank is empty.	Fill the water tank.
Coffee is too weak.	Grinding level is too coarse.	Adjust the grinding level to a finer setting.
Machine not turning on.	Power cord not properly connected.	Check power cord connection and wall outlet.
Error indicator light is on.	Coffee grounds container full or descaling needed.	Empty grounds container or perform descaling cycle. Refer to the full manual for specific error codes.

8. SPECIFICATIONS

Feature	Detail
Brand	KRUPS
Model Number	SA402AE0
Capacity	2 Liters (Water Tank)
Dimensions (DxWxH)	29.5P x 15l x 36H cm
Wattage	1370 Watts
Voltage	220 Volts
Coffee Type Used	Whole Bean, Ground Coffee
Special Features	Pre-ground coffee option, Easy to clean, 15 cm width, Steel grinder, Smart control panel
Operating Mode	Fully Automatic
Country of Origin	China

9. WARRANTY AND SUPPORT

The Krups Coffee Crush Extra (Model SA402AE0) comes with a **2-year product warranty**. For warranty claims, technical support, or to access the full detailed manual, please visit the official KRUPS website or contact your local customer service center. You can also find more information on the [KRUPS Brand Store](#).

10. PRODUCT VIDEO

Your browser does not support the video tag.

Official product video demonstrating the features and operation of the Krups Coffee Crush Extra automatic coffee machine.

© 2023 KRUPS. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question