

Saved from manuals.plus.

Open the live page for links to other documents and user manuals.

[Manuals.plus](#) /

› [Norelco](#) /

› Philips Norelco Shaver 500 Series S591/94 Electric Shaver User Manual

Norelco S591/94

Philips Norelco Shaver 500 Series S591/94 User Manual

Model: S591/94

INTRODUCTION

This manual provides essential information for the safe and effective use of your Philips Norelco Shaver 500 Series, Model S591/94. Please read these instructions carefully before using the appliance and retain them for future reference.



Image: Philips Norelco Shaver 500 Series S591/94, a compact electric shaver.

IMPORTANT SAFETY INFORMATION

Warning: To reduce the risk of electric shock, personal injury, or damage to the appliance, always follow basic safety precautions.

- Do not use the shaver near water while charging.
- Ensure the appliance is fully dry before connecting it to power for charging.
- Keep the appliance away from children.
- Do not disassemble or attempt to repair the shaver yourself. Contact authorized service personnel.
- Only use the provided USB-A cable for charging. A power adapter is not included.

WHAT'S IN THE BOX

Your Philips Norelco Shaver 500 Series package includes the following items:

- 1x Shaver 500 Series (Model S591/94)
- 1x Travel Pouch
- 1x USB-A Cable (power adapter not included)
- 1x Magnetic Cap

What's in the box



✕  Power adapter **not** included

Image: The shaver, travel pouch, USB-A cable, and magnetic cap included in the package.

SETUP AND CHARGING

Initial Charge

Before first use, fully charge your shaver. Connect the provided USB-A cable to the shaver and a compatible USB power adapter (not included). A full charge takes approximately 1 hour and provides up to 40 minutes of shaving time. A 5-minute quick charge provides enough power for one shave.



**SteelPrecision
Blades**



**5 min. quick
charge**



**Travel
Lock**



**40 min.
runtime**



**Powerful,
Magnetic Motor**



**100%
Waterproof**



Image: Visual representation of the shaver's features, including charging time and runtime.

Portability and Travel

The compact design of the Shaver 500 Series makes it ideal for travel. It fits easily into a travel pouch or bag, ensuring you can maintain your grooming routine anywhere.

Designed to perform, wherever you go




Image: The compact shaver being placed into a travel bag, demonstrating its portability.

Activating Travel Lock

To prevent accidental activation during travel, activate the travel lock. Press and hold the power button for 3 seconds until the travel lock indicator illuminates. To deactivate, press and hold the power button again for 3 seconds.

Your browser does not support the video tag.

Video: Demonstrates the features and usage of the Philips Norelco Compact Shaver 500 Series, including activating the travel lock.

OPERATING THE SHAVER

Shaving Technique

For optimal results, move the shaver in small, circular motions across your face. The 3D Floating Heads adapt to your facial contours, ensuring comfortable skin contact even in hard-to-shave areas. The SteelPrecision blades, combined with Lift & Cut technology, gently lift and cut hair at skin level for a close shave.

A close-up photograph of a man with dark, wavy hair and light skin, looking slightly to the left. He is holding a black, compact electric shaver to his chin. The shaver has a power button and three small indicator lights. The background is a soft, out-of-focus grey.

**Close shave
anytime,
anywhere**

Designed to fit
in the palm of
your hand

Image: A man using the compact shaver for a close shave, highlighting its portability.

Skin-close shave

Blades gently lift the hair before shaving at skin-level



SteelPrecision
Blades



Lift & Cut
Technology




Image: Detailed view of the SteelPrecision blades and Lift & Cut Technology for a skin-close shave.

Comfortable shave

Ideal skin contact even
in hard-to-shave areas



3D Floating
Heads



Image: Close-up of the 3D Floating Heads designed for comfortable shaving and optimal skin contact.

Wet and Dry Shave

The Philips Norelco Shaver 500 Series is designed for both wet and dry shaving. You can use it for a comfortable dry shave or with gel or foam for a refreshing wet shave. Its IPX7 water-resistant rating allows for safe use in wet conditions.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and hygiene of your shaver.

Daily Cleaning

After each use, rinse the shaver head under running water. The shaver is 100% waterproof, making cleaning effortless. Simply pop off the shaving head and rinse away any clipped hairs.



Image: The shaver being rinsed under running water, demonstrating its waterproof design for easy cleaning.

Deep Cleaning

Periodically, you may wish to perform a more thorough cleaning. Refer to the full user manual (available on the Philips Norelco website) for detailed instructions on disassembling and reassembling the shaving heads for deep cleaning.

SPECIFICATIONS

Model Number	S591/94
Power Source	Rechargeable Li-ion Battery
Charging Time	1 hour for full charge, 5 minutes for quick charge
Shaving Time	Up to 40 minutes
Blades	SteelPrecision blades with Lift & Cut System
Shaving Heads	3D Floating Heads
Water Resistance	IPX7 (100% waterproof)
Motor	Powerful Magnetic Motor (63,000 cutting actions/minute)
Dimensions	5.67 x 4.92 x 3.39 inches
Weight	13.76 ounces

TROUBLESHOOTING

If you encounter issues with your shaver, please refer to the following common solutions:

- **Shaver not turning on:** Ensure the shaver is charged. Check if the travel lock is activated (deactivate by holding the power button for 3 seconds).
- **Reduced shaving performance:** Clean the shaving heads thoroughly. Blades may need replacement after extended use (typically every 12 months).
- **Charging issues:** Verify the USB-A cable is properly connected to both the shaver and a working power source. Ensure the power adapter (not included) is functional.

- **Skin irritation:** For sensitive skin, try using the shaver with shaving gel or foam for a wet shave. Ensure proper shaving technique (small circular motions, not pressing too hard).

For further assistance, visit the official Philips Norelco support website or contact customer service.

WARRANTY AND SUPPORT

Your Philips Norelco Shaver 500 Series is covered by a manufacturer's warranty. Please refer to the warranty card included in your packaging for specific terms and conditions. For product registration, support, replacement parts, or to view the full user manual, please visit the official Philips Norelco website:

www.philips.com/norelco

You can also find additional information and FAQs on the Philips Norelco store page on Amazon: [Philips Norelco Store](#).

© 2023 Philips Norelco. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0G9BQK387>

More documents and user manuals: <https://manuals.plus/>