Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOMCOM 83B-278V00CG

HOMCOM Modern Accent Chair with Footrest (Model 83B-278V00CG) Instruction Manual

Model: 83B-278V00CG

Important Safety Information

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- **Assembly Required:** This chair requires assembly. Follow the provided instructions carefully to ensure safe and proper assembly.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 265 lbs (120 kg) to maintain stability and prevent damage.
- **Stability:** Ensure all screws are fully tightened before use. Periodically check and re-tighten all fasteners to ensure continued stability.
- **Placement:** Use the chair on a flat, stable surface. Avoid placing it on uneven ground.
- **Children:** Keep small parts and packaging materials away from children during assembly.

Package Contents

Verify that all components are present before beginning assembly.



Image: Components as received in packaging.

- Padded Cushion (1)
- Metal Frame for Cushion (1)
- Wooden Side Frames (2)
- Wooden Crossbars (2)
- Assembly Hardware (Screws, Dowels)

Assembly Instructions

Follow these steps carefully for proper assembly. It is recommended to assemble the chair on a soft, clean surface to prevent scratches.

Step 1: Attach Cushion Frame Sections

Connect the two sections of the metal cushion frame using the provided screws. Ensure the 'Front' label on the fabric aligns correctly.



Image: Connecting the two metal frame sections for the cushion.

Step 2: Prepare Wooden Frame

Insert the wooden dowels into the designated holes on the wooden side frames and crossbars. Connect the crossbars to one of the side frames, securing them with screws. Tighten screws approximately 70% at this stage.



Image: Assembling the wooden frame, showing dowel and screw placement.

Step 3: Complete Wooden Frame Assembly

Attach the second wooden side frame to the assembled crossbars. Fully tighten all screws on the wooden frame once all connections are made.

Step 4: Attach Padded Cushion to Frame

Carefully place the padded cushion onto the assembled wooden frame. Align the pre-drilled holes on the cushion's metal frame with the holes on the wooden frame. Secure the cushion to the wooden frame using the remaining screws.



Image: Securing the padded cushion to the wooden frame.

Assembly Video Guide

For a visual guide, please refer to the assembly video below. This video demonstrates the step-by-step process of putting together your accent chair.

Your browser does not support the video tag.

Video: Step-by-step assembly guide for the HOMCOM Accent Chair.

Operating Instructions

The HOMCOM Modern Accent Chair is designed for comfortable relaxation and reading.

- **Seating:** Sit comfortably in the chair, allowing the high backrest and thick foam seat to provide support.
- **Footrest:** The integrated footrest extends naturally to support your legs, allowing you to stretch out and unwind.
- **Reclining Positions:** This chair offers 5 reclining positions. Adjust the backrest to your desired angle for optimal comfort.



Image: Demonstrating comfortable use of the chair with its footrest.

Maintenance

Proper care will extend the life and appearance of your accent chair.

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the velvet upholstery or wood finish.
- **Spills:** Blot spills immediately with a clean, dry cloth. Do not rub.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading of the upholstery.
- **Inspection:** Periodically inspect all screws and connections to ensure they remain tight. Re-tighten as necessary.



Image: Close-up view of the chair's skin-friendly velvet-feel fabric.

Troubleshooting

If you encounter any issues with your chair, refer to the following common solutions.

- **Chair feels unstable or wobbly:**
  - Ensure all assembly screws are fully tightened.
  - Verify that the chair is placed on a flat, even surface.
  - Check if any wooden dowels were missed during assembly.
- **Back cushion slides down or chair tilts forward:**
  - Ensure the cushion is correctly seated and secured to the frame as per assembly instructions.
  - Verify that the reclining mechanism is properly engaged in your desired position.
  - Confirm that the maximum weight capacity of 265 lbs (120 kg) is not exceeded.
- **Difficulty adjusting reclining positions:**
  - Ensure no obstructions are preventing the mechanism from moving freely.

- Apply gentle, even pressure when adjusting.

Specifications

Feature	Detail
Brand	HOMCOM
Model Number	83B-278V00CG
Overall Dimensions (W x D x H)	26.4" W x 44.9" D x 41.3" H (67 x 114 x 105 cm)
Weight Capacity	265 lbs (120 kg)
Material	Velvet (Upholstery), Birch Wood (Frame), Foam (Fill)
Color	Dark Grey
Back Style	Solid Back
Special Features	Foot Rest, High Back, Upholstered, 5 Reclining Positions
Assembly Required	Yes
Product Care	Wipe Clean



Image: Detailed product dimensions.

Warranty Information

This HOMCOM Accent Chair comes with a **90 Day Warranty Against Manufacturer Defects**. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear. Please retain your proof of purchase for warranty claims.

Customer Support

For any questions, concerns, or assistance with your HOMCOM Accent Chair, please contact our customer support team:

- **Manufacturer:** Aosom Canada
- **Phone:** 1-416-792-6088
- **Location:** Markham, Ontario, CA

Please have your model number (83B-278V00CG) and proof of purchase ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GBWNZ576

More documents and user manuals: **https://manuals.plus/**