Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GDOR TB-8008-3

GDOR 1200W Smoothie Blender User Manual

Model: TB-8008-3

Introduction

Thank you for choosing the GDOR 1200W Smoothie Blender. This professional blender features a powerful 1200W motor, a durable 52oz glass jar, and a convenient 24oz to-go cup. Equipped with 6-leaf and 4-leaf stainless steel blades, it is designed to efficiently blend ice cubes, frozen fruits, and create smooth shakes. This manual provides essential information for safe operation, maintenance, and optimal use of your new appliance.



Image: The GDOR 1200W Smoothie Blender, highlighting its design and capabilities.

Important Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before using the appliance.
- Do not immerse the motor base in water or other liquids.
- Unplug from outlet when not in use, before assembling or disassembling parts, and before cleaning.

- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Keep hands and utensils out of container while blending to prevent the possibility of severe injury to persons or damage to the blender. A scraper may be used but only when the blender is not running.
- Blades are sharp. Handle with care.
- Always operate blender with lid in place.
- Do not blend hot liquids in the portable cup.

Package Contents

Your GDOR Smoothie Blender package includes the following items:

- Blender Motor Base
- 52oz Glass Jar
- 6-leaf Stainless Steel Blade Assembly (for Glass Jar)
- 24oz Portable To-Go Cup
- 4-leaf Stainless Steel Blade Assembly (for Portable Cup)
- Lid for Glass Jar
- Leak-proof Lid for Portable Cup



Image: All included components of the GDOR Smoothie Blender, including the motor base, glass jar, portable cup, and blade assemblies.

Product Features

- **Powerful 1200W Motor:** Crushes frozen fruits and ice cubes quickly for smooth results.
- **5 Intelligent Programs:** Dedicated settings for Extract, Milkshake, Smoothies, Ice Crush, and Pulse.
- **52oz Glass Jar:** Durable and large capacity for family use, featuring a 6-leaf stainless steel blade.
- **24oz Single-serve To-Go Cup:** Ideal for individual portions, with a 4-leaf blade and leak-proof lid.
- **Self-Cleaning Function:** Utilizes the 'Extract' mode for easy cleaning with soapy water.



Image: Illustration of the 1200W motor and multi-blade system, emphasizing power and quality.




Image: Comparison of the 6-blade assembly with the glass jar and the 4-blade assembly with the portable cup.

Setup

1. Unpack all components and remove any packaging materials.
2. Wash the glass jar, portable cup, lids, and blade assemblies with warm, soapy water before first use. Rinse thoroughly and dry.
3. Place the motor base on a clean, dry, and stable surface.
4. **For Glass Jar:** Place the 6-leaf blade assembly onto the motor base, then align the 52oz glass jar onto the blade assembly and twist clockwise until securely locked.
5. **For Portable Cup:** Place the 4-leaf blade assembly onto the motor base, then align the 24oz portable cup onto the blade assembly and twist clockwise until securely locked.
6. Ensure the jar or cup is properly seated and locked onto the motor base before plugging in the appliance.

Operating Instructions

The GDOR Smoothie Blender features a touch control panel with 5 smart programs and a Pulse function.




Image: Close-up of the blender's control panel showing the 'Start/Stop', 'Pulse', and five smart program buttons: 'Extract', 'Milkshake', 'Smoothies', 'Ice Crush'.

1. Add ingredients to the glass jar or portable cup. Do not exceed the MAX fill line.
2. Securely attach the appropriate lid. For the glass jar, ensure the lid is firmly in place. For the portable cup, ensure the blade assembly is tightly screwed on.
3. Place the jar/cup assembly onto the motor base and twist clockwise until it clicks into a locked position. The blender will not operate unless properly locked.
4. Plug the power cord into a standard electrical outlet.
5. Select your desired program by touching the corresponding icon on the control panel:
    - **Extract:** For nutrient extraction, typically runs for 90 seconds.
    - **Milkshake:** Optimized for milkshakes, runs for 70 seconds.
    - **Smoothies:** Perfect for fruit smoothies, runs for 60 seconds.
    - **Ice Crush:** Specifically designed for crushing ice, runs for 40 seconds.
6. Alternatively, use the **Pulse** function for manual control and quick bursts of blending. Press and hold the 'Pulse' button for continuous blending, release to stop.
7. Press the **Start/Stop** button to begin or end a program.
8. Once blending is complete, unplug the blender from the outlet.
9. Carefully remove the jar/cup assembly by twisting counter-clockwise.
10. Remove the lid or blade assembly and pour your blended creation.

Your browser does not support the video tag.

Video: An official GDOR video demonstrating the blender in use, showcasing its power and various functions.

Cleaning and Maintenance

Proper cleaning ensures the longevity and hygiene of your blender.

1. **Self-Cleaning Function:** For quick and easy cleaning, add warm water and a drop of dish soap to the jar/cup. Secure the lid and place it on the motor base. Select the 'Extract' program and let it run. Rinse thoroughly afterward.
2. **Manual Cleaning:** For a more thorough clean, disassemble the jar/cup and blade assemblies. Wash all removable parts with warm, soapy water. Use a brush to clean around the blades carefully. Rinse thoroughly and allow to air

dry.

3. **Motor Base:** Wipe the motor base with a damp cloth. Never immerse the motor base in water or any other liquid.
4. Store the blender in a dry place.



Image: The blender's self-cleaning function in action, showing water swirling inside the glass jar.

Troubleshooting

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; Jar/cup not securely locked; Power outage.	Ensure power cord is plugged in. Twist jar/cup clockwise until it clicks into place. Check power supply.
Ingredients are not blending smoothly.	Too little liquid; Too many ingredients; Ingredients are too large.	Add more liquid. Reduce ingredient quantity. Cut ingredients into smaller pieces. Use Pulse function for stubborn ingredients.
Blender stops during operation.	Overheating; Overload.	Unplug and let cool for 15-20 minutes. Reduce ingredients or add more liquid.
Leakage from the jar/cup.	Lid not properly sealed; Blade assembly not tightened.	Ensure lid is securely fastened. Tighten blade assembly onto the cup/jar. Do not overfill.

Specifications

Feature	Detail
Brand	GDOR
Model Number	TB-8008-3
Power	1200 Watts
Voltage	120 Volts
Large Jar Capacity	52 oz (Glass)

Feature	Detail
Portable Cup Capacity	24 oz
Blade Material	Stainless Steel (6-leaf and 4-leaf)
Control Type	Touch
Product Dimensions (Blender with 52oz Jar)	5.7"D x 5.9"W x 15.75"H
Item Weight	7.8 pounds
Material	Glass (Jar), BPA Free (Portable Cup)



Image: Diagram showing the dimensions of the GDOR Blender with both the glass jar and the portable cup.

Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your product or visit the official GDOR website. You may also contact GDOR customer service directly for assistance with product operation, troubleshooting, or parts replacement.

For additional resources and product information, visit theGDOR Store on Amazon.

© 2026 GDOR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GC4NPHRL

More documents and user manuals: **https://manuals.plus/**