

[Manuals.plus](#) /

› [WOLFBOX](#) /

› WOLFBOX Electric Air Duster MF 50 User Manual

WOLFBOX MF 50

WOLFBOX Electric Air Duster MF 50 User Manual

Model: MF 50

1. INTRODUCTION

Thank you for purchasing the WOLFBOX Electric Air Duster MF 50. This device is designed for efficient dust removal from electronics, keyboards, car interiors, and other hard-to-reach areas. Please read this manual thoroughly before using the product to ensure safe and optimal performance. Keep this manual for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

WARNING: To reduce the risk of fire, electric shock, or injury, please observe the following safety precautions:

- Do not immerse the device in water or other liquids.
- Do not operate the device with wet hands.
- Keep the device away from heat sources, direct sunlight, and flammable materials.
- Do not point the air duster directly at eyes, ears, or other body parts.
- Keep out of reach of children. This device is not a toy.
- Do not block the air intake or outlet during operation.
- Use only the provided USB-C cable for charging.
- Do not attempt to disassemble, repair, or modify the device. Contact customer support if service is required.
- Store the device in a cool, dry place when not in use.

3. PRODUCT OVERVIEW

3.1 Package Contents

- WOLFBOX Electric Air Duster MF 50 Main Unit
- Flat Diffusion Nozzle
- Inflation Nozzle
- Slim Nozzle
- Universal Round Nozzle
- USB Type-C Charging Cable
- User Manual

3.2 Device Components



Image: The WOLFBOX Electric Air Duster MF 50, showcasing its compact design and nozzle attachment point.

The WOLFBOX MF 50 features a powerful motor, a comfortable grip, LED indicators for battery and speed, and a USB-C charging port. Nozzles are easily interchangeable for various cleaning tasks.

3.3 Key Features

- **High-Speed Motor:** Equipped with a brushless motor reaching up to 110,000 RPM.
- **Powerful Airflow:** Delivers a maximum wind speed of over 75m/s for effective dust removal.
- **Long Battery Life:** Built-in 5000mAh battery provides up to 240 minutes of continuous use on the lowest setting.
- **Lightweight Design:** Weighs approximately 204g for comfortable, single-handed operation.
- **Versatile Nozzles:** Includes 4 specialized nozzles for different applications (PC, keyboard, car, inflation).
- **USB-C Charging:** Convenient and flexible charging via USB Type-C.

- **3-Speed Adjustment:** Easily switch between low, medium, and high wind speeds.

4. GETTING STARTED

4.1 Charging the Device

1台多役

シーンに合わせて自由に切り替える


軽いホコリの清掃や心地よい扇風機として活躍



弱風
モード: **11m/s**



キーボードの隙間、ペットの抜け毛
車内の隅々まで
掃除機が届かない場所の汚れを一掃



強風
モード: **30m/s**

洗車後の水滴飛ばしや、冬の除雪に
あらゆるホコリを一瞬で吹き飛ばす



暴風
モード: **≥75m/s**



Image: Illustration of the internal battery and various USB-C charging options, including wall adapter, power bank, and laptop.

1. Before first use, fully charge the air duster.

2. Connect the provided USB Type-C cable to the charging port on the device.
3. Plug the other end of the USB cable into a compatible USB power source (e.g., AC adapter, computer USB port, power bank).
4. The LED indicators will show charging status. A full charge typically takes about 3 hours.
5. Once fully charged, disconnect the charging cable.

4.2 Attaching Nozzles

2026NEWモデル

日本
初上陸

エアダスターの常識を覆す!

ホコリや水を一瞬で吹き飛ばそう



**便利**
USB充電対応

**強力**
モーター

**一台多役**

**95%**
省エネ設計

**3段階**
風速調節

**5000 mAh**
大容量バッテリー

**≥75m/s**業務用
レベルの強力送風

**最大240 min**
連続使用

Image: The four included nozzles: Flat Diffusion, Inflation, Slim, and Universal Round, ready for attachment.

Select the appropriate nozzle for your cleaning task:

- **Flat Diffusion Nozzle:** Ideal for cleaning larger surfaces like keyboards and PC cases.
- **Inflation Nozzle:** For inflating air beds, air mats, and similar items.
- **Slim Nozzle:** Perfect for reaching narrow gaps and tight spaces.
- **Universal Round Nozzle:** Suitable for general cleaning, snow removal, and water droplet removal.

To attach a nozzle, align it with the air outlet and push firmly until it clicks into place. To remove, gently pull the nozzle off.

5. OPERATION

5.1 Power On/Off

Press and hold the power button for a few seconds to turn the device on. Press and hold again to turn it off.

5.2 Adjusting Wind Speed



Image: Visual representation of the three wind speed modes: Weak (11m/s), Strong (30m/s), and Storm (≥ 75 m/s), with corresponding usage examples.

The WOLFBOX MF 50 has three adjustable wind speeds:

1. **Low Speed (Weak Mode):** Press the power button once after turning on. Ideal for light dust and delicate surfaces.
2. **Medium Speed (Strong Mode):** Press the power button a second time. Suitable for general cleaning and moderate dust.
3. **High Speed (Storm Mode):** Press the power button a third time. For heavy-duty cleaning and stubborn debris.

The LED indicators will show the current speed setting.

5.3 Using the Nozzles



Image: Demonstrates the use of each nozzle type: Flat Diffusion for keyboards, Inflation for air beds, Slim for window crevices, and Universal Round for car snow/water removal.

Once the desired nozzle is attached and the device is powered on, direct the airflow towards the area to be cleaned. Adjust the speed as needed. For optimal results, hold the device a few inches away from the surface.

6. MAINTENANCE AND CARE

- **Cleaning the Device:** Wipe the exterior of the air duster with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Nozzle Cleaning:** Nozzles can be cleaned with a damp cloth and allowed to air dry completely before reattaching.
- **Storage:** Store the device and its accessories in a clean, dry place, away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the device frequently. Charge it regularly, even if not used for extended periods.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on	Battery is depleted	Charge the device fully.
Weak airflow	Low battery; Air intake/outlet blocked	Charge the device; Ensure air intake/outlet are clear.
Device not charging	Faulty cable or power source	Try a different USB-C cable or power adapter. Ensure connections are secure.
Unusual noise or vibration	Internal obstruction or damage	Stop using the device immediately and contact customer support.

8. SPECIFICATIONS

Feature	Specification
---------	---------------

Feature	Specification
Brand	WOLFBOX
Model	MF 50
Motor Speed	Up to 110,000 RPM
Max Wind Speed	≥75m/s
Battery Capacity	5000mAh
Continuous Use Time	Up to 240 minutes (low speed)
Weight	Approx. 204g
Charging Port	USB Type-C
Charging Time	Approx. 3 hours
Nozzles Included	4 types
Country of Origin	China

9. WARRANTY AND CUSTOMER SUPPORT

専用収納バッグは別売り



Image: Information regarding WOLFBOX's 2-year warranty and a warning about counterfeit products.

9.1 Manufacturer's Warranty

WOLFBOX provides a **24-month manufacturer's warranty** from the date of purchase. In case of product defects or malfunctions within the warranty period, WOLFBOX offers a new product exchange rather than repair. This warranty covers manufacturing defects and normal use.

9.2 Customer Support

For any questions regarding product usage, troubleshooting, or warranty claims, please contact WOLFBOX customer support. You can typically reach support through the seller contact option on the product's purchase page. Please have your order details ready when contacting support.

Note: Please ensure you purchase genuine WOLFBOX products to be eligible for warranty and support. Be aware of counterfeit products on the market.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GC4TJDXL>

More documents and user manuals: <https://manuals.plus/>