

- Manuals.plus /
- › ZOVIMAX /
- › ZOVIMAX X7 MAX Bone Conduction Headphones User Manual

ZOVIMAX X7 MAX

ZOVIMAX X7 MAX Bone Conduction Headphones

User Instruction Manual

INTRODUCTION

The ZOVIMAX X7 MAX Bone Conduction Headphones offer a versatile audio experience with both MP3 and Bluetooth capabilities. Designed for durability and performance in various environments, these headphones feature an IP68 waterproof rating, military-grade construction, and an open-ear design for situational awareness. This manual provides essential information for the proper setup, operation, and maintenance of your device.

WHAT'S IN THE BOX

Packaging and Size



Packaging box



Instruction manual



Adjustable cord



Charging cable



Weight and Dimensions



Image: Packaging and contents of the ZOVIMAX X7 MAX headphones. This image displays the retail box, the bone conduction headphones, a magnetic charging cable, an adjustable cable, and the instruction manual.

- ZOVIMAX X7 MAX Bone Conduction Headphones (1 unit)
- Magnetic Charging Cable (1 unit)
- Adjustable Cable (1 unit)
- Instruction Manual (1 unit)


Dual Mode: MP3 Player & Bluetooth 6.0

MP3-Player & Bluetooth 6.0 Dual Modes



MP3 Mode

- 32GB Larger Storage Memory Card
- Supports Download up to 8000 Songs
- Adapt to any Extreme Environment



Bluetooth Mode

- Bluetooth V6.0 for Seamless, Lag-Free Gaming
- Game-ready Performance with Ultra-Low Latency, 15M(50FT) Stable Range and Strong Anti-Interference

Image: This image illustrates the dual functionality of the headphones, showing internal components for MP3 playback and a phone screen demonstrating Bluetooth connectivity. The headphones support 32GB internal storage for MP3s and Bluetooth 6.0 for wireless connection.

- **MP3 Mode:** Features 32GB of integrated memory, capable of storing up to 8,000 songs. Ideal for use in

environments where Bluetooth is not available or suitable, such as underwater.

- **Bluetooth 6.0 Mode:** Provides stable and low-latency wireless connectivity for streaming music and calls on land.

Note: Bluetooth functionality is limited or non-existent underwater; use MP3 mode for swimming.

IP68 Waterproof Rating



IPX8 Waterproof for Swim

Supports 5m deep submersion for up to 2.5 hours

Note: Use MP3 mode for swimming as water blocks Bluetooth

Image: A swimmer wearing the ZOVIMAX X7 MAX headphones, demonstrating their IP68 waterproof rating. The headphones are designed for submersion up to 5 meters for 2.5 hours, specifically for MP3 audio playback during swimming.

The X7 MAX headphones are rated IP68, indicating resistance to dust and water. They can be submerged up to 5 meters (16.4 feet) for 2.5 hours, making them suitable for swimming and other water sports. For underwater use, the MP3 mode must be activated as Bluetooth signals do not transmit effectively through water.

Military-Grade Durability



MILITARY STANDARD D.I.N.



-40C-70°C
Temperature test



Anti-fulid
corrosion



Dust-proof



Anti- impact

Image: This collage shows individuals using the ZOVIMAX X7 MAX headphones during hiking, running, swimming, and cycling, highlighting their versatility. Below, icons represent military-grade standards for temperature resistance (-40°C to 70°C), anti-fluid corrosion, dust-proofing (IP68), and anti-impact features.

Constructed to D.I.N. military standards, the X7 MAX headphones are designed for extreme durability. They are tested to withstand temperatures from -40°C to 70°C, resist liquids and corrosion, are dustproof (IP68), and shock-resistant, ensuring reliable performance in demanding conditions.

Open-Ear Comfort and Situational Awareness



Listen to Music, Yet Hear the Traffic

Maintain situational awareness
during outdoor activities

Image: A person cycling while wearing the ZOVIMAX X7 MAX headphones, illustrating the open-ear design that allows the user to hear both music and ambient sounds like traffic, enhancing safety during outdoor activities.

The open-ear design ensures comfort during extended wear and allows users to remain aware of their surroundings, which is crucial for safety during outdoor activities like running, cycling, or hiking. The ergonomic design provides a secure fit, compatible with swim caps, goggles, or helmets.

Battery Life and Charging

Wind-Resistant Mics



Quick Charge

Get 2.5 hours of playtime
in 5 minutes

Professional Rapid Charging Cable

Waterproof port



Optimised Physical Button

Conqu to Prevent Accidental
Contact



Longer Playtime

Up to 12 hours of playtime

Image: This image highlights key features of the ZOVIMAX X7 MAX headphones, including wind-resistant microphones, quick charging capability (2.5 hours playtime in 5 minutes), a professional rapid charging cable with a waterproof port, optimized physical buttons to prevent accidental contact, and a total playtime of up to 12 hours.

The X7 MAX offers up to 12 hours of music playback and call time on a full charge. A quick 10-minute charge provides approximately 3 hours of listening time. The headphones utilize a magnetic charging cable for convenience and water resistance.

SETUP

1. Charging the Headphones

1. Connect the magnetic charging cable to the charging port on the headphones.
2. Connect the USB end of the cable to a standard USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show charging status. A full charge takes approximately 1.5-2 hours.
4. For quick charge, 10 minutes of charging provides about 3 hours of playback.

2. Powering On/Off

- **Power On:** Press and hold the Power button for 3 seconds until the LED indicator flashes.
- **Power Off:** Press and hold the Power button for 3 seconds until the LED indicator turns off.

3. Bluetooth Pairing (for use on land)

1. Ensure the headphones are powered off.
2. Press and hold the Power button for 5-7 seconds until the LED indicator flashes red and blue alternately, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "X7 MAX" from the list of devices.
5. Once paired, the LED indicator will flash blue periodically.

4. MP3 Mode Usage (for use in water or without a connected device)

1. **Transferring Music:**
 - Connect the headphones to your computer using the magnetic charging cable.
 - The headphones will appear as a removable disk drive.
 - Drag and drop your MP3 audio files into the headphone's storage folder.
 - Safely eject the device from your computer before disconnecting.
2. **Switching to MP3 Mode:** While the headphones are on, press the Mode button (refer to button layout in Operating Instructions) to switch between Bluetooth and MP3 modes. The headphones will indicate the current mode.

OPERATING INSTRUCTIONS

Button Functions

The ZOVIMAX X7 MAX headphones feature optimized physical buttons to prevent accidental contact during activities.

Button/Action	Function
Power Button (Long Press 3s)	Power On/Off
Power Button (Short Press)	Play/Pause music, Answer/End call

Button/Action	Function
Volume Up (+) Button (Short Press)	Increase Volume
Volume Down (-) Button (Short Press)	Decrease Volume
Volume Up (+) Button (Long Press)	Next Track
Volume Down (-) Button (Long Press)	Previous Track
Mode Button (Short Press)	Switch between Bluetooth Mode and MP3 Mode
Power Button (Double Press)	Redial last number (in Bluetooth mode)

Making and Receiving Calls (Bluetooth Mode Only)

- **Answer Call:** Short press the Power button.
- **End Call:** Short press the Power button during a call.
- **Reject Call:** Long press the Power button when an incoming call rings.
- **Redial:** Double press the Power button to redial the last number.

MAINTENANCE

- **Cleaning:** Wipe the headphones with a soft, damp cloth after each use, especially after exposure to sweat, chlorine, or saltwater. Ensure the charging contacts are clean and dry before charging.
- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Resistance:** While IP68 rated, avoid prolonged submersion beyond specified limits. Always ensure the charging port is dry before connecting the magnetic cable to prevent corrosion.
- **Battery Care:** To prolong battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not in use for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones for at least 10 minutes.
Cannot pair via Bluetooth.	Headphones not in pairing mode; device Bluetooth off; too far from device.	Ensure headphones are in pairing mode (red/blue flashing LED). Turn on Bluetooth on your device. Move closer to your device (within 15 meters/50 feet).
No sound or poor sound quality.	Volume too low; incorrect mode; audio source issue.	Increase volume. Ensure correct mode (Bluetooth or MP3). Check audio source. For bone conduction, ensure transducers are correctly placed on cheekbones.
Bluetooth does not work underwater.	Bluetooth signals do not transmit through water.	Switch to MP3 mode for underwater listening. Ensure music files are loaded onto the internal 32GB memory.

Problem	Possible Cause	Solution
Short battery life.	Battery degradation; frequent high volume use.	Ensure full charge. Reduce volume. If battery life significantly degrades over time, contact support.
Crackling or static during calls/music.	Interference; weak Bluetooth signal; faulty unit.	Move away from sources of interference. Ensure device is close. If problem persists, try resetting headphones or contact support.

SPECIFICATIONS

Feature	Detail
Brand	ZOVIMAX
Model Name	X7 MAX
Color	Matte Black
Ear Placement	Open Ear
Form Factor	Neckband
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth 6.0
Impedance	20 Ohms
Noise Control	Environmental Noise Cancellation
Water Resistance Level	IP68 (Waterproof)
Internal Memory	32GB (for MP3 mode)
Battery Life (Average)	Up to 12 hours
Charging Time	Approx. 1.5-2 hours (10 min for 3 hours playback)
Control Type	Button Control
Compatible Devices	Phone, Tablet, Computer, Car Audio System
Special Features	MP3 + Bluetooth, Military D.I.N. Standard, IP68 Waterproof, Open-Ear Design, 12h Battery Life

WARRANTY AND SUPPORT

The ZOVIMAX X7 MAX Bone Conduction Headphones come with a **2-year warranty**. This warranty covers manufacturing defects and ensures the quality of our product. If you encounter any issues during this period, please contact our customer support for assistance. We are committed to resolving any problems promptly. For further support or inquiries, please refer to the contact information provided on the ZOVIMAX official website or your purchase documentation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GC5N9YMF>

More documents and user manuals: <https://manuals.plus/>