



[Manuals.plus](#) /

› [LAUSAINT HOME](#) /

› LAUSAINT HOME 10'x20' Outdoor Patio Gazebo Instruction Manual

LAUSAINT HOME 10'x20' Outdoor Patio Gazebo

LAUSAINT HOME 10'x20' Outdoor Patio Gazebo

INSTRUCTION MANUAL

Introduction

Thank you for choosing the LAUSAINT HOME 10'x20' Outdoor Patio Gazebo. This heavy-duty gazebo is designed to provide a comfortable and protected outdoor space with its double roofs, mosquito nettings, and privacy screens. This manual contains important information regarding the assembly, safe operation, and maintenance of your gazebo. Please read it thoroughly before assembly and retain it for future reference.



Image: The LAUSAIN HOME 10'x20' Outdoor Patio Gazebo with its curtains open, providing a shaded area next to a swimming pool.

Safety Information


Important Safety Precautions:

- Always anchor the gazebo firmly using ground stakes or expansion bolts when setting it up.
- For windy weather, close or remove the curtains and netting to reduce wind resistance.
- If severe weather conditions occur, including strong winds, heavy rain, blizzards, or extreme winds, take down the gazebo completely to avoid potential damage to the structure and surrounding property.
- Do not hang heavy objects from the center ceiling hook or any part of the frame.
- Keep all flame and heat sources away from the gazebo fabric.

Package Contents

Before beginning assembly, ensure all parts listed below are present and undamaged. The product is delivered in two separate packages.

Product Dimension



Package Details



The product will delivered in **2** separate packages.

Image: Diagram illustrating the dimensions of the 10'x20' gazebo, including height and width measurements.

- Galvanized Steel Frame Components (various poles, connectors, and base plates)
- Main Canopy Fabric (1500MM waterproof polyester)
- Small Top Canopy Fabric (for double roof ventilation)
- Waterproof Privacy Curtains (with Velcro straps)
- Zippered Mosquito Netting
- Expansion Bolts (12 pieces for concrete/deck anchoring)
- Ground Stakes (12 pieces for grass anchoring)
- Wind-Resistant Ropes (4 pieces)
- Assembly Hardware (screws, washers, nuts, tools)

Package includes expansion bolts

12pcs expansion bolts, 12pcs stakes, 4pcs ropes




Image: A close-up view of the gazebo's base plate, showing the included expansion bolts, stakes, and ropes for secure installation.

Assembly Instructions

Assembly typically requires two people and can take approximately 2-4 hours. Follow the diagrams provided in your physical instruction manual carefully. Do not overtighten bolts until the entire frame is assembled.

- 1. Frame Assembly:** Begin by assembling the base frame according to the diagrams. Connect the horizontal and vertical poles using the provided connectors and hardware. Ensure all connections are secure but allow for slight adjustments until the full frame is upright.
- 2. Roof Structure Assembly:** Attach the roof support beams to the main frame. The double-tier roof design allows for improved airflow.
- 3. Canopy Installation:** Carefully spread the main canopy fabric over the roof structure. Ensure the fabric is correctly oriented and secured to the frame. Install the smaller top canopy, ensuring the mesh between the tiers is properly positioned for ventilation and insect deterrence.
- 4. Curtains and Netting Installation:** Hang the privacy curtains and mosquito netting onto the dual-track system. The dual-track allows for independent operation of the curtains and netting. Utilize the zipper design for a snug fit and to prevent gaps.
- 5. Anchoring the Gazebo:** For maximum stability, secure the gazebo to the ground. Use the provided expansion bolts for concrete or wooden decks, or ground stakes and wind-resistant ropes for grass or soft ground. Ensure all anchoring points are tight and stable.



Vented Double Roofs

Added nettings between the roofs for circulating air and repelling mosquitoes

Image: A close-up view of the gazebo's vented double roof, highlighting the mesh layer that promotes airflow and helps repel mosquitoes.



Dual-Track

The curtains and nettings can be operated separately

Image: The dual-track system, allowing curtains and netting to be operated independently for flexible use.

Operating Instructions

Your gazebo is designed for versatile outdoor use. Here's how to maximize its features:

- **Curtains and Netting:** Slide the privacy curtains for shade and privacy, or use the zippered mosquito netting to keep insects out while maintaining airflow. The dual-track system allows you to use them together or separately.
- **Securing Curtains:** Use the integrated Velcro straps to tie back the curtains when not in use, keeping your space open and tidy.
- **Hanging Hook:** A center ceiling hook is provided for hanging lightweight items such as decorative lights or small fans. Do not exceed the weight limit specified in your detailed manual.
- **Corner Rings:** Utilize the corner rings for attaching string lights, wind chimes, or other decorations.



Image: The gazebo with its privacy curtains fully closed, offering a secluded and shaded area next to a pool.



Velcro Straps

Easy to organize curtains and nettings



Image: Detail of the Velcro straps used to neatly organize and secure the gazebo's curtains when pulled back.

Maintenance

Proper maintenance will extend the lifespan of your gazebo:

- **Cleaning:** Clean the canopy fabric and netting with mild soap and water. Rinse thoroughly and allow to air dry completely before storage or prolonged closure. Avoid harsh chemicals or abrasive cleaners.
- **Frame Care:** Periodically inspect the galvanized steel frame for any signs of rust or damage. Clean the frame with a damp cloth.
- **Seasonal Storage:** During off-seasons or anticipated severe weather (heavy snow, strong winds), it is recommended to remove the canopy, curtains, and netting. Store them in a dry, protected area to prevent damage and prolong their life.
- **Anchoring Check:** Regularly check all ground stakes, expansion bolts, and ropes to ensure they remain securely fastened. Retighten any loose connections.

Water Leakage Holes

Prevents top water from collapsing
Increase structural stability



Image: Detail of the water leakage holes on the canopy, designed to prevent water accumulation and increase structural stability.

Troubleshooting

| Problem | Possible Cause | Solution |
|---------------------------------------|--|--|
| Water pooling on roof | Insufficient tension in canopy fabric; drainage holes blocked. | Ensure canopy is tautly installed. Clear any debris from drainage holes. |
| Gazebo unstable in wind | Improper anchoring; curtains/netting left open. | Verify all expansion bolts, stakes, and ropes are securely fastened. Close or remove curtains and netting during windy conditions. |
| Difficulty assembling frame | Parts misaligned; bolts overtightened prematurely. | Ensure all parts are correctly oriented before tightening. Do not fully tighten bolts until the entire section is assembled. Refer to the detailed diagrams. |
| Curtains/netting not sliding smoothly | Debris in tracks; damaged runners. | Clean the dual tracks of any dirt or obstructions. Inspect runners for damage. |

Specifications

- **Brand:** LAUSAINT HOME
- **Model:** 10'x20' Outdoor Patio Gazebo
- **Color:** Cream White
- **Material:** Galvanized Steel Frame, Polyester Canopy Fabric
- **Product Dimensions (L x W x H):** 236.2" x 110.6" x 110.6" (19.7 ft x 9.2 ft x 9.2 ft)
- **Item Weight:** 78.5 Pounds
- **Water Resistance Level:** Water Resistant (1500MM)
- **Ultraviolet Light Protection:** UV 50+
- **Shape:** Rectangular

Warranty and Support

This product is typically covered by a 30-day return policy. For specific warranty details, product support, or replacement parts, please contact the seller, YIZE-US, directly through your purchase platform. Ensure you have your order information and product model number available when contacting support.