



[Manuals.plus](#) /

› [LAUSAINT HOME](#) /

› LAUSAINT HOME 10'x20' Outdoor Patio Gazebo Instruction Manual

LAUSAINT HOME 10'x20' Outdoor Patio Gazebo

LAUSAINT HOME 10'x20' Outdoor Patio Gazebo Instruction Manual

Model: 10'x20' Outdoor Patio Gazebo

Brand: LAUSAINT HOME

INTRODUCTION

This manual provides essential instructions for the assembly, operation, and maintenance of your LAUSAINT HOME 10'x20' Outdoor Patio Gazebo. This heavy-duty gazebo is designed for outdoor use, featuring a galvanized steel frame, double roofs for ventilation, and integrated mosquito nettings and privacy screens. Please read these instructions thoroughly before beginning assembly or use to ensure proper setup and longevity of your product.



The LAUSAINT HOME 10'x20' Outdoor Patio Gazebo provides a spacious shaded area for outdoor activities.



The gazebo with privacy curtains closed, providing an enclosed space.

SAFETY INFORMATION

Always anchor the gazebo firmly using ground stakes or expansion bolts when setting it up. For windy weather, close or remove the curtains and netting. If severe conditions occur, including storms, heavy rain, blizzards, or extreme winds, take down the gazebo completely to avoid potential damage. Failure to follow these safety guidelines may result in product damage or personal injury.


PACKAGE CONTENTS

Before assembly, ensure all components are present and undamaged. The package typically includes:

- Galvanized Steel Frame Components
- Main Canopy Fabric
- Upper Canopy Fabric

- Mosquito Netting Panels
- Privacy Curtain Panels
- Expansion Bolts (12 pcs)
- Ground Stakes (12 pcs)
- Wind-resistant Ropes (4 pcs)
- Assembly Hardware (screws, nuts, washers, tools)

Product Dimension



Package Details



The product will delivered in **2** separate packages.

Product dimensions and package details. The gazebo is delivered in two separate packages.

SETUP AND ASSEMBLY

Assembly typically requires two people and approximately 3-4 hours. Follow the numbered and lettered diagrams provided in the separate assembly guide for detailed steps. Ensure all connections are secure before proceeding to the next step.

1. **Frame Assembly:** Begin by assembling the main galvanized steel frame components. Ensure all reinforced support beams are correctly oriented and securely fastened.

2. **Roof Structure:** Construct the double-tier roof frame, paying attention to the upper and lower sections.
3. **Canopy Installation:** Carefully place the main canopy fabric over the assembled roof frame. Then, install the smaller upper canopy. Ensure the fabric is taut and evenly distributed.
4. **Curtains and Netting:** Attach the mosquito netting and privacy curtains to the dual-track system on the frame. Ensure zippers are functional and panels can move freely.
5. **Anchoring:** Secure the gazebo to the ground using the provided expansion bolts for concrete/wood surfaces or ground stakes and wind-resistant ropes for grass. This step is crucial for stability, especially in varying weather conditions.

Package includes expansion bolts

12pcs expansion bolts, 12pcs stakes, 4pcs ropes



The package includes expansion bolts, stakes, and ropes for secure anchoring.



Convenient Elastic Buckles



Thickened square tube frame



The gazebo features a thickened square tube frame for enhanced durability.



Wind-resistant Ropes

Make your gazebo more stable

Wind-resistant ropes are included to enhance gazebo stability.


OPERATING INSTRUCTIONS

Your gazebo is designed for comfort and versatility in various outdoor settings.

- **Double-Tier Roof:** The double-top roof design facilitates improved airflow, allowing hot air to escape and creating a cooler environment. The integrated mesh between roof tiers helps deter insects while maintaining ventilation.
- **Mosquito Netting and Privacy Curtains:** Utilize the dual-track system to operate the mosquito netting and privacy curtains independently. The netting provides insect protection, while the curtains offer shade and privacy. Both feature zippers for full enclosure and elastic buckles for securing them when open.
- **Hanging Hook and D-Rings:** A central ceiling hook is provided for hanging lights, fans, or decorative items. Additional D-rings on the frame offer convenient attachment points for string lights or other accessories.
- **Water Drainage:** The canopy is equipped with side drainage holes to prevent rainwater accumulation and improve structural stability.

Double roof with nettings

Keeping good air flows and repel mosquitos



The double roof with nettings promotes airflow and helps repel mosquitoes.

Water Leakage Holes

Prevents top water from collapsing
Increase structural stability



Water leakage holes prevent water from pooling on the roof, enhancing stability.



Dual-Track

The curtains and nettings can be operated separately


The dual-track system allows separate operation of curtains and nettings.



Zippers

Both the curtains and nettings have zippers

Both curtains and nettings are equipped with zippers for complete closure.




Convenient elastic buckles are used to secure curtains and nettings when open.



Corner Rings

4 corner rings for decorations, such as lights, wind chimes, etc



Corner rings provide attachment points for lights or other decorations.



Velcro Shade Curtains

Prevent mosquitoes from entering through gaps effectively

Velcro fasteners on shade curtains help prevent gaps and mosquito entry.

MAINTENANCE

Regular maintenance will extend the lifespan of your gazebo.

- **Cleaning:** Clean the canopy fabric and netting with mild soap and water. Avoid harsh chemicals or abrasive cleaners. Rinse thoroughly and allow to air dry completely before storage.
- **Frame Care:** Inspect the galvanized steel frame periodically for any signs of rust or damage. Clean with a damp cloth and dry thoroughly.
- **Fasteners:** Regularly check all bolts, screws, and anchoring points to ensure they remain tight and secure. Re-tighten as necessary.
- **Seasonal Storage:** During periods of extreme weather (heavy snow, strong winds, prolonged rain), it is recommended to remove the canopy, curtains, and netting to prevent damage and prolong their life. Store these components in a dry, protected area.

TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Water Accumulation on Roof:** Ensure the canopy is properly stretched and secured to allow water to drain through the designated holes. If water still pools, check for any sagging areas and adjust the frame or canopy tension.
- **Gazebo Instability:** Verify that all anchoring points (expansion bolts, stakes, ropes) are correctly installed and tightened. Ensure the gazebo is placed on a level surface. In high winds, always use the wind-resistant ropes.
- **Difficulty with Assembly:** Refer to the detailed assembly diagrams. Ensure all parts are correctly identified and oriented. If a part seems difficult to fit, double-check the instructions for that specific step. Two people are recommended for easier assembly.
- **Damaged or Missing Parts:** If you receive damaged or missing parts, please contact LAUSAINT HOME customer support for assistance.

SPECIFICATIONS

Feature	Specification
---------	---------------

Brand	LAUSAINT HOME
Material	Metal (Galvanized Steel Frame)
Product Dimensions (L x W x H)	236.2" x 110.6" x 110.6" (19.7' x 9.2' x 9.2')
Water Resistance Level	Water Resistant (1500MM)
Shape	Rectangular
Ultraviolet Light Protection	UV 50+
Color	Khaki
Number of Items	1

WARRANTY AND SUPPORT

For any questions, concerns, or to report damaged/missing parts, please contact LAUSAINT HOME customer support. Refer to your purchase documentation for specific warranty details and contact information.