Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GAOMON ssw-PPS_339C7HXE-gmbCzas

GAOMON Large Outdoor Chicken Coop Instruction Manual

Model: ssw-PPS_339C7HXE-gmbCzas

Introduction

Thank you for choosing the GAOMON Large Outdoor Chicken Coop. This manual provides essential information for the safe assembly, operation, and maintenance of your new chicken coop. Please read these instructions thoroughly before beginning assembly and retain them for future reference.

Safety Information

- Always wear appropriate safety gear, such as gloves, during assembly to prevent injury.
- Ensure all screws and fasteners are securely tightened to maintain structural integrity.
- Place the chicken coop on a level, stable surface to prevent tipping.
- Regularly inspect the coop for any loose parts or damage that could compromise the safety of your poultry.
- Keep children and pets away from the assembly area.

Package Contents

Before assembly, verify that all components are present and undamaged. Refer to the included parts list in your packaging. If any parts are missing or damaged, please contact customer support immediately.



Image: Overview of the GAOMON Large Outdoor Chicken Coop, showing its various sections and open access points.

Setup and Assembly

Assembly of this chicken coop is designed to be straightforward. An electric drill is recommended for faster and more secure assembly. Follow the step-by-step instructions provided in your packaging. Ensure all connections are firm.

Product Specifications:

Dimension:80.3" x 35.8" x 54.1"



Image: Detailed dimensions of the chicken coop, including length, width, and height measurements for various sections.

Important: Some parts may not have pre-drilled holes. Align components carefully before securing them. If you encounter any damaged parts during unpacking or assembly, do not proceed; contact customer service for assistance.

Operating Instructions

Nesting Box Usage

The integrated nesting box provides a secure and private area for your poultry to lay eggs. The lid of the nesting box can be opened from the outside for easy egg collection.



Image: Key features of the coop, highlighting the asphalt roof, accessible nesting box, secure door latch, and ramp.

Ramp and Access

A sliding door and ramp facilitate easy access for poultry between the ground run area and the raised housing area. The ramp features timber ridges to prevent slipping.

Security Features

The coop doors are equipped with metal slide bolt locks to ensure your poultry are safe from predators and prevent escape.

Maintenance

Cleaning

The coop features a removable bottom sliding tray for convenient and hygienic cleaning. Regular cleaning is essential for the health of your poultry.



Image: Close-up view of the pull-out cleaning tray and the internal ramp with anti-slip ridges.

Weather Protection

The coop is constructed from solid, rain-resistant fir wood with environmentally friendly paint and features an asphalt sloping roof. This design provides protection against rain, wind, and snow, ensuring a dry and comfortable environment for your poultry.

Troubleshooting

- **Wood Splitting:** If wood splits during assembly, ensure screws are not overtightened. For significant splits, contact customer support for replacement parts.
- **Misaligned Parts:** If parts do not align correctly, double-check the assembly steps and ensure all components are oriented as shown in the instructions. Slight adjustments may be needed due to natural wood variations.
- **Damaged Components:** If any component arrives damaged, do not attempt to force it into place. Contact GAOMON customer support for a replacement.

Specifications

Product Dimensions (L x W x H)	78.74" x 51.18" x 51.18"
Capacity	4-6 Chickens
Material	Solid Fir Wood, Asphalt Roof
Color	Grey
Item Weight	125.44 Pounds
Model Number	ssw-PPS_339C7HXE-gmbCzas
UPC	199913321811

Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact GAOMON customer service directly. Provide your model number (ssw-PPS_339C7HXE-gmbCzas) and proof of purchase when seeking assistance.
Contact information can typically be found on the manufacturer's website or on the product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GC6RQ6V3

More documents and user manuals: **https://manuals.plus/**