Voukad NLQ-H1906

Voukad Beard Trimmer Instruction Manual

Model: NLQ-H1906

Brand: Voukad

Introduction

This manual provides essential information for the safe and effective use of your Voukad Beard Trimmer. Please read these instructions thoroughly before first use and retain them for future reference. The Voukad Beard Trimmer is designed for precision grooming, offering versatile settings and a durable, waterproof design for optimal performance.

What's Included

Your Voukad Beard Trimmer kit includes the following components:

- Men's Electric Hair Trimmer Handle
- Replaceable Nose/Ear Hair Trimmer Blade
- Replaceable Steel Detailer Trimmer Blade
- 2 x Length Combs (for various beard lengths)
- Soft Pouch
- USB-C Charging Cable
- Lubricating Oil
- Cleaning Brush



Image: Complete Grooming Kit with main trimmer, detailer head, nose trimmer, guide combs, USB-C cable, lubricating oil, and soft pouch.

Setup

Charging the Trimmer

Before first use, fully charge the trimmer. Use the provided USB-C cable to connect the trimmer to a compatible USB power source. The LED indicator lights on the trimmer will show the charging status. A full charge provides up to 120 minutes of cordless runtime. A quick 5-minute charge can provide enough power for one complete trim if needed.



Image: The trimmer charging via its universal USB-C port, indicating 120 minutes of runtime and a 5-minute quick charge feature.

Attaching and Detaching Trimmer Heads

The trimmer comes with a main beard trimming head, a precision detailer blade, and a nose/ear trimmer. To change heads, gently push the current head off the main unit and snap the desired head into place until it clicks securely.

Attaching Guide Combs

The main trimmer head uses a Pro-Wheel Dial system for length adjustment. Simply slide one of the two provided length combs onto the main trimmer head. The dial allows for 40 precise length settings from 0.5mm to 20mm in 0.5mm increments. Ensure the comb is securely attached before adjusting the dial.



Image: The Pro-Wheel precision dial on the trimmer, allowing for 40 length settings from 0.5mm to 20mm without changing guide combs.

Operating Instructions

Powering On/Off and Travel Lock

Press the power button to turn the trimmer on or off. To activate the travel lock, press and hold the power button for 5 seconds. This prevents accidental activation during travel. Repeat the process to unlock.

Adjusting Trim Length

With a length comb attached, rotate the Pro-Wheel Dial to select your desired trim length. The dial offers 40 precise settings from 0.5mm for stubble to 20mm for a longer beard. The dial locks in place to ensure consistent cutting length.

Using Different Attachments

- **Main Trimmer:** Use with a guide comb for overall beard trimming. The Constant Voltage Chip maintains 100% motor torque, preventing hair pulling even at low battery.
- **Precision Detailer Blade:** Attach this narrow head for sharpening cheek lines, cleaning the mustache lip area, or creating detailed edges.
- **Nose/Ear Trimmer:** Use this attachment for safely removing unwanted nose and ear hair.




Image: Using the detailer blade to define sharp lines around the mustache and sideburns for a precise look.

Wet and Dry Use (IPX7 Waterproof)

The Voukad Beard Trimmer is IPX7 waterproof, allowing for both wet and dry trimming. You can use it in the shower for convenience and easy cleanup. Do not use in the shower with the power cord plugged in.



Image: The IPX7 waterproof trimmer being rinsed under running water, highlighting its shower-safe design and easy cleaning.

Maintenance

Cleaning

After each use, detach the trimmer head and rinse it under running water. Use the provided cleaning brush to remove any trapped hairs from the blades and inside the trimmer head. Ensure the trimmer is dry before reattaching the head or storing.



Image: Cleaning the IPX7 waterproof beard trimmer under running water for quick and easy maintenance.

Lubrication

Apply a few drops of the included lubricating oil to the blades regularly, especially after cleaning, to maintain optimal cutting performance and prolong blade life.

Troubleshooting

Problem	Possible Cause	Solution
The cutting is uneven.	The guiding comb does not touch the skin when you move the appliance through the hair/beard.	Make sure the flat part of the guiding comb is always fully in contact with the skin when you move the appliance through the hair/beard.
	You only move the appliance in one direction.	Not all hairs grow in the same direction; move the appliance in different directions (upwards, downwards and across).
	The setting of guiding comb is changed during trimming.	Check the setting of the guiding comb on the dial. If you push the appliance too hard onto the scalp, you may accidentally changed the setting of the guiding comb.
	The comb is not assembled correctly.	Detach the comb and reattach it.
The appliance doesn't work when switched on.	The cutting performance decreases when the cutting blade and the guiding comb are dirty.	Clean the cutting blade and the guiding comb.
	The rechargeable battery is empty.	Charge the appliance. Make sure that the charging cable is inserted into the appliance properly and the supply unit is connected to the wall socket properly.

Specifications

- **Model Number:** NLQ-H1906
- **Brand:** Voukad
- **Power Source:** Battery Powered
- **Battery:** 1 9V battery (included)
- **Cordless Runtime:** Up to 120 minutes
- **Charging Method:** USB-C (no adapter included)
- **Input Voltage:** 5V
- **Waterproof Rating:** IPX7
- **Blade Material:** Ceramic, Stainless Steel
- **Precision Settings:** 40 (0.5mm to 20mm)
- **Item Weight:** 0.39 Kilograms (13.76 ounces)
- **Color:** Blue + Black

Warranty and Support

Please refer to the warranty card included in your product packaging for detailed information regarding warranty coverage and registration. For any support or service inquiries, please contact Voukad customer service.

Official Product Videos

Your browser does not support the video tag.

Video: Efficient Beard Trimmer, USB-C Charging, 120-Min Runtime. This video demonstrates the trimmer's efficient operation, USB-C charging capability, and long battery life.

Your browser does not support the video tag.

Video: Unboxing Voukad Beard Trimmer. This video shows the unboxing experience and the various components included in the Voukad Beard Trimmer kit.

Your browser does not support the video tag.

Video: Manages all body hair + waterproof! Nothing better than this! This video highlights the trimmer's versatility for body hair and its waterproof capabilities.

Your browser does not support the video tag.

Video: Precision trimmer has 40 different lengths! This video showcases the precision dial and its 40 length settings for accurate trimming.