

Yubeaahn B13

Yubeaahn B13 Wireless Earbuds User Manual

Model: B13

INTRODUCTION

Thank you for choosing the Yubeaahn B13 Wireless Earbuds. This manual provides essential information for setting up, operating, and maintaining your earbuds to ensure optimal performance. Please read these instructions carefully before use.

SETUP

Before First Use

Ensure the wireless earbuds are fully charged before initial pairing. Place both earbuds into the charging case and connect the case to a power source using a compatible USB cable.

Pairing Instructions

1. **For iOS Devices:** Open the lid of the charging case. A pairing window will automatically appear on your iPhone screen. Follow the on-screen prompts to connect.
2. **For Android Devices:** Turn on Bluetooth on your phone. Open the earbud charging case. On your phone, search for "B13" in the Bluetooth device list and select it to pair.
3. After the first successful connection, the earbuds will automatically power on and connect to your device when taken out of the charging case.

Note: Ensure the earbuds are within approximately 10 meters (33 feet) of your phone for a stable connection.

ONE STEP PAIRING

Super Fast And Simple Pairing Process

1
take the bluetooth wireless
headset out of the charging box

2
turn on the bluetooth
and select B13 connect

3
the IOS system will pop up a
connection window,click "Done" to

The phone screen constantly
monitors the battery status



Image: Visual guide demonstrating the one-step pairing process for the earbuds, showing the charging case and a smartphone displaying a connection prompt.

UPGRADED BLUETOOTH 5.0




CONSTANT
Signals



STRONG
Connection



≥ BLUETOOTH 4.0



iPhone | iPad | Mac | Samsung | Huawei | Android | PC | MP4

Image: Illustration highlighting the upgraded Bluetooth 5.3 technology, constant signals, strong connection, and broad compatibility with various devices including iOS, Android, Mac, and Windows.

OPERATING

Smart Touch Controls

The earbuds feature smart touch controls for easy management of music and calls. The touch-sensitive area is located on the outer surface of each earbud.

- **Play/Pause Music:** Touch either earbud once.
- **Previous Song:** Touch the left earbud twice (L).
- **Next Song:** Touch the right earbud twice (R).
- **Answer/Hang Up Call:** Touch either earbud once.
- **Reject Call:** Touch either earbud twice.
- **Power On/Off:** Press and hold either earbud for 3 seconds.

- **Activate Voice Assistant (e.g., Siri):** Touch either earbud three times. Please touch lightly and wait about 2 seconds for accurate control as the smart key is sensitive.

Mono Mode

If you prefer to use only one earbud, simply take one earbud out of the charging case and use it separately. The other earbud can remain in the case.

Dual Ear Talking

The earbuds support hands-free conversations using the built-in microphones on both sides, allowing for clear communication during calls.

INTELLIGENT TOUCH CONTROL



Touch 2(L)
Previous Song



Press 3s(L)
Power on/off



Touch 1
Play/Pause music



Touch 1
Answer/Hang up



Touch 2(L)
Next Song



Touch 2
Reject Call

Hey, Siri!



Touch 3

Please touch lightly and wait
about 2s to control accurately because the Smart
Key is very sensitive



Image: Diagram illustrating the various touch control gestures on the earbuds for functions like play/pause, next/previous song, answer/reject calls, power on/off, and activating voice assistant.

MAINTENANCE

Charging the Earbuds and Case

- Place the earbuds into the charging case. Ensure the charging contacts at the bottom of the earbuds and case are clean and free from obstructions.
- Connect the charging case to a USB power source. The case has a 650mAh battery capacity.
- A full charge for the earbuds typically provides 3 hours of talking time or 4 hours of listening time. The charging case can fully charge the earbuds multiple times.

Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Ensure the charging port at the bottom of the charging case is dry and clean.
- Avoid using abrasive materials or harsh chemicals for cleaning.



Image: Depiction of the powerful charging case for the earbuds, highlighting its 650mAh capacity and estimated usage times: 3 hours talking, 4 hours listening, and 50 minutes for a full charge.

TROUBLESHOOTING

Common Issues and Solutions

- **Sound Delay, No Sound, or Connection Issues:** If you experience any of these problems, try inserting both earbuds back into the charging case for a few seconds, then take them out to re-establish the connection. Alternatively, re-pair them with your phone by following the pairing instructions.
- **Earbuds Not Pairing:** Ensure the earbuds are fully charged. Press and hold the button on the back of the charging case to delete the last pairing record, then attempt to pair again.
- **One Earbud Not Working:** Place both earbuds back into the charging case, close the lid, and then open it again. Ensure both earbuds are properly seated and charging.

SPECIFICATIONS

- **Model Name:** B13
- **Connectivity Technology:** Wireless (Bluetooth)
- **Bluetooth Version:** 5.3
- **Bluetooth Range:** Up to 10 meters (33 feet)
- **Water Resistance Level:** IPX7 (Waterproof)
- **Control Method:** Touch
- **Audio Driver Type:** Dynamic Driver (13mm dual-chamber speaker unit)
- **Noise Control Features:** Noise Cancelling
- **Included Components:** Earphones, Charging Case
- **Compatible Devices:** Smartphones (iOS/Android), TV, Computers, Laptops, Smart Watches
- **Material:** Plastic, Silicone
- **Item Weight:** 1.44 ounces
- **Package Dimensions:** 5.63 x 3.98 x 0.87 inches

WARRANTY INFORMATION

For detailed warranty information, please refer to the product packaging or contact the seller directly through your purchase platform. Keep your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

If you encounter any issues or have questions not covered in this manual, please contact Yubeaahn customer support. You can typically find contact information on the platform where you purchased the product.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question