

TehanId B0GCCCT6VR

TehanId 130 Can Beverage Refrigerator User Manual

Model: B0GCCCT6VR

[Information](#) [Setup](#) [Operation](#) [Introduction](#) [Safety](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the TehanId 130 Can Beverage Refrigerator. This manual provides essential information for the safe and efficient use of your new appliance. Please read these instructions thoroughly before installation and operation, and retain them for future reference.

This beverage refrigerator is designed to store a variety of drinks, offering a cooling range of 34°F to 64°F. Its compact, freestanding design makes it suitable for various environments such as home bars, kitchens, offices, or entertainment areas.

2. SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or injury, follow these basic precautions:

- Read all instructions before using the appliance.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- This appliance must be properly installed and located in accordance with the Installation Instructions before it is used.
- Connect to properly grounded outlets only. Refer to "Grounding Instructions" in the Setup section.
- Never unplug your appliance by pulling on the power cord. Always grasp the plug firmly and pull straight out from the outlet.
- Repair or replace immediately all electric service cords that have become frayed or otherwise damaged. Do

not use a cord that shows cracks or abrasion damage along its length, the plug, or the connector end.

- Unplug your appliance before cleaning or before making any repairs.
- If your old appliance is not being used, we recommend that you remove the door and leave the shelves in place. This will reduce the possibility of danger to children.
- Do not use any electrical device or any sharp instrument in defrosting your appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

3. SETUP

3.1 Unpacking and Inspection

Carefully remove all packaging materials. Inspect the refrigerator for any shipping damage. Report any damage to your retailer immediately. Ensure all components are present: the beverage refrigerator unit, adjustable shelves, and power cord.

3.2 Placement

This is a freestanding unit. Allow at least 2-4 inches of space between the back and sides of the refrigerator and any adjacent walls to ensure proper air circulation. Avoid placing the unit in direct sunlight or near heat sources (e.g., ovens, radiators). The dimensions of the unit are approximately 18.89"D x 17.51"W x 31.29"H.

3.3 Leveling the Unit

The refrigerator is equipped with adjustable leveling feet. It is crucial for the unit to be level to ensure proper operation and door sealing. Adjust the feet by turning them clockwise or counter-clockwise until the refrigerator is stable and level on the floor.



This image illustrates the adjustable leveling feet, double tempered glass door, and reversible door design, which contribute to the stability and versatility of the unit.

3.4 Door Reversibility

The glass door is reversible, allowing it to open from either the left or right side to suit your room layout. Refer to the detailed instructions in the separate door reversal guide (if included) or contact customer support for

assistance with this procedure.

3.5 Initial Cleaning

Before first use, clean the interior and exterior of the refrigerator with a soft cloth and mild detergent. Rinse with clean water and dry thoroughly.

3.6 Power Connection

Plug the refrigerator into a dedicated, grounded electrical outlet. Do not use extension cords or adapter plugs. Allow the unit to stand upright for at least 2-4 hours before plugging it in to allow the refrigerant to settle.

4. OPERATING INSTRUCTIONS

4.1 Powering On/Off

To turn the unit on or off, press the power button on the control panel located inside the refrigerator, near the top.

4.2 Temperature Control

The Tehanld beverage refrigerator features an adjustable thermostat with a cooling range of 34°F to 64°F. Use the up and down arrow buttons on the control panel to set your desired temperature. The current temperature will be displayed on the digital screen.

Adjustable Temperature Beverage Cooler

Cooling Range: 34–64°F




This image shows the intuitive control panel for adjusting the temperature and managing the LED light.

4.3 Internal Air Circulation

The unit is designed with internal air circulation to promote even cooling throughout the cabinet, ensuring all your beverages are chilled consistently.

Internal Air Circulation Cooling

Promotes Even Cooling Throughout the Cabinet



A visual representation of the internal air circulation system, designed for consistent cooling.

4.4 Adjustable Shelves

The refrigerator includes adjustable shelves, providing flexibility to store various sizes of cans, bottles, and taller drinks. You can reposition the shelves to optimize storage space as needed.

Compact Size, Spacious Storage

Ideal for Home Bars & Offices



This image highlights the compact dimensions and the flexible storage options for different types of beverages.

4.5 LED Lighting

Press the LED light button on the control panel to turn the interior light on or off, allowing for clear visibility of your stored beverages.

5. MAINTENANCE

5.1 Cleaning the Interior

Unplug the refrigerator before cleaning. Wash the interior with a mild detergent and warm water solution. Use a soft cloth or sponge. Do not use abrasive cleaners or scouring pads. Rinse thoroughly and dry completely before plugging the unit back in.

5.2 Cleaning the Exterior

Clean the exterior surfaces with a soft cloth and mild detergent. For the glass door, use a glass cleaner. Avoid getting water on the control panel or electrical components.

5.3 Manual Defrost

This unit features a manual defrost system. Over time, frost may accumulate on the cooling surfaces. When frost buildup becomes excessive (approximately 1/4 inch thick), unplug the unit and allow the frost to melt naturally. Place towels at the bottom to absorb water. Do not use sharp objects to remove frost.

5.4 Power Interruption

In case of a power outage, keep the door closed to maintain the internal temperature for as long as possible. Avoid opening the door unnecessarily.

6. TROUBLESHOOTING

Before contacting customer support, please refer to the following table for common issues and their solutions.

Problem	Possible Cause	Solution
Refrigerator does not operate.	No power to the unit.	Check if the power cord is securely plugged into a working outlet. Check the circuit breaker.
Unit is not cold enough.	Temperature setting is too high. Door is not closed properly. Excessive door openings. Unit is placed near a heat source.	Lower the temperature setting. Ensure the door is fully closed and sealed. Minimize door openings. Relocate the unit away from heat sources.
Unit is noisy.	Unit is not level. Vibrations from internal components.	Adjust the leveling feet to ensure the unit is stable. Some operational noise from the compressor is normal.
Door does not close properly.	Unit is not level. Gasket is dirty or damaged. Shelves are improperly positioned.	Level the unit. Clean or replace the door gasket. Ensure shelves are correctly inserted and not obstructing the door.
Water on the floor.	Drainage hole is blocked. Excessive humidity.	Clear any blockage from the drainage hole. Ensure the door is sealed properly to prevent excessive humidity ingress.

7. SPECIFICATIONS

Feature	Detail
Brand	TehanId

Feature	Detail
Model Number	B0GCCCT6VR
Product Dimensions (D x W x H)	18.89" x 17.51" x 31.29"
Capacity	3.2 Cubic Feet (approx. 90 liters) / 130 Standard Cans
Color	Black
Cooling Method	Compressor
Adjustable Temperature Control	Yes (34°F - 64°F)
Defrost System	Manual Defrost
Installation Type	Freestanding
Door Orientation	Reversible
Special Features	Adjustable Shelves, Adjustable Leveling Feet
Item Weight	52.91 Pounds
Power Source	Corded Electric

8. WARRANTY AND CUSTOMER SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact Tehanld customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.

For assistance, please visit the Tehanld store on Amazon or contact the seller EYSTER directly through your Amazon order details.