Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MAILANGSHI YA-11111

MAILANGSHI 2026 RGB Lighting Wireless Guitar System Instruction Manual

Model: YA-11111

Introduction

Thank you for choosing the MAILANGSHI 2026 RGB Lighting Wireless Guitar System. This manual provides essential information for the proper setup, operation, and maintenance of your new wireless system. Please read these instructions carefully before use to ensure optimal performance and longevity of the product.

What's in the Box

The MAILANGSHI 2026 RGB Lighting Wireless Guitar System package includes the following items:

- Wireless Transmitter (TX)
- Wireless Receiver (RX)
- Type-C Charging Cable
- Portable Storage Bag
- User Manual



Image: All components included in the MAILANGSHI Wireless Guitar System package.

Product Overview

The MAILANGSHI Wireless Guitar System consists of a transmitter (TX) and a receiver (RX), both designed for seamless audio transmission. Each unit features a 6.35mm jack, a power/function button, and RGB lighting for visual feedback.



Image: The transmitter (TX) and receiver (RX) units with their RGB lighting activated.



Image: Overview of the wireless receiver and transmitter system.

Setup

1. Charging the Devices

Before initial use, ensure both the transmitter and receiver are fully charged. Use the provided Type-C charging cable to connect the devices to a USB power source. A red indicator light will show during charging and turn off when fully charged. A full charge provides up to 12 hours of continuous use.



Image: The wireless unit connected to a Type-C charging cable, illustrating the charging process.

2. Connecting to Your Instrument and Amplifier

1. Insert the transmitter (TX) into the 6.35mm output jack of your instrument (guitar, bass, ukulele, etc.). The 280° rotating plug allows for flexible positioning.
2. Insert the receiver (RX) into the 6.35mm input jack of your amplifier or audio interface.



Image: The wireless unit plugged into a guitar, showing its adjustable angle.




Image: Comparison of wired vs. wireless guitar setup, highlighting the convenience of the wireless system.

Operating Instructions

1. Power On/Off and Pairing

1. To power on/off, press and hold the power button on both the transmitter and receiver for 2 seconds.
2. When the receiver is not connected, the blue light will flash slowly.
3. Upon successful connection, the light will gradually change, indicating a stable link. The system is designed for automatic pairing.



Image: Visual guide for power, light effects, and connection status.

2. RGB Lighting Control

The wireless system features dynamic RGB lighting that pulsates with the music, enhancing your playing experience. You can control the lighting effects:

- **Single Click:** Press the power button once to cycle through seven different lighting effects.
- **Double Click:** Press the power button twice to turn off the lighting effects.



Image: Details on adjustable RGB lighting and its dynamic effects.

3. Transmission Performance

The system offers an ultra-long transmission distance of 230 feet (approximately 70 meters) with low noise, low latency (3ms), and interference-free operation. This ensures stable and high-quality audio transmission even when moving remotely.




Image: Visual representation of the system's transmission range and low latency.

4. Wide Compatibility

The MAILANGSHI Wireless Guitar System is compatible with all instruments featuring a 6.35mm jack, including acoustic guitars, electric guitars, basses, ukuleles, mandolins, accordions, and keyboards.




Image: Examples of instruments compatible with the wireless system.




Image: The wireless system demonstrating wide compatibility with different musical instruments.

Maintenance

- Keep the devices clean and dry. Avoid exposure to moisture or extreme temperatures.
- Store the transmitter and receiver in the provided portable storage bag when not in use to protect them from dust and damage.
- Use a soft, dry cloth to clean the surfaces of the devices. Do not use harsh chemicals or abrasive materials.
- Ensure the charging ports are free from debris to maintain proper charging functionality.

Troubleshooting

No Sound Output:

- Ensure both the transmitter and receiver are powered on and successfully paired (indicated by a solid, gradually changing light).
- Check the battery levels of both devices. Recharge if necessary.
- Verify that the transmitter is securely plugged into your instrument and the receiver into your amplifier/audio device.
- Confirm that your amplifier/audio device is powered on and its volume is adjusted appropriately.

Connection Issues:

- If the blue light on the receiver continues to flash slowly, the devices are not paired. Power both units off and then on again, ensuring they are in close proximity for initial pairing.
- Avoid strong electromagnetic interference sources that might disrupt the wireless signal.
- Ensure the distance between the transmitter and receiver is within the 230-foot range.

Short Battery Life:

- Ensure devices are fully charged before use.

- Battery performance may vary based on usage patterns and environmental conditions.
- If the issue persists, contact customer support.

Specifications

Feature	Detail
Brand	MAILANGSHI
Model Name	2026
Model Number	YA-11111
Color	Black
Transmission Distance	230 feet (approx. 70 meters)
Latency	3ms (ultra-low)
Battery Life	Up to 12 hours (continuous use)
Charging Port	Type-C
Rotating Plug Angle	280°
Connector Type	6.35mm Jack
RGB Lighting Effects	7 adjustable effects, pulsates with music
Compatible Devices	Acoustic Guitar, Electric Guitar, Bass, Ukulele, Mandolin, Accordion, Keyboard
Product Dimensions	4.72"D x 1.97"W x 4.72"H

Warranty and Support

This product comes with a one-year warranty from the date of purchase. For warranty claims, technical support, or any inquiries regarding your MAILANGSHI Wireless Guitar System, please refer to the contact information provided with your purchase or visit the official MAILANGSHI website.

© 2026 MAILANGSHI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GCF45LXL

More documents and user manuals: **https://manuals.plus/**