

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [HOMCOM](#) /

> [HOMCOM TV Stand for up to 65-inch TVs, Industrial Style with Charging Station, 5 Drawers, and Open Shelves, Rustic Brown \(Model UK83B-662V70RB0331\)](#)

HOMCOM UK83B-662V70RB0331

HOMCOM Industrial Style TV Stand

Model: UK83B-662V70RB0331

INTRODUCTION

Thank you for purchasing the HOMCOM Industrial Style TV Stand. This manual provides important information regarding the assembly, operation, maintenance, and safety of your new TV stand. Please read these instructions carefully before assembly and retain them for future reference.

This TV stand is designed to accommodate televisions up to 65 inches and features a built-in charging station, five fabric drawers, and two open shelves for organized storage.



Image: The HOMCOM Industrial Style TV Stand, showcasing its design and functionality in a home environment.

SAFETY INFORMATION

- Always follow the assembly instructions carefully.
- Ensure all parts are securely fastened before use.
- Do not overload the TV stand. The maximum load capacity is 50 kg (110 lbs).
- Place the TV stand on a flat, stable surface to prevent tipping.
- Keep small parts and packaging materials away from children.
- Do not allow children to climb on the TV stand.
- When using the charging hub, ensure devices are compatible with the specified voltage and current. Do not exceed the maximum power rating of the charging hub.
- Unplug the charging hub from the wall outlet when not in use or during electrical storms.

PACKAGE CONTENTS

Before beginning assembly, please check that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- TV Stand Panels (engineered wood)
- Steel Frame Components
- 5 Fabric Drawers
- Built-in Charging Hub (pre-installed or separate unit)
- Assembly Hardware (screws, bolts, cam locks, etc.)
- Adjustable Foot Pads
- Assembly Tools (e.g., Allen wrench, screwdriver - may be included or required)

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is required for this TV stand. It is recommended to have two people for assembly. Please follow the step-by-step instructions provided in the included assembly guide (not part of this digital manual). Ensure you have a clear, spacious area for assembly.

1. **Unpack all components:** Carefully remove all parts from the packaging and lay them out on a soft, clean surface to prevent scratches.
2. **Assemble the steel frame:** Connect the steel frame components using the provided hardware. Ensure all connections are tight and secure.
3. **Attach panels:** Secure the engineered wood panels to the steel frame according to the assembly guide.
4. **Install shelves:** Place the two open shelves into their designated slots.
5. **Insert fabric drawers:** Fold and insert the five fabric drawers into their respective compartments.
6. **Adjust foot pads:** Once assembled, place the TV stand in its desired location. Adjust the foot pads at the bottom of the steel frame to ensure the stand is level and stable on uneven floors.
7. **Connect charging hub:** If the charging hub is not pre-installed, follow the instructions to secure it and plug its power cord into a wall outlet.

Solid Structure



01

02



Powder Coated Steel Frame



Adjustable Foot Pads

Image: Detail showing the powder-coated steel frame and adjustable foot pads for stability and leveling.

OPERATING INSTRUCTIONS

Placing Your Television

This TV stand is designed to hold televisions up to 65 inches in size and a maximum weight of 50 kg (110 lbs). Carefully place your television on the top surface of the stand, ensuring it is centered and stable.

HOLDS TVS UP TO 65"



Image: The TV stand supporting a 65-inch television, demonstrating its maximum screen size compatibility.

Using the Built-in Charging Hub

The TV stand features a convenient built-in charging hub with three AC sockets and two USB ports (5V, 2.1A). This allows you to power and charge various media devices directly from the stand.

- Plug the charging hub's power cord (1.5m length) into a standard wall outlet (220-250V, 50Hz).
- Connect your media devices (e.g., DVD players, gaming consoles, soundbars) to the AC sockets.
- Connect your mobile devices (e.g., smartphones, tablets) to the USB ports for charging.
- Ensure that the total power consumption of connected devices does not exceed the hub's maximum rating.



Built-In Charging Station



USB Port & USB-C Port
5V, 2.1A



3 AC Sockets
220-250V, 50Hz



Power Cord
1.5 m

Image: The integrated charging station, highlighting its AC sockets and USB ports for convenient device power and charging.

Utilizing Storage Space

The TV stand offers versatile storage options:

- **Open Shelves:** Use the two open shelves for media players, game consoles, or decorative items that require easy access or ventilation.
- **Fabric Drawers:** The five fabric drawers provide concealed storage for cables, remotes, games, DVDs, or other accessories, helping to keep your living space tidy.



Spacious Storage Space

2 Open Shelves ●

5 Fabric Drawers ●

Image: The TV stand's storage compartments, including two open shelves and five fabric drawers, designed for organizing media and accessories.

MAINTENANCE

To ensure the longevity and appearance of your HOMCOM TV stand, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the surfaces with a soft, dry cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the finish.
- **Spills:** Immediately wipe up any spills with a dry cloth to prevent staining or damage to the engineered wood.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Tighten if necessary to maintain stability.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood-effect finish.
- **Heat:** Do not place hot items directly on the surface. Use coasters or protective pads.

TROUBLESHOOTING

Problem	Possible Cause	Solution
TV stand is wobbly or unstable.	Uneven floor; loose fasteners.	Adjust the foot pads at the bottom of the stand. Check and tighten all assembly screws and bolts.
Charging hub is not working.	Not plugged into wall outlet; wall outlet not active; device not properly connected; device incompatible; hub overloaded.	Ensure the hub's power cord is securely plugged into a live wall outlet. Test the outlet with another device. Check device connections. Verify device compatibility and ensure total load does not exceed hub capacity.
Drawers do not slide smoothly.	Drawer not assembled correctly; obstruction.	Ensure fabric drawers are fully expanded and correctly inserted. Check for any items obstructing the drawer's movement.

SPECIFICATIONS

Model Number	UK83B-662V70RB0331
Overall Dimensions (L x W x H)	140 x 30 x 50 cm (55.1 x 11.8 x 19.7 inches)
Weight	14 kg (30.8 lbs)
Material	Engineered Wood, Alloy Steel
Color	Rustic Brown
Maximum TV Size	65 inches
Maximum Load Capacity	50 kg (110 lbs)
Number of Drawers	5 (Fabric)
Number of Shelves	2 (Open)
Charging Hub	3 AC Sockets, 2 USB Ports (5V, 2.1A)
Power Input	220-250V, 50Hz
Power Cord Length	1.5 m
Special Features	Fabric Drawers, Integrated Charging Hub, Adjustable Feet



50 kg



Image: Detailed dimensions of the TV stand, including shelf and drawer measurements, and maximum TV size/weight capacity.

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or visit the official HOMCOM website. If you encounter any issues not covered in this manual, please contact HOMCOM customer service for assistance.

Manufacturer: Sold by MHSTAR

