

[Manuals.plus](#) /

› [Bearwind](#) /

› Bearwind Misting Fan S42 Instruction Manual

Bearwind S42

Bearwind Misting Fan S42 Instruction Manual

Model: S42

INTRODUCTION

Thank you for choosing the Bearwind Misting Fan S42. This portable device combines a powerful turbo fan with a refreshing cool mist spray, designed to provide instant cooling in various environments. Please read this manual thoroughly before use to ensure proper operation and maintenance.

PRODUCT OVERVIEW

The Bearwind Misting Fan S42 features a 165° foldable design, a 4000mAh rechargeable battery, 5 adjustable fan speeds, and a continuous mist function. It includes a digital display for easy monitoring of speed, mist mode, and battery level.

What's Included:

- 1 x Bearwind Misting Fan S42
- 1 x 50mL Water Bottle (for refilling)
- 1 x Lanyard
- 1 x USB Type-C Charging Cable
- 1 x User Manual

Product List

- 1 50mL Bottle
- 2 Misting Fan
- 3 Packaging
- 4 Lanyard
- 5 USB Cable
- 6 User Manual



Image: Contents of the Bearwind Misting Fan S42 package, including the fan, water bottle, lanyard, USB cable, and user manual.

SETUP

1. Charging the Fan:

1. Connect the provided USB Type-C charging cable to the fan's charging port.
2. Connect the other end of the cable to a compatible USB power adapter (not included) or a computer USB port.
3. The digital display will show the battery percentage during charging. A full charge (100%) typically takes about 3 hours with 10W fast charging.
4. Ensure the fan is fully charged before first use for optimal battery life.

4000mAh Rechargeable

Not just long-lasting, but stronger



19 H max
Working time



3 hour
Fast charging



10-15 min
Misting time

Image: The Bearwind Misting Fan S42 connected to a charging cable, displaying battery percentage on its digital screen.

2. Filling the Water Tank for Mist Function:

1. Locate the water tank cap on the fan head.
2. Gently open the cap.
3. Using the provided 50mL water bottle, carefully fill the tank with clean tap water. Do not use purified water, essential oils, or corrosive liquids, as this may damage the atomizer.

4. Close the water tank cap securely to prevent leaks.

Misting Fan Portable

3X faster cooling with turbo mist

A woman with long dark hair, wearing a light blue V-neck top, is holding a black portable misting fan. She has her eyes closed and a pleasant expression, enjoying the mist. The fan is emitting a fine spray of water, which is illustrated with several small, glowing water droplets (H₂O) floating in the air around her face. The background shows a sunny outdoor setting with a bus stop and a clear blue sky.



Before: sticky & sweaty



After: refreshing & hydrating

Image: A person using the Bearwind Misting Fan S42, demonstrating the misting function for cooling.

OPERATING INSTRUCTIONS

1. Power On/Off and Fan Speed Adjustment:

- To power on the fan, press and hold the power button (usually located on the handle) for 2 seconds. The digital display will light up.
- To adjust the fan speed (F1-F5), short press the power button. Each press cycles through the 5 speed levels.
- To power off the fan, press and hold the power button for 2 seconds again.

5-Speed Adjustment

Tips: Avoid adding purified water to the water tank



Image: The Bearwind Misting Fan S42 in use, showing the digital display indicating fan speed levels (F1-F5) and estimated battery life.

2. Mist Function Activation:

- With the fan powered on and the water tank filled, short press the mist button (usually located near the power button) to activate the continuous mist.
- The mist function can operate for up to 15 minutes continuously on a full tank.
- To turn off the mist function, short press the mist button again.

3. Using the Foldable Design:

- The fan head can be folded up to 165° relative to the handle. This allows for versatile use as a handheld fan, a desktop fan, or a neck fan.
- To use as a neck fan, attach the included lanyard to the designated slots on the fan handle.

Hand Free Cooling Fan

A must have for outdoors in hot summer



Image: A person wearing the Bearwind Misting Fan S42 around their neck using the included lanyard, demonstrating its hands-free capability.

MAINTENANCE

1. Cleaning:

- Ensure the fan is powered off and unplugged before cleaning.

- Wipe the exterior of the fan with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- For the fan blades, gently wipe with a dry cloth or use a soft brush to remove dust.
- Do not immerse the fan in water or any other liquid.

2. Water Tank and Atomizer Care:

- Regularly empty and rinse the water tank to prevent mineral buildup and bacterial growth.
- If the mist output decreases, gently clean the atomizer opening with a cotton swab dipped in white vinegar to remove mineral deposits, then rinse with clean water.
- Always use clean tap water. Avoid purified water as it can affect mist production due to low mineral content.

3. Storage:

- When not in use for extended periods, ensure the fan is fully charged and the water tank is empty and dry.
- Store the fan in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on.	Low battery or no charge.	Charge the fan using the provided USB Type-C cable.
Mist function not working.	Water tank empty or atomizer clogged.	Refill the water tank with clean tap water. Clean the atomizer as described in the Maintenance section.
Weak airflow.	Fan speed set too low or fan blades are dirty.	Increase the fan speed. Clean the fan blades.
Fan makes unusual noise.	Obstruction in fan blades or internal issue.	Power off the fan and check for any obstructions. If the noise persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Bearwind
Model Name	S42
Color	Black
Power Source	Battery Powered (4000mAh Rechargeable)
Charging Time	Approx. 3 hours (10W Type-C Fast Charge)
Operating Time	Up to 15 hours (fan only, depending on speed)
Mist Duration	Up to 15 minutes continuous
Number of Speeds	5
Product Dimensions	7.6"D x 2.6"W x 2.1"H

Feature	Detail
Item Weight	8 ounces
Noise Level	30 Decibels
Material	Acrylonitrile Butadiene Styrene
Special Features	Digital Display, Foldable Design, Misting Function

WARRANTY AND SUPPORT

Your Bearwind Misting Fan S42 comes with a standard manufacturer's warranty. For specific warranty details, please refer to the product packaging or contact Bearwind customer support.

If you encounter any issues or have questions regarding your product, please visit the official Bearwind website or contact their customer service team for assistance. Contact information can typically be found on the product packaging or on the brand's official online store page.

© 2024 Bearwind. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GCSJT5DM>

More documents and user manuals: **<https://manuals.plus/>**