

[Manuals.plus](#) /

› [CubiCubi](#) /

› CubiCubi L Shaped Gaming Desk (Model TPUC-CD0018-120BLA-01) Instruction Manual

CubiCubi TPUC-CD0018-120BLA-01

CubiCubi L Shaped Gaming Desk Instruction Manual

Model: TPUC-CD0018-120BLA-01

1. PRODUCT OVERVIEW

The CubiCubi L Shaped Gaming Desk is designed for versatile use in gaming, home office, or study environments. It features a spacious L-shaped surface, a movable monitor stand, and a sturdy construction for durability and stability.




Image 1.1: Overview of the CubiCubi L Shaped Gaming Desk in a typical setup, showcasing its L-shape and ample workspace.

Key Features:

- **L-Shaped Design:** Provides optimal legroom and a large surface area for multiple monitors and accessories.
- **Movable Monitor Stand:** Allows for ergonomic positioning of your screen, promoting better posture.
- **Reversible Configuration:** Can be assembled with the longer side on either the left or right to fit various room layouts.
- **Durable Construction:** Made with engineered wood and an alloy steel frame for stability and longevity.
- **Integrated Desk Hook:** Convenient for hanging headphones or backpacks.
- **Adjustable Foot Pads:** Ensures stability on uneven surfaces and prevents wobbling.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Always assemble the desk on a flat, level, and stable surface to prevent tipping.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not overload the desk or monitor stand beyond their specified weight capacities. The main desk surface has a vertical weight capacity of 132 lbs, and the monitor stand has a vertical weight capacity of 30 lbs.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Avoid using harsh chemicals or abrasive cleaners on the desk surface.
- Do not stand or sit on the desk.
- This desk is not designed for clamp-style monitor stands.




Image 2.1: Product dimensions and weight capacities, highlighting the 132lb capacity for the main desk and 30lb for the monitor stand.
Note: No clamp-style monitor stand is supported.

3. SETUP AND ASSEMBLY

Assembly is required for this product. All necessary tools are included. It is recommended to have two people for assembly.

Before You Begin:

- Unpack all components and verify against the parts list (refer to the included assembly guide for a detailed list).
- Clear a spacious, flat area for assembly.
- Keep all hardware organized to prevent loss.

Assembly Steps:

1. **Assemble the Frame:** Attach the leg frames to the main support beams using the provided screws. Ensure all connections are firm.
2. **Attach Desktop Panels:** Carefully place the L-shaped desktop panels onto the assembled frame. Secure them with screws from underneath. Note the reversible design allows you to choose the orientation of the L-shape (left or right).
3. **Install Monitor Stand:** Position the movable monitor stand on the desired section of the desk. It is designed to sit freely on the desktop.
4. **Attach Desk Hook:** Secure the iron hook to either the left or right side of the desk frame as per your preference.
5. **Adjust Foot Pads:** Once the desk is assembled and in its final position, adjust the foot pads at the bottom of the legs to ensure the desk is level and stable.



Image 3.1: Illustration of the stable Z-shaped leg frame, which ensures structural integrity and stability during assembly and use.



Image 3.2: Close-up of the adjustable foot pads, which can be rotated to level the desk on uneven floors and prevent wobbling.

Reversible Design

Freely choose left or right installation




Image 3.3: Visual representation of the desk's reversible design, allowing users to configure the L-shape for either left or right-hand orientation.

4. OPERATING INSTRUCTIONS

This section provides guidance on utilizing the features of your CubiCubi L Shaped Gaming Desk.

Using the Monitor Stand:

- The monitor stand is designed to be movable. Place it on any section of the desk that best suits your ergonomic needs.
- Ensure the monitor stand is placed on a stable part of the desk and does not overhang excessively.
- The stand elevates your monitor by approximately 3.9 inches, promoting a healthier viewing angle and posture.



Ours



Others



Image 4.1: The removable monitor stand, illustrating its 3.9-inch elevation for improved ergonomics and space underneath for storage.

Utilizing the Desk Hook:

- The integrated iron hook can be used to hang headphones, backpacks, or other accessories, keeping your workspace tidy.
- Ensure items hung on the hook do not exceed its weight capacity or interfere with desk stability.



Image 4.2: The convenient desk hook, shown holding a pair of headphones, designed for easy storage and access.

Footrests:

- The desk includes footrests integrated into the leg design, providing additional comfort and support during long periods of sitting.



Image 4.3: Illustration of the footrests, designed to increase stability and provide comfortable foot support.

5. MAINTENANCE

Proper maintenance will extend the life and appearance of your desk.

- **Cleaning:** Wipe the desk surface with a soft, damp cloth. For stubborn marks, use a mild soap solution and dry immediately. Avoid abrasive cleaners or harsh chemicals.

- **Spills:** The desktop material is waterproof. Wipe up spills promptly to prevent any potential damage or staining.
- **Scratches:** The desktop is scratch-resistant, but avoid dragging sharp or heavy objects across the surface to maintain its finish.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Environment:** Keep the desk in a dry environment, away from direct sunlight and extreme temperature changes.



Image 5.1: Features of the durable desktop material, highlighting its waterproof, scratch-resistant, and easy-to-clean characteristics.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your desk.

Issue: Desk is wobbly or unstable.

- **Solution 1:** Ensure all assembly screws are fully tightened.
- **Solution 2:** Adjust the foot pads at the bottom of each leg. Rotate them clockwise or counter-clockwise until the desk is level and stable on the floor.
- **Solution 3:** Verify the desk is placed on a flat, even surface.

Issue: Parts are missing or damaged during assembly.

- **Solution:** Contact customer service immediately with your product model number and a description of the missing or damaged parts. Do not attempt to force assembly with incorrect or damaged parts.

Issue: Monitor stand slides or is not stable.

- **Solution:** Ensure the monitor stand is placed centrally on a flat section of the desk and not near edges where it could tip. Avoid placing excessively heavy items on the stand beyond its 30 lb capacity.

7. SPECIFICATIONS

Feature	Detail
Brand	CubiCubi
Model Number	TPUC-CD0018-120BLA-01
Shape	L-Shaped (Rectangular components)
Product Dimensions (D x W x H)	17.72"D x 47.24"W x 28.62"H

Feature	Detail
Color	Black Carbon Fiber
Style	Modern
Base Material	Alloy Steel
Top Material Type	Engineered Wood
Item Weight	30 pounds
Main Desk Vertical Weight Capacity	132 lbs
Monitor Stand Vertical Weight Capacity	30 lbs
Assembly Required	Yes (Tools included)
Special Features	Movable Monitor Stand, Reversible Design, Desk Hook, Adjustable Foot Pads, Waterproof & Scratch-Resistant Desktop

8. WARRANTY AND SUPPORT

CubiCubi is committed to providing high-quality products and excellent customer service.

Warranty Information:

Specific warranty details may vary. Please refer to the warranty card included with your product or visit the official CubiCubi website for the most up-to-date information regarding warranty coverage and terms.

Customer Support:

If you have any questions, concerns, or require assistance with assembly, parts, or product functionality, please contact our customer support team. Have your model number (TPUC-CD0018-120BLA-01) ready when contacting support for faster service.

For support, please visit the [CubiCubi Store on Amazon](#) or refer to the contact information provided in your product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question