



Manuals.plus /

› PRAISUN /

› PRAISUN 54-Inch Record Player Stand with Power Outlets and LED Lights User Manual

PRAISUN B0GCZS14RY

PRAISUN 54-Inch Record Player Stand User Manual

Model: B0GCZS14RY

1. PRODUCT OVERVIEW

The PRAISUN 54-inch Record Player Stand is designed to organize and display your audio equipment and vinyl collection. It features integrated power outlets, USB ports, and 3-color LED lighting. The stand includes two fluted cabinets and open storage sections with metal dividers for records.



Figure 1: Front view of the PRAISUN 54-inch Record Player Stand.

Key Features:

- **Built-in Power Outlets:** Includes 2 AC outlets, 2 USB ports, and 1 USB-C port for convenient device charging and powering audio equipment.
- **3-Color LED Lighting:** Integrated lighting with cool white, warm white, and mixed light modes to enhance ambiance. A dedicated USB port for the LED strip is located beneath the tabletop.
- **Ample Storage:** Two side sliding fluted cabinets provide dust-free storage. The center section features metal dividers and can hold up to 300 records. Open shelves offer flexible space for various items.
- **Durable Construction:** Constructed from particle board with solid wood legs for stability and longevity.
- **Cable Management:** Four cable management holes are included to keep cords organized.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Weight Capacity:** Do not exceed the maximum weight capacity of the shelves. Distribute weight evenly.
- **Stability:** Ensure the stand is placed on a flat, stable surface. Avoid placing heavy items on the edges to prevent tipping.

- **Electrical Safety:** Only use the built-in power outlets with devices that meet the specified voltage and current ratings (125V/12A for AC, 5V/2A for USB/USB-C). Do not overload the outlets. Keep liquids away from electrical components.
- **Assembly:** Assemble the product according to the provided instructions. Do not use power tools for assembly unless explicitly stated, as this may overtighten screws and damage components.
- **Children:** Keep small parts and packaging materials away from children during assembly. Do not allow children to climb on or play with the stand.

3. SETUP AND ASSEMBLY

The PRAISUN Record Player Stand requires assembly. Follow the step-by-step instructions provided in the separate assembly guide included with your product. All necessary tools and clearly labeled parts are included.

Before You Begin:

1. **Unpack:** Carefully unpack all components and verify against the parts list in your assembly guide.
2. **Clear Area:** Choose a clean, flat, and spacious area for assembly to prevent scratching the product or your floor.
3. **Tools:** Ensure you have the provided tools readily available.

Assembly Tips:

- Do not fully tighten screws until all components are loosely assembled, then tighten them securely.
- If you encounter any difficulties, refer to the troubleshooting section or contact customer support.

Product Size



Figure 2: Product dimensions for planning placement and assembly.

4. OPERATING INSTRUCTIONS

4.1 Using the Built-in Power Outlets

The stand features an integrated power strip on the top surface for convenient access to power and charging.

- **AC Outlets:** Two standard AC outlets (125V/12A) are available for powering record players, speakers, or other compatible devices.
- **USB Ports:** Two USB ports (5V/2A) and one USB-C port (5V/2A) are provided for charging mobile devices, tablets, or other USB-powered accessories.
- **Connecting the Stand:** Plug the stand's main power cord into a wall outlet.



Figure 3: Detail of the built-in power outlets and USB ports.

4.2 Activating the 3-Color LED Lighting

The stand includes an LED light strip to illuminate the central open shelf, offering three color modes.

- **Powering the LED:** The LED light strip connects to a dedicated USB port located discreetly beneath the tabletop. Ensure this connection is secure.
- **Changing Colors:** Use the control switch on the LED strip to cycle through the three lighting modes: cool white, warm white, and mixed light.



Figure 4: The three available LED lighting color options.

4.3 Utilizing Storage Spaces

The stand offers various storage solutions for your media and accessories.

- **Side Fluted Cabinets:** Slide the doors to access the enclosed storage compartments on either end. These are suitable for smaller items or accessories you wish to keep dust-free.
- **Center Record Storage:** The central section is equipped with metal dividers to organize and store up to 300 vinyl records. The dividers can be removed if a larger open space is desired.
- **Open Shelves:** The upper and lower open shelves provide space for your record player, speakers, books, or decorative items.

3-Tier Multiple Storage Options

Stores up to 300 vinyl albums



Figure 5: Overview of the stand's storage capabilities.



Figure 6: Detail of the double-sided grid sliding door and cabinet interior.

5. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your record player stand.

- **Cleaning:** Wipe the surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Dusting:** Regularly dust the surfaces to prevent buildup.
- **Liquid Spills:** Immediately wipe up any liquid spills to prevent water damage.
- **Electrical Components:** Ensure all electrical connections are secure and free from dust. Do not attempt to clean the power outlets with liquids.
- **Structural Integrity:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.

6. TROUBLESHOOTING


If you encounter issues with your PRAISUN Record Player Stand, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Stand is wobbly or unstable.	Loose fasteners; uneven floor.	Ensure all screws are tightened. Adjust the stand's position or use shims if the floor is uneven.
Power outlets are not working.	Stand's main power cord unplugged; circuit breaker tripped; device not properly plugged in.	Check if the stand's power cord is securely plugged into a wall outlet. Verify the wall outlet is functional. Check your home's circuit breaker. Ensure devices are fully inserted into the outlets.
LED lights are not turning on.	LED strip USB connection loose; power issue.	Ensure the LED strip's USB connector is securely plugged into its dedicated port under the tabletop. Verify the stand's main power is connected.
Assembly difficulties (e.g., screws not fitting).	Incorrect part usage; misalignment; manufacturing defect.	Double-check the assembly guide to ensure correct parts are used for each step. Ensure components are aligned before inserting screws. If issues persist, contact PRAISUN customer support.


7. SPECIFICATIONS

- **Brand:** PRAISUN
- **Model:** B0GCZS14RY
- **Product Dimensions (D x W x H):** 14.2" x 53.9" x 29.7" (36.07 cm x 136.91 cm x 75.44 cm)
- **Material:** Particle Board, Solid Wood Legs, Metal (dividers)
- **Color:** Walnut
- **Number of Shelves:** 6 (including open and cabinet sections)
- **Power Outlets:** 2 AC Outlets (125V/12A), 2 USB Ports (5V/2A), 1 USB-C Port (5V/2A)
- **Special Feature:** 3-Color LED Lighting

More Thoughtful Details



4 Cable Holes



CD Partition



Tapered Table Legs



Reinforced Base

Figure 7: Additional design details for functionality and stability.

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact the seller directly through the platform where the product was purchased. Keep your purchase receipt as proof of purchase.

For further assistance, you may visit the PRAISUN Store on Amazon:PRAISUN Store