

ZOVIMAX X500

ZOVIMAX X500 Bone Conduction Headphones User Manual

Model: X500

INTRODUCTION

Thank you for choosing the ZOVIMAX X500 Bone Conduction Headphones. These open-ear headphones are designed for active lifestyles, offering a secure and comfortable fit while maintaining environmental awareness. Featuring Bluetooth 6.0 connectivity, IP68 waterproofing, and a wind-protected microphone, the X500 is ideal for various outdoor activities. Please read this manual carefully to ensure proper use and optimal performance of your device.

WHAT'S IN THE BOX

The ZOVIMAX X500 package includes the following items:

- ZOVIMAX X500 Bone Conduction Headphones
- User Manual
- Professional Fast Charging Cable

PRODUCT OVERVIEW

The ZOVIMAX X500 headphones feature an ergonomic neckband design with open-ear transducers that rest on your cheekbones, delivering sound through bone conduction. This design allows you to hear your audio while remaining aware of your surroundings.

Key Features

- **Open Bone Conduction Technology:** Ensures situational awareness.
- **Bluetooth 6.0:** For fast, stable, and low-latency wireless connectivity.
- **IP68 Waterproof Rating:** Resistant to sweat and water, suitable for various sports.
- **Wind-Protected Microphone:** Provides clear calls even in windy conditions.
- **Tactile Controls:** Optimized physical buttons for easy operation and to prevent accidental touches.
- **Adjustable LED Safety Light:** Enhances visibility during nighttime activities.
- **Long Battery Life:** Up to 18 hours of playtime on a single charge.
- **Multipoint Pairing:** Connects to two devices simultaneously.

Components and Controls

Familiarize yourself with the main components and control buttons of your ZOVIMAX X500 headphones.

Windgeschützte Mikrofone



**Schweiß- und
wasserfest**

Professionelles Schnellladekabel

Wasserdichter Anschluss



Optimierte physische Tasten

Vermeidung von unbeabsichtigten Berührungen



Längere Nutzungsdauer

18H

Bis zu 18 Stunden Spielzeit

Image: Overview of ZOVIMAX X500 features including wind-protected microphones, IP67 water resistance, optimized physical buttons, and a waterproof charging connection.

Frei Wandern – Immer Verbunden

Ausgestattet mit einem **ZOVIMAX Bluetooth 6.0** Chip, bietet das X500 schnelle, stabile Konnektivität in einem Bereich von **15m (50 Fuß)**.



Image: Internal view highlighting the ZOVIMAX Bluetooth 6.0 chip, ensuring stable connectivity.

SETUP

Charging the Headphones

Before first use, fully charge your ZOVIMAX X500 headphones. Use the provided professional fast charging cable. The charging port is waterproof.

1. Connect the charging cable to the waterproof charging port on your headphones.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show the charging status. Once fully charged, the indicator will change (refer to the LED indicator section in the full manual for specific light patterns).

A full charge provides up to 18 hours of playtime.

Bluetooth Pairing

Pair your ZOVI MAX X500 headphones with your mobile device for wireless audio.

1. **Power On:** Press and hold the Power button until the LED indicator flashes, indicating pairing mode.
2. **Activate Bluetooth:** On your mobile device, go to Bluetooth settings and turn Bluetooth on.
3. **Select Device:** Look for "ZOVI MAX X500" in the list of available devices and select it to connect.
4. **Confirmation:** Once connected, the LED indicator will change (refer to the LED indicator section in the full manual), and you will hear an audio prompt.

Multipoint Pairing

The X500 supports multipoint pairing, allowing simultaneous connection to two devices for a flexible and seamless audio experience.

Multipoint-Pairing

Einfache Verbindung zu zwei Geräten für ein flexibles und nahtloses Klangerlebnis



Image: Multipoint pairing feature, showing the headphones connected to both a laptop and a smartphone.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Press and hold the Power button for 2 seconds.
- **Power Off:** Press and hold the Power button for 3 seconds.

Music Playback

- **Play/Pause:** Press the Multi-function button once.
- **Next Track:** Double-press the Multi-function button.
- **Previous Track:** Triple-press the Multi-function button.
- **Volume Up:** Press the Volume + button.
- **Volume Down:** Press the Volume - button.

ZOVIMAX™ Militrtaugliches Nanomaterial



Ultra-Komfortabler Sitz für Ganztägiges Tragen

Optimiertes Anpressen

-18%



Geringere Vibration



Gewicht optimiert

30g



Image: The 'Immersive Sound Bubble' feature provides clear sound, powerful volume, and rich bass.

Call Management

- **Answer/End Call:** Press the Multi-function button once.
- **Reject Call:** Press and hold the Multi-function button for 2 seconds.
- **Voice Assistant:** Press the Multi-function button twice to activate your device's voice assistant.

The wind-protected microphone ensures clear communication during calls, even in challenging environments.

LED Safety Light

The ZOVIMAX X500 features an adjustable LED safety light for enhanced visibility during outdoor activities, especially in low-light conditions.

- **Modes:** The LED light offers four operating modes: On, Off, Slow Flash, and Fast Flash.
- **Control:** Refer to the specific button combination in the full manual for controlling the LED light modes.



Image: The adjustable LED safety light on the ZOVIMAX X500 headphones, providing visibility during evening runs.



Musik hören, Trotzdem den Verkehr hören

Behalten Sie bei Outdoor-Aktivitäten stets die Übersicht über die Situation.

Image: The open-ear design allows users to listen to music while maintaining awareness of their surroundings, crucial for outdoor activities like cycling.

MAINTENANCE

Proper maintenance ensures the longevity and performance of your ZOVIMAX X500 headphones.

- **Cleaning:** Wipe the headphones with a soft, damp cloth. Do not use harsh chemicals or abrasive materials.
- **Water Resistance:** The headphones are IP68 waterproof and sweat-resistant. After exposure to water or sweat, ensure

they are dry before charging. Do not submerge them for extended periods or use them in hot water.

- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- **Charging Port:** Keep the charging port clean and dry to prevent corrosion.

TROUBLESHOOTING

If you encounter issues with your ZOVIMAX X500 headphones, try the following solutions:

Problem	Possible Solution
Cannot power on	Ensure the headphones are fully charged. Press and hold the Power button for 2 seconds.
Cannot pair with device	Ensure Bluetooth is enabled on your device. Make sure the headphones are in pairing mode (flashing LED). Move closer to your device. Forget the device in your phone's Bluetooth settings and try pairing again.
No sound or low volume	Check the volume levels on both the headphones and your connected device. Ensure the headphones are properly positioned on your cheekbones. Reconnect the Bluetooth.
Call quality issues	Ensure the microphone is not obstructed. Move to an area with less wind or background noise. Check your device's network signal.
Charging issues	Ensure the charging cable is securely connected. Try a different USB power source or cable. Check the charging port for debris.

SPECIFICATIONS

Model Name	X500
Brand	ZOVIMAX
Connectivity Technology	Wireless (Bluetooth 6.0)
Ear Placement	Open Ear
Form Factor	Neckband
Water Resistance Level	IP68 (Waterproof)
Control Method	Touch
Battery Type	Lithium-polymer (Rechargeable)
Battery Life	Up to 18 hours (Playtime)
Material	Plastic
Special Features	Open Bone Conduction Technology, Wind Protection, Adjustable LED Safety Light
Compatible Devices	Mobile Phone
Specific Uses for Product	Sport

WARRANTY AND SUPPORT

ZOVIMAX is committed to excellence and the quality of our products.



Image: ZOVIMAX 2-Year Warranty Badge.

Your ZOVIMAX X500 headphones come with a **2-year manufacturer's warranty**. This warranty covers manufacturing defects and ensures the quality of your product. Should any issues arise during this period, please contact our customer support for prompt resolution.

Our dedicated support team is available to answer any questions you may have regarding your product or warranty. Please refer to the contact information provided with your purchase or visit the official ZOVIMAX website for assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

