



Manuals.plus /

› PRAISUN /

› PRAISUN 35.4 Inch Record Player Stand with Power Outlets and LED Lighting User Manual

PRAISUN B0GD12XBDC

PRAISUN 35.4 Inch Record Player Stand with Power Outlets and LED Lighting User Manual

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your PRAISUN 35.4 Inch Record Player Stand. Designed to enhance your audio experience, this stand features integrated power outlets, multi-color LED lighting, and ample storage for your vinyl collection and audio equipment. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your product.



Image: The PRAISUN 35.4 Inch Record Player Stand, showcasing its design and functionality within a home environment.

ASSEMBLY INSTRUCTIONS

Before beginning assembly, ensure all parts are present and undamaged. Refer to the included hardware and part list. Assembly typically requires basic household tools (not included unless specified). Follow the step-by-step instructions provided in the separate assembly guide included in the packaging.

Preparation:

- Unpack all components and lay them out on a clean, soft surface to prevent scratches.
- Verify all parts against the parts list in your assembly guide.
- Keep children and pets away from the assembly area.

Key Assembly Features:

- **Labeled Parts:** All components are clearly labeled for easy identification.
- **Included Tools:** Necessary assembly tools are provided.
- **Cable Management:** The stand includes 4 cable management holes to keep cords neat and organized.
- **Reinforced Base:** Ensures stability and durability.

- **Tapered Table Legs:** Solid wood legs provide stable support.



Image: Close-up illustrating the thoughtful details of the stand, such as cable management holes, tapered legs, and reinforced base for stability.

OPERATING INSTRUCTIONS

Integrated Power Outlets:

The record player stand is equipped with a built-in power strip for convenient device charging and power supply. This includes:

- 2 AC Outlets (125V / 12A)
- 1 USB-C Port (5V / 2A)
- 1 USB Port (5V / 2A)

To use, simply plug the stand's main power cord into a wall outlet. Then, connect your turntable, speakers, phone, or other devices to the integrated outlets and ports.



Image: Detailed view of the integrated power outlets, demonstrating their use for charging devices and powering audio equipment.

3-Color LED Lighting:

The stand features integrated LED lighting to enhance your listening environment. The lighting offers three distinct modes:

- **Cool Light:** Bright, crisp illumination.
- **Warm Light:** Soft, ambient glow.
- **Mixed Light:** A blend of cool and warm tones.

Use the control switch (location specified in assembly guide) to cycle through the different lighting modes to suit your preference.




Image: Visual representation of the three LED lighting options available on the stand, demonstrating the different moods they create.

Storage Options:

The PRAISUN record player stand offers versatile storage solutions for your audio collection and accessories:

- **Side Sliding Cabinets:** Two fluted sliding cabinets provide dust-free storage for various items.
- **Center Vinyl Storage:** The central section includes metal dividers and can hold up to 150 records.
- **Open Storage Shelves:** Flexible space for turntables, speakers, or decorative items.

3-Tier Multiple Storage Options

Stores up to 150 vinyl albums



Image: Overview of the stand's multiple storage tiers, highlighting its capacity for various media and equipment.



Image: Detail of the double-sided grid sliding door, revealing the enclosed storage space.

CARE AND MAINTENANCE

Proper care will ensure the longevity and appearance of your record player stand.

- **Cleaning:** Wipe the smooth surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Dusting:** Regularly dust with a dry, soft cloth to prevent buildup.
- **Spills:** Immediately wipe up any spills to prevent staining or water damage.
- **Placement:** Avoid placing the stand in direct sunlight or near heat sources, which can cause fading or warping.
- **Weight Capacity:** Do not exceed the recommended weight capacity for shelves to prevent structural damage.

TROUBLESHOOTING

If you encounter any issues with your PRAISUN Record Player Stand, please refer to the following common solutions:

- **Stability Issues:**

- Ensure all screws and fasteners are tightened securely.
- Verify the stand is placed on a level surface.

- **Power Outlets Not Working:**

- Check if the stand's main power cord is securely plugged into a functional wall outlet.
- Ensure the devices plugged into the stand's outlets are functioning correctly.
- Check for any tripped circuit breakers in your home.

- **LED Lights Not Functioning:**

- Confirm the stand is receiving power.
- Check the connection of the LED strip to the power source.
- Ensure the control switch is properly connected and functioning.

- **Sliding Doors Sticking:**

- Inspect the tracks for any obstructions or debris.
- Ensure the doors are properly aligned in their tracks.

If problems persist after attempting these solutions, please contact customer support.

PRODUCT SPECIFICATIONS

Product Size



Image: Dimensional drawing of the record player stand, providing key measurements for planning placement.

Feature	Detail
Brand	PRAISUN
Model Number	B0GD12XBDC
Dimensions (Overall)	36.1D x 89.9W x 75.4H centimetres (approximately 35.4 inches wide)
Weight	16.96 kg
Material	Durable Particle Board, Solid Wood Legs
Mounting Type	Floor Mount
Room Type	Living Room, Bedroom, Office, Studio
Number of Shelves	3 (including top surface)
Power Outlets	2 AC (125V/12A), 1 USB-C (5V/2A), 1 USB (5V/2A)
LED Lighting	3-Color (Cool, Warm, Mixed)
Vinyl Capacity	Up to 150 records in center section
Special Features	Cable Management Holes, Sliding Cabinets, Reinforced Base

WARRANTY INFORMATION

PRAISUN products are manufactured to high-quality standards. For specific warranty details, including coverage period and terms, please refer to the warranty card included with your product packaging or visit the official PRAISUN website. Please retain your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report a damaged or missing part, please contact PRAISUN customer support. Contact information can typically be found in your product packaging or on the official PRAISUN website.

When contacting support, please have your product model number (B0GD12XBDC) and proof of purchase readily available.