Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PUPKIDS T223

PUPKIDS Dog Training Collar T223 User Manual

Model: T223 (B0GD16SCFV, B0GCZPB9QF)

Thank you for choosing the PUPKIDS Dog Training Collar. This manual provides essential information for safe and effective use of your device.

1. Setup

1.1 Unboxing and Initial Preparation

Upon receiving your PUPKIDS Dog Training Collar, please ensure all components are present. Remove any protective screen films from the remote control and collar receiver before first use.

Your browser does not support the video tag. Please update your browser to view this content.

Video: Demonstrating the initial setup and testing of the collar's functions, including static, vibration, and tone modes, and how the static test light illuminates.

1.2 Charging the Devices

Fully charge both the remote control and the collar receiver before their first use. The included dual charging cable allows simultaneous charging. The collar receiver has an IPX7 waterproof rating, but the remote is not waterproof.



Image: The PUPKIDS Dog Training Collar and remote control, illustrating the charging process with the dual cable.

1.3 Pairing the Collar(s)

If you are using a single collar, it is typically pre-paired at the factory. For multiple collars or re-pairing:

1. Select 'Dog 1' or 'Dog 2' on the remote and ensure the corresponding 'Collar' channel is turned off.
2. Touch both magnetic red dots (on the remote and receiver) for 5 seconds. The collar's red and green lights will flash, indicating pairing status.
3. Press both the 'Tone' and 'Vibra' buttons on the remote simultaneously to complete the pairing process.

Your browser does not support the video tag. Please update your browser to view this content.

Video: Detailed instructions on how to pair the remote with one or two collar receivers, including visual cues for successful pairing.

1.4 Fitting the Collar

The collar is adjustable for dogs weighing between 20-140 lbs, with neck sizes ranging from 12-25 inches. It is not recommended for small breeds. Ensure a snug but comfortable fit, allowing two fingers to fit between the collar and your dog's neck. The excess strap can be cut off after proper sizing.



Image: Illustrates the adjustable nature of the collar and its suitability for medium to large dogs (20-140 lbs), with a note that it is not for small dogs.

2. Operating the Collar

2.1 Training Modes

The PUPKIDS Dog Training Collar offers four effective training modes:

- **Night-Light Modes:** 3 types (seven-color breathing, colorful streamer, high-bright lights).
- **Tone Mode:** 1-8 adjustable levels.
- **Vibrate Mode:** 1-8 adjustable levels.
- **Static Mode:** 0-100 HI adjustable levels.



Image: Visual representation of the four training modes: Night-Light, Static, Vibra, and Tone, with their respective level ranges.

2.2 Adjusting Training Levels

To adjust the intensity of the Tone, Vibrate, or Static modes, press the intensity dial down to switch between modes. Turn

the dial left for '+' to increase the level or right for '-' to decrease the level.



Image: Shows how to use the intensity dial on the remote to adjust training levels for static, vibration, and tone modes.

2.3 Night-Light Functionality

The collar features three safety anti-lost night-light modes: seven-color breathing lights, colorful streamer lights, and high-bright lights. These are useful for locating your dog in low-light conditions.

- Long-press the light button on the collar to turn the lights on/off.
- Short-press the light button to switch between the different light modes.

Your browser does not support the video tag. Please update your browser to view this content.

Video: Demonstrates the three night-light modes (seven-color breathing, colorful streamer, high-bright) on the PUPKIDS T223 training collar.




Image: Shows a dog wearing the collar with night-lights activated, illustrating how the lights help locate the pet in various dark environments.

2.4 Remote Control Features

- **Channel Selection:** Switch between Dog 1 and Dog 2 channels to control individual collars. The remote can control two dogs simultaneously.
- **Accidental Touch Prevention:** Press the 1/2 button for 5 seconds to lock or unlock the selected channel, preventing unintended activations.
- **Magnetic On/Off:** The collar receiver can be turned on or off by touching the magnetic red dot on the remote to the magnetic red dot on the receiver for 5 seconds.

Your browser does not support the video tag. Please update your browser to view this content.

Video: Demonstrates the innovative magnetic switch feature for turning the collar receiver on and off using the remote control.



Image: Illustrates the magnetic switch mechanism for turning the collar on/off by touching the remote to the receiver.

2.5 Remote Range

The remote control has an operating range of up to 4200 feet in open, unobstructed areas, allowing for flexible training indoors or outdoors.



Image: Depicts a person training two dogs simultaneously with the remote, highlighting the extensive 4200FT remote range in an open field.

3. Maintenance

3.1 Charging and Battery Life

The collar and remote can be fully charged in approximately 2 hours. The collar receiver offers up to 15 days of working time and 200 days of standby time. The remote provides up to 30 days of working time and 200 days of standby time.



Image: Illustrates the quick charging capability and long-lasting battery life of both the remote and the collar receiver.

3.2 Cleaning and Care

Regularly clean the collar and remote with a damp cloth. Ensure the contact points on the receiver are clean and free of debris to maintain optimal performance. The receiver is IPX7 waterproof, suitable for swimming and rainy conditions, but the remote is not waterproof.



Image: Shows a dog in water and rain, emphasizing the IPX7 waterproof rating of the collar receiver, with a clear note that the remote is not waterproof.

3.3 Skin Health

Monitor your dog's skin around the collar area for any signs of irritation or redness. If irritation occurs, discontinue use and consult a veterinarian. Ensure the collar is not worn for more than 12 consecutive hours.

4. Troubleshooting

- **Collar not responding:** Check if both the remote and collar are charged and powered on. Ensure they are properly paired. Verify that you are within the effective remote range.
- **Static mode not working:** Use the included test light to confirm the static function. Ensure the contact points are making proper contact with your dog's skin. Adjust the static level if necessary.

- **Inconsistent training results:** Ensure consistency in your training commands and the use of the collar. Start with lower intensity levels and gradually increase as needed. Consult a professional dog trainer if issues persist.

5. Specifications

Feature	Detail
Brand	PUPKIDS
Model Number	T223
Training Modes	Night-Light (3 types), Tone (1-8 levels), Vibrate (1-8 levels), Static (0-100 HI levels)
Remote Range	Up to 4200 feet (unobstructed)
Collar Waterproof Rating	IPX7
Remote Waterproof Rating	Not waterproof
Dog Weight Range	20-140 lbs
Neck Size Range	12-25 inches
Battery Life (Collar)	15 days working, 200 days standby
Battery Life (Remote)	30 days working, 200 days standby
Charging Time	Approx. 2 hours
Material	Nylon

6. Warranty & Support

6.1 Warranty Information

This PUPKIDS Dog Training Collar comes with a 12-month manufacturer's warranty from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

6.2 Customer Support

For any questions, concerns, or technical assistance regarding your product, please contact PUPKIDS customer support. Refer to the product packaging or the official PUPKIDS website for contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GD16SCFV

More documents and user manuals: **https://manuals.plus/**