

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Huuger](#) /
- › [Huuger 86.6 Inch 15-Drawer Dresser and TV Stand Instruction Manual](#)

Huuger B0GD1D1H24

Huuger 86.6 Inch 15-Drawer Dresser and TV Stand Instruction Manual

Model: B0GD1D1H24 | Brand: Huuger

PRODUCT OVERVIEW

The Huuger 86.6 Inch 15-Drawer Dresser and TV Stand is a versatile furniture piece designed for various rooms, including bedrooms and living rooms. It features an extra-long desktop suitable for TVs ranging from 65 to 85 inches, along with ample storage provided by 15 fabric drawers. The unit is constructed with a sturdy metal frame and a durable engineered wood top, offering both stability and a rustic brown aesthetic.



Image: The Huuger 86.6 Inch Dresser in a dining room setting, showcasing its length and storage capacity. A dog is resting on the floor in front of the dresser.




Image: A detailed diagram illustrating the dimensions of the Huuger 86.6 Inch Dresser, including its overall width (86.6"), height (26.8"), and depth (11.8"), as well as the varying sizes of its 15 drawers.

SETUP AND ASSEMBLY

This dresser is designed for easy assembly. All necessary tools, clearly labeled parts, and easy-to-follow instructions are included to facilitate a straightforward setup process.

Assembly Steps:

1. Unpack all components and verify against the parts list in the included manual.
2. Assemble the metal frame structure according to the step-by-step instructions.
3. Attach the engineered wood top securely to the assembled frame.
4. Insert the fabric drawers into their designated slots. Ensure the reinforced bottom is correctly placed in each drawer.
5. Adjust the leveling feet at the bottom of the dresser to ensure stability on uneven surfaces.
6. Install the anti-tipping device to a wall stud for enhanced safety, especially in households with children or pets.

Assembly Video Guide:

Your browser does not support the video tag.

Video: A general installation guide for a dresser and TV stand, demonstrating the assembly process. While this video is for a similar product from WLIVE, the assembly principles are applicable to the Huuger dresser.

Why Choose Us?



Anti-Tip Design



Adjustable Feet



Quick & Easy Assembly



No unpleasant odors

Image: Visual representation of the dresser's key features, including the anti-tip design for safety, adjustable feet for stability, quick and easy assembly process, and the use of odor-free materials.

OPERATING INSTRUCTIONS

Drawer Usage:

- The 15 fabric drawers are designed for smooth operation. Pull gently on the handles to open and push to close.
- Each drawer features a reinforced bottom to maintain its shape and support contents.
- Utilize the varied drawer sizes to organize different items, from clothing and bedding to office supplies and media accessories.

TV Stand Functionality:

- The 86.6-inch wide top surface can accommodate TVs from 65 to 85 inches.
- Place your television centrally on the top surface, ensuring it is stable and balanced.
- The drawers below can store media devices, remote controls, and other entertainment accessories, keeping your living space tidy.



Image: The Huuger 86.6 Inch Dresser serving as a TV stand in a living room, with a 65-inch television positioned above it, demonstrating its suitability for large screens.

Your browser does not support the video tag.

Video: A product overview of the Huuger 86.6 Inch Dresser, highlighting its features as a TV stand and storage unit with 15 fabric drawers.

MAINTENANCE

To maintain the appearance and longevity of your Huuger dresser, follow these simple care instructions:

- **Cleaning the Surface:** Wipe the engineered wood top and metal frame with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Cleaning Fabric Drawers:** For the fabric drawers, spot clean with a mild detergent and a damp cloth. Allow to air dry completely. Do not machine wash or tumble dry.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.
- **Avoid Overloading:** Do not overload the drawers beyond their capacity to prevent damage to the fabric or the frame.

SPECIFICATIONS

Feature	Detail
Brand	Huuger
Product Dimensions	11.8"D x 86.6"W x 26.8"H
Color	Rustic Brown
Room Type	Bedroom, Living Room
Material	Engineered Wood, Fabric
Number of Drawers	15
Item Weight	44.9 pounds
Assembly Required	Yes
Recommended TV Sizes	65 to 85 inches

TROUBLESHOOTING

If you encounter any issues with your Huuger dresser, please refer to the following common troubleshooting tips:

- **Wobbly Unit:** Ensure all screws are tightened. Use the adjustable feet at the bottom to level the dresser on uneven floors.
- **Drawers Not Sliding Smoothly:** Check that the fabric drawers are correctly inserted into their tracks and that nothing is obstructing their movement. Ensure the reinforced bottom is flat.
- **Missing Parts:** If any parts are missing upon unpacking, please contact Huuger customer support immediately.

WARRANTY AND SUPPORT

For warranty information, product support, or to report any issues, please contact Huuger customer service. Keep your purchase receipt and model number (B0GD1D1H24) handy for faster service.

You can often find support contact details on the manufacturer's website or through the retailer where the product was purchased.