

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Kismile](#) /

› [Kismile 4.41 Cu.Ft Compact Refrigerator Mini Fridge - Model BC-128C-E User Manual](#)

Kismile BC-128C-E

Kismile 4.41 Cu.Ft Compact Refrigerator Mini Fridge - Model BC-128C-E User Manual

Your guide to safe and efficient operation

IMPORTANT SAFETY INSTRUCTIONS

To ensure safe operation and reduce the risk of injury or damage, please read all instructions before using this appliance. Keep this manual for future reference.

- **Electrical Safety:** Ensure the refrigerator is connected to a properly grounded outlet. Do not use extension cords or ungrounded adapters.
- **Placement:** Place the refrigerator on a firm, level surface away from direct sunlight and heat sources. Ensure adequate ventilation around the unit.
- **Ventilation:** Maintain a minimum clearance of 10cm from both sides and the backside to facilitate proper heat dissipation.
- **Handling:** Do not damage the refrigerant circuit. Avoid placing heavy objects on top of the refrigerator.
- **Cleaning:** Always unplug the refrigerator before cleaning. Use a soft cloth and mild detergent.
- **Defrosting:** Defrost manually when frost accumulation reaches 5mm. Unplug the unit and remove all food. Allow frost to melt naturally.
- **Children:** This appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

PRODUCT OVERVIEW & FEATURES

The Kismile 4.41 Cu.Ft Compact Refrigerator is designed for efficient and quiet cooling, ideal for various small spaces.

Efficient Partitioning Large Capacity



Image: Interior view of the Kismile refrigerator highlighting its efficient partitioning for various items like canned drinks, boxed beverages, fruits, and cooler compartment.

- **Compact Design, Large Capacity:** Features a 4.41 cu.ft fresh food refrigeration area, offering an ideal footprint-to-capacity ratio for small spaces.
- **Reversible Door:** The door hinge can be adjusted to open from either the left or right side, adapting to different room layouts.
- **Adjustable Feet:** Equipped with adjustable feet for stability on various flooring types.
- **Adjustable Thermostat:** A mechanical dial allows precise temperature control from 32°F to 50°F.
- **Silent & Energy Saving:** Operates at less than 38 dB and has an ultra-low annual consumption of 253 kWh.
- **Easy Cleaning:** Includes 3 detachable glass shelves and a drip tray for convenient cleaning.



Image: Dimensions of the Kismile refrigerator, showing a height of 31.5 inches, width of 20.28 inches, and depth of 22.05 inches, with a 4.41 Cu.Ft capacity.

SETUP

Follow these steps for initial setup of your refrigerator:

1. **Unpacking:** Remove all packaging materials, including bottom cushions and foam pads. Tear off the protective film on the door and the refrigerator body.
2. **Placement:** Place the refrigerator in a well-ventilated indoor area on a flat and sturdy ground. Avoid direct sunlight, heat sources, or moist/watery places to prevent rust or reduction of insulating effect. Ensure distances from both sides and backside are more than 10cm for heat dissipation.
3. **Initial Power-On:** The refrigerator should stay for half an hour before connecting power when it is firstly started. It should run for 2 to 3 hours before loading fresh or frozen foods. For summer, it should run for more than 4 hours.
4. **Adjusting Feet:** Adjust the leveling feet by turning them clockwise to raise or counter-clockwise to lower the refrigerator until it is horizontal and stable.
5. **Reversible Door (Optional):** The door can be reversed to open from the left or right. Refer to the detailed instructions in the manual for this procedure, which typically requires a cross screwdriver, thin-blade screwdriver, and masking tape.

Reversible Door Design

Left or right opening to fit your space and layout



Image: The Kismile refrigerator demonstrating its reversible door design, allowing it to open from either the left or right side to fit various space and layout needs.

OPERATING INSTRUCTIONS

The refrigerator features a mechanical dial for temperature control.

- **Temperature Control:** The mechanical dial offers 7 adjustment functions, allowing you to set the desired temperature between 32°F and 50°F.
- **Setting the Temperature:** Turn the dial to the desired setting. '1' is the warmest setting, and '7' is the coldest setting. 'OFF' means the unit is stopped.
- **Optimal Use:** Accurately set the temperature to keep beverages, fruits, vegetables, or beauty products fresh.

Adjustable Temperature Levels

32 °F to 50 °F can be adjusted with a button, and the display shows the temperature that is currently set.



Image: The Kismile refrigerator showing its adjustable temperature dial (32°F to 50°F) and examples of items that can be stored, such as fruits, vegetables, desserts, and drinks.

Your browser does not support the video tag.

Video: A user demonstrating the interior capacity and features of the Kismile 4.41 Cu.Ft Compact Refrigerator, including its shelves and door compartments. The video highlights the practical storage solutions for various items.

MAINTENANCE

Regular maintenance ensures the longevity and efficiency of your refrigerator.

- **Cleaning:** Unplug the appliance before cleaning. Use a soft cloth with warm water and a mild detergent. Avoid abrasive cleaners or solvents. The removable glass shelves and drip tray can be easily taken out for thorough cleaning.
- **Defrosting:** This refrigerator requires manual defrosting. When frost on the evaporator reaches 5mm (about 0.2 inches) thick, unplug the unit, remove all food, and allow the frost to melt naturally. Use a soft cloth to wipe away melted water. Do not use sharp objects to remove ice.
- **Long-Term Storage:** If the refrigerator will not be used for an extended period, unplug it, clean it thoroughly, and leave the door slightly ajar to prevent odors and mold growth.

TROUBLESHOOTING

If you experience issues with your refrigerator, consult the table below before contacting customer service.

Problem	Possible Cause	Solution
Refrigerator does not operate	Not plugged in; power outage; fuse blown.	Check power supply; plug in firmly.
Temperature not cold enough	Door not closed properly; thermostat set too warm; excessive food load; poor ventilation.	Ensure door is sealed; adjust thermostat to colder setting; reduce food load; ensure proper ventilation.
Excessive noise	Unit not level; contact with wall/furniture.	Adjust leveling feet; ensure clearance from surrounding objects.
Water on floor	Drainage plug loose; excessive frost melting.	Check and secure drainage plug; defrost unit.

SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Brand Name	Kismile
Model Info	BC-128C-E
Item Weight	44.9 pounds
Product Dimensions	20.35 x 21.46 x 31.5 inches
Capacity	4.41 Cubic Feet
Annual Energy Consumption	253 Kilowatt Hours
Installation Type	Undercounter
Form Factor	Compact, Freezer Less
Special Features	Adjustable Shelves, Compact, Energy Efficient, Large Capacity, Low Noise
Color	BLACK
Voltage	115 Volts
Defrost	Manual
Door Hinges	Reversible
Shelf Type	Glass
Number of Shelves	3
Included Components	Beverage refrigerator

WARRANTY AND SUPPORT

Your Kismile refrigerator is covered by a manufacturer's warranty. For specific details regarding warranty coverage, duration, and how to claim service, please refer to the warranty card included with your product or contact Kismile customer support.

- **Warranty Service:** Warranty service must be obtained from Kismile Consumer Services or an authorized Midea servicer.
- **Warranty Period:** One year full warranty from original purchase date.
- **Consumer Responsibility:** The consumer is responsible for diagnosis, removal, transportation, and reinstallation costs required because of service.
- **Exclusions:** The warranty typically does not cover failures caused by improper installation, misuse, damage, or unauthorized repairs.

For further assistance or inquiries, please visit the [Kismile Store on Amazon](#).