

## Ulanzi MA66

# Ulanzi MA66 Multi-functional Quick Release Tripod Instruction Manual

Model: MA66 | Brand: Ulanzi

## INTRODUCTION

Thank you for choosing the Ulanzi MA66 Multi-functional Quick Release Tripod. This versatile accessory is designed to enhance your photography and videography experience with DJI Osmo Pocket 3 and Pocket 4 cameras. It offers multiple modes of operation, including tabletop stand, handheld grip, tripod, hanging, and magnetic attachment, providing flexibility for various shooting environments. Please read this manual carefully to ensure proper use and maintenance of your device.

## PRODUCT OVERVIEW

The Ulanzi MA66 is a compact and lightweight accessory crafted from durable aluminum alloy. It integrates five distinct modes into a single unit, making it an indispensable tool for creators on the go.

### Key Features:

- **5-in-1 Functionality:** Seamlessly switch between Tabletop Stand, Handheld Grip, Tripod, Hanging Mode, and Magnetic Stand.
- **Strong Magnetic Attachment:** Equipped with powerful magnets for secure attachment to smooth metal surfaces.
- **Uka & Arca-Swiss Quick Release System:** Supports both Uka and Arca-Swiss quick release plates for rapid device changes.
- **210° Angle Adjustment:** Flexible rotation allows for diverse shooting angles.
- **Dedicated Design:** Specifically designed for DJI Osmo Pocket 3 and Pocket 4, ensuring full access to buttons, screen rotation, joystick, and charging port.
- **Lightweight & Portable:** Weighing approximately 75g, it is easy to carry and can be attached to backpack straps.

## SETUP

### Attaching Your Camera:

1. Ensure the Ulanzi MA66 is in its folded or desired configuration.
2. Align the quick release plate on your DJI Osmo Pocket 3 or Pocket 4 with the corresponding slot on the MA66.

3. Slide the camera onto the MA66 until it clicks securely into place. Verify that the camera is firmly attached before use.

### Using the Quick Release System:

The MA66 supports both Uka and Arca-Swiss quick release systems. To detach, simply press the release mechanism and slide the camera off. To attach, align and slide until it locks. If the base does not attach correctly, adjust its orientation until it is firmly fixed.

## Ukaクイックリリースシステム対応

Arca-Swissクイックリリースもあ対応でき、あらゆる撮影状況にすぐに対応可能。



\*ベースが正しく取り付けられていない場合は、しっかりと固定されるよう方向を調整してください。

Image: Demonstrates the Uka and Arca-Swiss quick release system for easy camera attachment and detachment.

### OPERATING MODES

The Ulanzi MA66 offers five versatile operating modes to suit various shooting needs:

#### 1. Tabletop Stand Mode:

Unfold the legs to create a stable base for placing your camera on flat surfaces like tables or desks. Ideal for video calls, live streaming, or stationary recording.

# 自撮り棒と卓上三脚の2in1

手持ちと三脚モードを自由に切り替え、様々な撮影シーンに対応



Image: Shows the MA66 in tabletop stand mode, supporting a camera on a desk.

## 2. Handheld Grip Mode:

Fold the legs together to form a comfortable handheld grip. This mode is perfect for vlogging, action shots, or any situation requiring mobile filming.



## 多機能pocket3用スタンド



Image: Illustrates the MA66 being used as a handheld grip for dynamic shooting.

### 3. Tripod Mode:

Extend the legs fully to use the MA66 as a mini tripod. This provides stability for time-lapses, long exposures, or group photos.

### 4. Hanging Mode:

Utilize the integrated hook to hang the device from railings, fences, or other suitable structures. This allows for unique POV shots and stable recording in unconventional locations. When using hanging mode, ensure all tripod feet are in full contact with a stable, flat support surface. Do not attach to moving objects (such as car windows).

# 隠しフック掛けるモード

簡単に柵や手すりにデバイスを固定いつでも最適な俯瞰撮影を楽しめます。



\*掛けるモードを使用する場合、すべてのストランドフットは、安定した平らな支持面に全面が接触している必要があります。可動物体（車両の窓など）には取り付けないでください。



Image: Shows the MA66 hanging from a tennis net, demonstrating its hanging mode functionality.

## 5. Magnetic Stand Mode:

The powerful magnets allow the MA66 to attach securely to smooth metal surfaces like shelves or refrigerators. This provides a stable, hands-free setup for creative angles. Ensure the magnetic attachment is used correctly for optimal stability.

# 強力マグネット吸着で、しっかり安定して固定

簡単に柵や手すりにデバイスを固定いつでもどこでも最適な俯瞰撮影を楽しめます。



Image: Displays the MA66 attached magnetically to a metal surface, highlighting its strong magnetic hold.

## Angle Adjustment:

The MA66 features a 210° free angle adjustment. The rotation is smooth, allowing you to easily find and lock your desired shooting angle. The design ensures that the charging port remains unobstructed.

## 多角度自由調節

角度が柔軟で、回転がスムーズ、  
様々な撮影アングルに対応



充電ポートを塞がない



1/4インチネジ



Image: Illustrates the 210-degree angle adjustment capability and unobstructed charging port.

### Portability:

The MA66 can be flexibly stored and easily retrieved. Its feet can be attached to a strap buckle, allowing for convenient carrying on backpack straps. This enables quick access and hands-free shooting while on the move.

# ストラップで柔軟に収納、 取り出し自由



重量約  
75g



脚部をストラップバックルに装着可能。  
すぐに取り出せて両手が自由になる



吊り下げたまま撮影可能。  
移動撮影時のアングル選択が広がる

Image: Shows the MA66 attached to a backpack strap, demonstrating its portability and quick access feature.

## MAINTENANCE

- **Cleaning:** Wipe the product with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the tripod in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically check all moving parts and connections for any signs of wear or damage.
- **Avoid Overloading:** Do not exceed the maximum load capacity of 249.99g to prevent damage.

## TROUBLESHOOTING

- **Camera Not Attaching Securely:** Ensure the quick release plate is correctly aligned and fully inserted until it locks. Check for any obstructions.
- **Magnetic Attachment Instability:** Ensure the metal surface is smooth, flat, and clean. The magnetic force is strong but may not hold on uneven or painted surfaces. Always verify stability before leaving your camera unattended.
- **Angle Adjustment Stiffness:** The hinge is designed to be firm to maintain position. Apply gentle, consistent force to adjust the angle.
- **Tripod Instability:** Ensure the legs are fully extended and placed on a flat, stable surface. The compact design is best suited for tabletop use; for outdoor or uneven terrain, exercise caution.

## SPECIFICATIONS

|                         |                                      |
|-------------------------|--------------------------------------|
| Brand                   | Ulanzi                               |
| Model Number            | MA66 (C110JP110)                     |
| Color                   | Black                                |
| Compatible Devices      | DJI Osmo Pocket 3, DJI Osmo Pocket 4 |
| Material                | Aluminum Alloy                       |
| Item Weight             | 75 grams                             |
| Weight Limit            | 249.99 grams                         |
| Folded Size (D x W x H) | 38 x 11.5 x 121.8 mm                 |
| Tripod Head Type        | Ball Head                            |
| Special Feature         | Multi-functional                     |
| Warranty                | 1-year manufacturer warranty         |

### WARRANTY AND SUPPORT

The Ulanzi MA66 Multi-functional Quick Release Tripod comes with a 1-year manufacturer warranty. If you encounter any issues with the product, please contact Ulanzi customer support. We aim to respond to inquiries within 24 hours. For further assistance or to report a defect, please refer to the contact information provided with your purchase or visit the official Ulanzi website.