

[Manuals.plus](#) /

› [NEWBULIG](#) /

› NEWBULIG 10FT Offset Cantilever Patio Umbrella Instruction Manual

NEWBULIG A013-503-010-009

NEWBULIG 10FT Offset Cantilever Patio Umbrella Instruction Manual

Model: A013-503-010-009

PRODUCT OVERVIEW

The NEWBULIG 10FT Offset Cantilever Patio Umbrella is designed to provide ample shade and comfort for various outdoor environments. Its offset design offers more usable space compared to traditional patio umbrellas. Key features include:

- **10FT Offset Design:** Creates more space underneath, ideal for covering patio furniture without a central pole obstruction.
- **UV Protection & Water-Resistant Fabric:** Crafted from 180g polyester fabric, offering UV protection and water repellency with American standard 4-level color fastness to resist fading.
- **Easy Tilt Adjustment:** Equipped with a hand crank lifting mechanism for effortless opening and closing, and adjustable angle to block the sun throughout the day.
- **Enhanced Stability:** Features a reinforced cross base, 2 pole locking knobs, 8 sturdy ribs, and a top air vent for optimal support and wind resistance. A weighted base (62 lbs or more) is recommended for stability.
- **Durable Construction:** Heavy-duty iron frame with rust-proof powder coating, and premium aluminum crank handle for long-lasting performance.

COMPONENTS LIST

Please ensure all components are present before beginning assembly:

- Umbrella Canopy with Ribs
- Main Pole Assembly
- Cross Base (2 interlocking pieces)
- Crank Handle
- Pole Locking Knobs (2)
- Assembly Hardware (bolts, washers, wrench)
- User Manual (this document)

Note: Weighted base units (e.g., water/sand-filled) are sold separately or may be included depending on your

specific product package.

SETUP AND ASSEMBLY

Follow these steps to assemble your NEWBULIG Patio Umbrella. It is recommended to have two people for easier assembly.

1. Assemble the Cross Base:

Interlock the two cross base pieces to form an 'X' shape. Secure them using the provided bolts and washers. Ensure all connections are tight for maximum stability.

ENHANCED STABILITY



Image: Detailed view of the cross base assembly, showing the interlocking pieces and bolt locations.

2. Attach the Main Pole:

Insert the main pole into the center of the assembled cross base. Secure it using the remaining bolts and the provided wrench. Ensure the pole is firmly attached and upright.

PRODUCT DIMENSION



Image: The main pole being inserted and secured into the center of the cross base.

3. Install Weighted Base (if applicable):

If using separate weighted base units (e.g., water/sand-filled), place them onto the arms of the cross base. Fill them according to their instructions to provide the necessary weight for stability. A minimum of 62 lbs is recommended.



Image: A fully assembled patio umbrella with weighted base units placed on the cross base, providing stability.

4. **Attach Umbrella Canopy:**

Carefully lift the umbrella canopy assembly and slide it onto the top of the main pole. Secure it using the pole locking knobs. Ensure the canopy is properly seated and locked in place.

ADJUSTMENT



EASILY ADJUST TO THE PERFECT ANGLE

The handle on the pole moves up and down to adjust the umbrella's angle.

Image: A close-up of the umbrella pole showing the locking knobs and the attachment point for the canopy.

Assembly Video Guide:

Your browser does not support the video tag.

Video: This official seller video demonstrates the step-by-step assembly process of the NEWBULIG Patio Umbrella, including attaching the base, pole, and canopy.

OPERATING INSTRUCTIONS

Operating your NEWBULIG Patio Umbrella is straightforward:

1. Opening the Umbrella:

Locate the hand crank on the main pole. Rotate the crank clockwise to smoothly open the umbrella canopy until it is fully extended.

2. Adjusting the Tilt:

To adjust the angle of the umbrella, use the tilt adjustment mechanism located on the main pole. This allows you to position the canopy to effectively block the sun as it moves.

PATIO UMBRELLA

Pack & Go, Shade Anywhere



Image: The umbrella canopy shown at various tilt angles, demonstrating the manual tilt adjustment feature.

3. Closing the Umbrella:

Rotate the hand crank counter-clockwise to retract the umbrella canopy until it is fully closed. Secure the closed canopy with any integrated straps to prevent it from unfurling in windy conditions.

4. Securing the Pole:

Ensure the 2 pole locking knobs are tightened to keep the umbrella pole securely in place and prevent unwanted rotation or movement.



Image: Close-up of the umbrella fabric highlighting its UV protection, waterproof, and fade-resistant properties.

MATERIAL



Aluminum Crank Handle

Aluminum crank handle for superior sturdiness and durability.

Metal Tube

Metal tubes with rust-proof powder coating.



Image: A view of the top air vent on the umbrella canopy, designed to boost airflow and wind resistance.

MAINTENANCE

To ensure the longevity and optimal performance of your NEWBULIG Patio Umbrella, please follow these maintenance guidelines:

- **Storage:** Store the umbrella indoors during harsh weather conditions, including strong winds, heavy rain, or snow. This prevents damage to the canopy and frame.
- **Cleaning:** Clean the canopy fabric periodically with mild soap and water. Rinse thoroughly and allow to air dry completely before closing or storing.
- **Frame Inspection:** Regularly inspect the iron frame for any signs of rust or damage. Touch up any scratches on the powder coating to prevent corrosion.
- **Hardware Check:** Periodically check all bolts and knobs to ensure they remain tight. Re-tighten as necessary to maintain stability.

TROUBLESHOOTING

If you encounter any issues with your NEWBULIG Patio Umbrella, refer to the following common solutions:

- **Umbrella is unstable:** Ensure the cross base is fully assembled and all bolts are tightened. Verify that the weighted base units are filled to the recommended weight (62 lbs or more) and properly placed on the cross base.
- **Crank mechanism is stiff:** Apply a silicone-based lubricant to the moving parts of the crank mechanism. Avoid using oil-based lubricants as they can attract dirt.

- **Canopy does not open/close smoothly:** Check for any obstructions in the canopy ribs or fabric. Ensure the pole is straight and not bent.
- **Fabric fading:** While the fabric is fade-resistant, prolonged exposure to intense sunlight can still cause some fading over time. Store the umbrella when not in use for extended periods to minimize exposure.

SPECIFICATIONS

Brand	NEWBULIG
Model Number	A013-503-010-009
Size	10FT-Basic
Canopy Diameter	116.14 Inches
Item Dimensions (W x H)	126.38"W x 96.46"H
Item Weight	12.8 Kilograms
Canopy Material	Polyester (180g)
Frame Material	Iron
Handle Material	Aluminum
Opening Mechanism	Crank Lift
Umbrella Tilt Mechanism	Manual Tilt
Special Features	Cantilever, Heavy Duty Fabric, Reinforced Frame, UV Resistant, Water Resistant
Recommended Base Weight	62 lbs or more (not included with basic model)

WARRANTY AND SUPPORT

For warranty information, technical support, or to inquire about replacement parts, please contact NEWBULIG customer service through the retailer where the product was purchased. Keep your purchase receipt and model number handy for faster service.