



[Manuals.plus](#) /

› [RORRY](#) /

› RORRY Flow Portable Charger (Model CB4-10000) User Manual

RORRY CB4-10000

RORRY Flow Portable Charger (Model CB4-10000) User Manual

10000mAh 40W Fast Charging Power Bank with Built-in USB-C Cable and Foldable Wall Plug

INTRODUCTION

The RORRY Flow Portable Charger is a versatile 10000mAh power bank designed for efficient charging of multiple devices. It features a 40W fast charging capability, a built-in USB-C cable, and a foldable wall plug for convenience. This manual provides essential information for the safe and effective use of your RORRY Flow Portable Charger.

All-in-Mini

One charger for all devices



Image: RORRY Flow Portable Charger connected to an iPad, Apple Watch, and AirPods, demonstrating its multi-device charging capability.

WHAT'S IN THE BOX

- 10000mAh Power Bank x 1
- 1M USB-C Cable x 1
- User Manual x 1

SETUP

Charging the Power Bank

Before initial use, fully charge your RORRY Flow Portable Charger. You have two primary methods for charging:

1. **Using the Foldable Wall Plug:** Extend the integrated foldable wall plug and insert it directly into a standard AC wall outlet. The LED display will show the charging progress.
2. **Using the USB-C Input Port:** Connect the provided 1M USB-C cable to the power bank's USB-C input port and to a compatible USB wall adapter (not included).

A full charge typically takes approximately 2 hours. The LED display will show '100' when fully charged.

**Ready to Power up
Wherever You Are**
No need to carry extra charger or cable



Image: RORRY Flow Portable Charger plugged into a wall outlet using its foldable plug, charging an iPhone and AirPods.

Checking Battery Level

Press the power button once to view the current battery percentage on the LED display.

Video: Demonstration of the RORRY Flow Portable Charger's features, including the foldable wall plug and built-in cables.

OPERATING

Charging Devices with Built-in USB-C Cable

Pull out the integrated USB-C cable from its storage slot. Connect the USB-C end to your compatible device (e.g., iPhone 15/16/17, iPad, MacBook). The power bank will automatically begin charging. For optimal fast charging, ensure your device supports USB Power Delivery (PD).



Image: Close-up of a RORRY Flow Portable Charger fast charging an iPhone 17 via its built-in USB-C cable.

Charging Apple Watch

Place your Apple Watch directly onto the wireless charging pad located on the top surface of the power bank. Ensure the watch is centered for proper alignment. The power bank will initiate 5W wireless charging for your Apple Watch.



Image: RORRY Flow Portable Charger wirelessly charging an Apple Watch on its dedicated charging pad.

Video: Detailed review highlighting the RORRY Flow Portable Charger's compatibility with Apple Watch and its travel-friendly design.

Charging Devices via USB-A/USB-C Ports

For devices requiring a different cable, use the additional USB-A or USB-C output ports. Connect your device's charging cable to the

appropriate port on the power bank. The power bank supports simultaneous charging of up to four devices (built-in USB-C, wireless Apple Watch, USB-A port, and USB-C output port).

Video: Overview of the RORRY Flow 10000mAh 40W Fast Charging Power Bank, showcasing its various charging options.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surface of the power bank. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, fully charge the power bank at least once every three months if not in regular use. Avoid fully discharging the battery frequently.

TROUBLESHOOTING

- **Device not charging:**
 - Ensure the power bank has sufficient charge.
 - Verify that the charging cable is securely connected to both the power bank and the device.
 - Try a different charging cable or port.
 - Confirm your device is compatible with the power bank's output specifications.
- **Power bank not charging:**
 - Ensure the foldable wall plug is fully inserted into a live AC outlet, or the USB-C input cable is properly connected to a working power source.
 - Check if the wall outlet is functional.
 - Try a different wall outlet or USB adapter.
- **Slow charging:**
 - Ensure your device supports fast charging protocols (e.g., PD) to utilize the 40W output.
 - Using multiple output ports simultaneously may distribute power, potentially reducing individual port speeds.
 - Check if the charging cable is rated for fast charging.

SPECIFICATIONS

Model Name	CB4-10000
Battery Capacity	10000 Milliamp Hours
Output Wattage	40 Watts
Output Current	3 Amps
Voltage	20 Volts
Connector Type	USB-C*2 + USB-A*1
Number of Ports	2 (plus built-in USB-C cable and wireless pad)
Battery Cell Type	Lithium Ion
Battery Charge Time	2 Hours
Item Weight	0.55 Pounds (approx. 250g)

Item Dimensions (L x W x Th)	4.3" x 2.2" x 1.2" (10.9cm x 5.6cm x 3.0cm)
Compatible Devices	AirPods / AirPods Pro, Apple Watch Series 11/10/9/8/7/6/SE/5/4, Apple Watch Ultra 1/2/3, iPad Air/Pro/Mini, iPhone 17/16/15/Air

WARRANTY AND SUPPORT

The RORRY Flow Portable Charger comes with a 30-Day Money Back Guarantee, a 1-Year Warranty, and Lifetime Technical Support. For any issues or inquiries, please contact our support team at support@rorry.com. We aim to reply within 24 hours.

