

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [VINGLI](#) /

› [VINGLI Boho Fluted TV Stand \(Model VL-G52009258\) User Manual](#)

VINGLI VL-G52009258

VINGLI Boho Fluted TV Stand (Model VL-G52009258) User Manual

Your guide to assembly, operation, and care.

1. INTRODUCTION

Thank you for choosing the VINGLI Boho Fluted TV Stand. This manual provides essential information for the safe assembly, proper operation, and effective maintenance of your new entertainment center. Please read these instructions carefully before beginning assembly and retain them for future reference.

Safety Information

- **Maximum Weight Capacity:** Do not load more than 330 lbs (150 kg) onto the TV stand. Exceeding this limit may result in structural failure and injury.
- **Sharp Edges:** Exercise caution around sharp edges during assembly to prevent injury.
- **Assembly:** Ensure all parts are correctly assembled and fasteners are securely tightened before use.
- **Placement:** Place the TV stand on a flat, stable, and level surface to prevent tipping.
- **Children:** Keep children away from the assembly area. Do not allow children to climb on or play with the TV stand.

2. PACKAGE CONTENTS

Before beginning assembly, verify that all components and hardware are present. Refer to the separate assembly instruction sheet included in your package for a detailed list of parts and diagrams. If any parts are missing or damaged, please contact VINGLI customer support.

3. SETUP AND ASSEMBLY INSTRUCTIONS

The VINGLI Boho Fluted TV Stand is designed for straightforward assembly. A detailed assembly manual with step-by-step instructions and diagrams is included in your product packaging. Please follow these instructions carefully.

General Assembly Steps:

1. **Unpack:** Carefully remove all components from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Match each part to the corresponding labels in the assembly manual.
3. **Follow Instructions:** Assemble the unit by following the numbered steps in the provided assembly manual. Pay close attention to the orientation of each piece.
4. **Secure Fasteners:** Ensure all screws, bolts, and other fasteners are tightened securely. Do not overtighten.
5. **Attach Legs:** Securely attach the solid wood legs to the base of the TV stand.

Product Dimensions



Figure 3.1: Product Dimensions. This image illustrates the overall dimensions of the TV stand (58"W x 15.8"D x 32"H) and indicates it can accommodate TVs up to 70 inches.

Anti-Scratch and Waterproof



Smooth Metal Handle



Soft-Close Hinges



Sturdy solid wood legs

Figure 3.2: Key Features. This image highlights the anti-scratch and waterproof surface, smooth metal handles, soft-close hinges, and sturdy solid wood legs, all integral components of the TV stand's construction.

4. OPERATING INSTRUCTIONS

The VINGLI Boho Fluted TV Stand offers versatile storage and display options for your media devices and decor.

Storage Compartments:

- **Spacious Desktop:** The 58-inch wide desktop is designed to accommodate televisions up to 70 inches.
- **Open Shelves:** Utilize the four open shelves for easy access to media players, gaming consoles, or decorative items.
- **Hidden Compartments:** The two hidden compartments, featuring fluted doors and soft-close hinges, provide concealed storage for items you wish to keep out of sight.

Adjustable Shelf:

The TV stand includes a 3-position adjustable shelf, allowing you to customize the storage space to fit items of

various heights. To adjust the shelf:

1. Empty the shelf of all contents.
2. Carefully lift the shelf and remove it from its current position.
3. Reinsert the shelf into the desired set of pre-drilled holes, ensuring it is level and securely seated on all four pins.



Figure 4.1: Ample Storage Space. This image highlights the spacious desktop, fixed shelf, adjustable shelf, and storage cabinets, demonstrating the versatile storage options available.



Smart Function

3-position Adjustable Shelf
for Flexible Storage

Figure 4.2: Smart Function: Adjustable Shelf. This image shows the 3-position adjustable shelf, indicating its flexibility for accommodating different item sizes.

Cable Management:

The TV stand features integrated cable management openings to help organize and conceal wires from your electronic devices, maintaining a tidy appearance.

5. MAINTENANCE

Proper care will extend the life and appearance of your VINGLI TV Stand.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the walnut wood finish.
- **Spills:** Clean up spills immediately to prevent staining or water damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Heat and Moisture:** Keep the TV stand away from direct heat sources and areas of high humidity.

- **Fasteners:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten as necessary.

6. TROUBLESHOOTING

If you encounter any issues with your VINGLI TV Stand, refer to the following common solutions:

- **Wobbling or Instability:**
 - Ensure the TV stand is placed on a level surface.
 - Check that all assembly screws and bolts are securely tightened.
 - Verify that the solid wood legs are properly attached and not damaged.
- **Doors Not Closing Properly:**
 - Inspect the soft-close hinges for any obstructions or misalignment.
 - Adjust the hinge screws if necessary to ensure proper door alignment.
- **Scratches or Dents:**
 - For minor scratches, wood repair kits or markers designed for walnut finishes may be used.
 - Prevent future damage by using coasters or protective pads under items placed on the desktop.

If these steps do not resolve the issue, please contact customer support.

7. SPECIFICATIONS

Attribute	Detail
Model Number	VL-G52009258
Product Dimensions	58 x 15.8 x 32 inches (W x D x H)
Item Weight	77.2 pounds
Material	Walnut Wood
Color	Walnut
Maximum Load Capacity	330 lbs (150 kg)
TV Size Compatibility	Up to 70 inches
Assembly Required	Yes (Instructions Included)

8. WARRANTY AND SUPPORT

For any questions, concerns, or assistance with your VINGLI Boho Fluted TV Stand, please contact VINGLI-Direct customer support. Information regarding specific warranty terms may be available through your purchase documentation or by contacting the seller directly. Please note that a 30-day return policy is typically offered for this product.

For further assistance, please refer to the contact information provided at the point of purchase or on the official VINGLI website.

© 2025 VINGLI. All rights reserved.