

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Havit](#) /
- › [Havit Fuxi H7SE Wireless Gaming Headset User Manual](#)

Havit FUXI H7SE

Havit Fuxi H7SE Wireless Gaming Headset User Manual

Model: FUXI H7SE

1. INTRODUCTION

The Havit Fuxi H7SE is a versatile wireless gaming headset designed for an immersive audio experience across multiple platforms. It features dual connectivity modes (2.4GHz wireless and Bluetooth 5.2), 40mm dynamic drivers, a detachable noise-canceling microphone, and a comfortable over-ear design. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your headset.

2. PACKAGE CONTENTS

Please check the box for the following items:

- Havit Fuxi H7SE Gaming Headset
- Detachable Microphone
- 2.4GHz USB Dongle
- USB-C Charging Cable
- 3.5mm Audio Cable
- User Manual

3. PRODUCT OVERVIEW

Familiarize yourself with the various components and controls of your Havit Fuxi H7SE headset.



Figure 3.1: Angled view of the Havit Fuxi H7SE headset, highlighting the controls on the left ear cup.





Figure 3.2: Detailed infographic illustrating key features, components, and specifications of the headset.

Key components include:

- **Adjustable Headband:** For a comfortable fit.
- **Cloud-Soft Ear Cushions:** Designed for extended wear.
- **Detachable Microphone:** Flexible and noise-canceling for clear communication.
- **Power Button:** To turn the headset on/off.
- **Volume Wheel:** For adjusting audio output.

- **Mode Switch Button:** To toggle between 2.4GHz and Bluetooth modes.
- **USB-C Port:** For charging the headset.
- **3.5mm Audio Jack:** For wired connection.

4. SETUP

4.1 Initial Charging

Before first use, fully charge the headset. Connect the supplied USB-C charging cable to the headset's USB-C port and the other end to a USB power source (e.g., computer, wall adapter). The charging indicator light will show charging status and turn off when fully charged. A full charge takes approximately 3 hours.

4.2 Attaching the Microphone

Insert the detachable microphone into the microphone port located on the left ear cup. Ensure it is securely connected. The microphone is flexible and can be adjusted to your preferred position.



Figure 4.1: Front view of the headset with the detachable microphone correctly attached.

4.3 Connecting via 2.4GHz Wireless (PC, PS4, PS5, Switch Docked)

1. Plug the 2.4GHz USB dongle into an available USB port on your PC, PS4, PS5, or Nintendo Switch dock.
2. Power on the headset by pressing and holding the Power button.
3. Press the Mode Switch button to select 2.4GHz mode. The headset will automatically connect to the dongle.
4. On your device, ensure the Havit Fuxi H7SE is selected as the audio output and input device.

4.4 Connecting via Bluetooth (Smartphones, Tablets, Switch Handheld)

1. Power on the headset by pressing and holding the Power button.
2. Press the Mode Switch button to select Bluetooth mode. The headset will enter pairing mode, indicated by a flashing LED.
3. On your device (smartphone, tablet, Nintendo Switch in handheld mode), go to Bluetooth settings and search for available devices.
4. Select "Havit Fuxi H7SE" from the list to pair. Once connected, the LED will stop flashing.

4.5 Connecting via 3.5mm Audio Cable

For wired connection, use the provided 3.5mm audio cable. This mode does not require battery power.

1. Connect one end of the 3.5mm audio cable to the headset's 3.5mm audio jack.
2. Connect the other end to the 3.5mm audio port on your device.
3. The headset will automatically switch to wired mode.

5. OPERATION

5.1 Power On/Off

- **Power On:** Press and hold the Power button for 2-3 seconds until the LED indicator lights up.
- **Power Off:** Press and hold the Power button for 3-4 seconds until the LED indicator turns off.

5.2 Switching Connectivity Modes

Press the Mode Switch button to cycle between 2.4GHz wireless and Bluetooth modes. An audible prompt or LED indicator will confirm the selected mode.

5.3 Volume Control

Rotate the Volume Wheel located on the ear cup to increase or decrease the audio volume.

5.4 Microphone Mute

The headset features an integrated microphone mute function. Refer to the product diagram for the exact location of the mute button or switch. Press it to mute/unmute the microphone.

6. BATTERY AND CHARGING

The Havit Fuxi H7SE headset is equipped with a rechargeable Lithium-ion battery.

- **Battery Life:** Up to 30 hours in 2.4GHz wireless mode, and up to 43 hours in Bluetooth mode.
- **Charging Time:** Approximately 3 hours for a full charge.
- **Charging Input:** 5V 750mA via USB-C.
- **Low Battery Indicator:** The headset will provide an audible warning or visual cue when the battery is low.

To preserve battery life, turn off the headset when not in use.

7. MAINTENANCE

Proper care will extend the life of your headset.

- **Cleaning:** Use a soft, dry cloth to clean the headset. Do not use harsh chemicals or abrasive materials.
- **Storage:** Store the headset in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Resistance:** This headset is not water-resistant. Avoid exposure to liquids.
- **Handling:** Avoid dropping or subjecting the headset to strong impacts.

8. TROUBLESHOOTING

If you encounter issues with your headset, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound from headset	Headset not powered on; Incorrect audio output selected; Low battery; Not connected.	Ensure headset is on and charged. Check device audio settings. Re-establish connection.
Microphone not working	Microphone muted; Not properly attached; Incorrect input device selected.	Unmute microphone. Ensure it's securely attached. Check device input settings.
Cannot connect via 2.4GHz	Dongle not plugged in; Headset in Bluetooth mode; Out of range.	Ensure dongle is connected. Switch headset to 2.4GHz mode. Move closer to the dongle.
Cannot connect via Bluetooth	Headset not in pairing mode; Device Bluetooth off; Already connected to another device.	Switch headset to Bluetooth pairing mode. Enable Bluetooth on your device. Disconnect from other devices.
Short battery life	Not fully charged; Old battery.	Ensure full charge cycle. Contact support if battery life significantly degrades.

9. SPECIFICATIONS

Feature	Detail
Model Name	HAVIT FUXI H7SE
Connectivity Technology	Wireless (2.4GHz USB Dongle, Bluetooth 5.2)
Compatible Devices	PC, PS4, PS5, Nintendo Switch, Smartphones
Driver Size	40mm Dynamic Drivers
Impedance	64 Ohms
Frequency Response	20Hz - 20kHz
Microphone Sensitivity	-42±3dB
Wireless Distance	Up to 10 meters
Battery Type	Lithium-ion

Feature	Detail
Battery Life (2.4GHz)	Up to 30 hours
Battery Life (Bluetooth)	Up to 43 hours
Charging Time	Approximately 3 hours
Charging Input	5V 750mA (USB-C)
Product Weight	238g
Material	Plastic
Ear Placement	Over-Ear (Circum-aural)
Color	Black
Water Resistance	No

10. WARRANTY AND SUPPORT

10.1 Manufacturer Warranty

The Havit Fuxi H7SE Gaming Headset comes with a **1-year manufacturer warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

10.2 Customer Support

For technical assistance, warranty claims, or any questions regarding your Havit Fuxi H7SE headset, please contact Havit customer support through their official website or the retailer where the product was purchased. Please have your proof of purchase and product model number (FUXI H7SE) ready when contacting support.