

[Manuals.plus](#) /

› [RORRY](#) /

› RORRY Flow 10000mAh 40W Portable Charger User Manual (Model CB4-10000)

## RORRY CB4-10000

# RORRY Flow 10000mAh 40W Portable Charger User Manual

Model: CB4-10000

## INTRODUCTION

Thank you for choosing the RORRY Flow Portable Charger. This compact and versatile power bank is designed to keep your devices charged on the go, featuring a 10000mAh capacity, 40W fast charging, a built-in USB-C cable, and a foldable wall plug. Please read this manual carefully to ensure proper use and optimal performance of your device.

## WHAT'S IN THE BOX

- 10000mAh Power Bank x 1
- 1M USB-C Cable x 1
- User Manual x 1

## PRODUCT OVERVIEW

The RORRY Flow Portable Charger is an all-in-one charging solution. It integrates multiple charging options into a single, portable device.

# All-in-Mini

One charger for all devices



Image: The RORRY Flow Portable Charger simultaneously charging an iPad, an Apple Watch, and an iPhone, highlighting its 'All-in-Mini' feature for multiple devices.

## Key Features:

- **Built-in USB-C Cable:** For convenient charging without extra cables.
- **Foldable Wall Plug:** Allows direct charging from a wall outlet and recharging the power bank.
- **Wireless Apple Watch Charger:** Integrated magnetic charging pad for Apple Watch.
- **Multiple Ports:** Includes USB-C (input/output) and USB-A (output) ports for broad compatibility.
- **Digital Display:** Shows remaining battery percentage.
- **LoopLink Design:** A sturdy key ring for easy attachment to bags or keys.



Image: A hand holding the RORRY Flow Portable Charger, illustrating its compact size and portability, ideal for travel.

## SETUP

### Charging the Power Bank:

1. **Via Wall Outlet:** Fold out the integrated AC plug and insert the power bank directly into a wall socket. The digital display will show the charging progress.
2. **Via USB-C Cable:** Connect the provided USB-C cable to the power bank's USB-C input port and to a compatible USB power adapter (not included).

A full charge typically takes approximately 2 hours.

# Ready to Power up Wherever You Are

No need to carry extra charger or cable



Image: The RORRY Flow Portable Charger plugged into a wall outlet using its foldable prongs, simultaneously charging an iPhone via its built-in USB-C cable and AirPods via an external cable.

## OPERATING INSTRUCTIONS

### Charging Your Devices:

The RORRY Flow Portable Charger supports simultaneous charging of up to 4 devices.

1. **For iPhone/iPad/MacBook (USB-C compatible):** Use the built-in USB-C cable or connect your device's USB-C cable to the power bank's USB-C output port.
2. **For Apple Watch:** Place your Apple Watch on the magnetic charging pad located on the power bank. Ensure it aligns correctly for wireless charging.
3. **For Other USB Devices (USB-A compatible):** Connect your device's USB-A cable to the power bank's

USB-A output port.



Image: An iPhone 17 connected to the RORRY Flow Portable Charger via its built-in USB-C cable, displaying a rapid charge of 50% in 20 minutes.

# 5W Fast Charging

Full Charges Apple Watch 11 in 1.2h



Image: An Apple Watch placed on the magnetic charging pad of the RORRY Flow Portable Charger, showing the 5W fast charging in progress.

## Checking Battery Level:

Press the power button once to activate the digital display, which shows the remaining battery percentage of the power bank.

## MAINTENANCE

- Keep the power bank away from water, fire, and extreme temperatures.
- Avoid dropping or subjecting the device to strong impacts.
- Clean the device with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Store in a cool, dry place when not in use.

## TROUBLESHOOTING

- **Device not charging:** Ensure the power bank is charged. Check all cable connections. For wireless charging, ensure the Apple Watch is correctly positioned on the magnetic pad.
- **Slow charging:** Verify that your device supports fast charging and that the cables used are appropriate. Charging multiple devices simultaneously may reduce individual charging speeds.
- **Power bank not recharging:** Ensure the wall plug is fully extended and inserted into a live outlet, or that the USB-C input cable is securely connected to a working power source.

## SPECIFICATIONS

Feature	Detail
Model Name	CB4-10000
Battery Capacity	10000 Milliamp Hours
Output Wattage	40 Watts
Connector Type	USB-C*2 + USB-A*1
Special Features	Built-in Cable, Built-in Wall Plug, Fast Charging, LoopLink Design, Pocket Size
Compatible Devices	AirPods / AirPods Pro, Apple Watch Series 11/10/9/8/7/6/SE/5/4, Apple Watch Ultra 1/2/3, iPad Air/Pro/Mini, iPhone 17/16/15/Air
Battery Charge Time	2 Hours (for power bank)
Item Weight	0.55 Pounds
Item Dimensions	4.3"L x 2.2"W x 1.2"Th

## WARRANTY AND SUPPORT

The RORRY Flow Portable Charger comes with a 30-Day Money Back Guarantee, a 1-Year Warranty, and Lifetime Technical Support.

For any problems or inquiries, please contact [support@rorry.com](mailto:support@rorry.com). Our support team aims to reply within 24 hours.

## OFFICIAL PRODUCT VIDEO

Video: An official product video from RORRY Store showcasing the RORRY Flow Portable Charger's features, including its compact design, built-in cables, and multi-device charging capabilities. This video highlights the convenience and versatility of the 10000mAh 40W fast charging power bank.